

# Avocent® ACS800/8000 Advanced Console System

Installer/User Guide

The information contained in this document is subject to change without notice and may not be suitable for all applications. While every precaution has been taken to ensure the accuracy and completeness of this document, Vertiv assumes no responsibility and disclaims all liability for damages resulting from use of this information or for any errors or omissions. Refer to other local practices or building codes as applicable for the correct methods, tools, and materials to be used in performing procedures not specifically described in this document.

The products covered by this instruction manual are manufactured and/or sold by Vertiv. This document is the property of Vertiv and contains confidential and proprietary information owned by Vertiv. Any copying, use or disclosure of it without the written permission of Vertiv is strictly prohibited.

Names of companies and products are trademarks or registered trademarks of the respective companies. Any questions regarding usage of trademark names should be directed to the original manufacturer.

### **Technical Support Site**

If you encounter any installation or operational issues with your product, check the pertinent section of this manual to see if the issue can be resolved by following outlined procedures.

Visit https://www.vertiv.com/en-us/support/ for additional assistance.

# TABLE OF CONTENTS

1 Introduction	1
1.1 Features and Benefits	1
1.1.1 Access options	1
1.1.2 Web user interface (web UI)	2
1.1.3 IPv4 and IPv6 support	
1.1.4 Flexible users and groups	2
1.1.5 Security	2
1.1.6 Authentication	2
1.1.7 VPN based on IPSec with NAT traversal	
1.1.8 Packet filtering	3
1.1.9 SNMP	
1.1.10 Data logging, notifications, alarms and data buffering	3
1.1.11 Power management	
1.1.12 Auto discovery	3
1.1.13 FIPS module	3
1.1.14 RestAPI server	4
1.2 Configuration Examples	4
12.1 Serial port LED status	9
2 Getting Started	10
21 Installation	
22 Turning On the Console System	
221 AC power	10
222 DC power	
2.3 Configuring a Console System	11
223 Using Telnet or SSH	
3 Accessing the Console System via the Web UI	14
3.1 Wizard Mode	14
3.2 Web User Interface Overview for Administrators	16
3.3 Expert Mode	17
3.3.1 Access	17
3.3.2 System tools	17
3.3.3 System	21
3.3.4 Network	26
3.3.5 IPSec(VPN)	30
3.3.6 SNMP configuration	33
3.3.7 Ports	
3.3.8 Cellular modem	
3.3.9 Pluggable devices	
3.3.10 Authentication	58
3.3.11 Users accounts and user groups	<u></u> 61

3.3.12 Events and logs	<u>69</u>
3.3.13 Power management	
3.3.14 Sensors	75
3.3.15 Active sessions	78
3.3.16 Monitoring	78
3.3.17 Change password	79
3.4 Web UI Overview for Regular Users	
3.5 Scheduled Tasks	
3.6 Diagnostics	
Appendices	
Appendices Appendix A: Technical Specifications	
Appendix A: Technical Specifications	84 86
Appendix A: Technical Specifications Appendix B: Zero-touch Provisioning	84 86 91
Appendix A: Technical Specifications Appendix B: Zero-touch Provisioning Appendix C: Bootp Configuration Retrieval	84 
Appendix A: Technical Specifications Appendix B: Zero-touch Provisioning Appendix C: Bootp Configuration Retrieval Appendix D: SSH Setup Allowing RSA Keypair Authentication Instead of a Username/Password	
Appendix A: Technical Specifications         Appendix B: Zero-touch Provisioning         Appendix C: Bootp Configuration Retrieval         Appendix D: SSH Setup Allowing RSA Keypair Authentication Instead of a Username/Password         Appendix E: Port Information for Communication with the Vertiv <sup>™</sup> Avocent <sup>®</sup> DSView Software	84 86 91 92 93 94

ii

# **1** Introduction

The Vertiv<sup>™</sup> Avocent<sup>®</sup> ACS800/8000 advanced console system serves as a single point for access and administration of connected devices, such as serial consoles, modems and power devices. The console system supports secure remote data center management and out-of-band management of IT assets from any location worldwide.

#### NOTE: Unless noted, references to a console system refer to all models in the 800/8000 series.

The console system provides secure local (console port) and remote (IP and dial-up) access. The console system runs the Linux<sup>®</sup> operating system with a persistent file system in Flash memory that can be upgraded with a local file on a computer connected to the console system.

Multiple administrators can be logged into the console system at the same time and can use the web user interface (web UI), the Command Line Interface (CLI utility), the RestAPI or the Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView<sup>™</sup> 4 management software to access and configure the console system.

# NOTE: Unless otherwise noted, all references to Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView software in this document refer to version 4 or greater.

Depending on the model, the console system has either four or eight USB ports to support modems, storage devices, network adapters, USB hubs and USB console devices. Some models have an SD card slot to support an additional storage device.

Two network ports support connections to more than one network or can be configured for Ethernet bonding for redundancy and greater reliability or network failover support.

For dial-in and secure dial-back with Point-to-Point Protocol (PPP), an optional internal modem can be factory installed or you can use an external modem connected to either a serial or USB port.

Some models also come equipped with an antenna for cellular connectivity.

## 1.1 Features and Benefits

## 1.1.1 Access options

Secure access is available through the following local (analog console port) and remote (digital IP and dial-up) options:

- LAN/WAN IP network connection.
- Dial-up to a factory-configured internal modem (optional) or a modem connected to one of the serial or USB ports.
- Some models also have an antenna for cellular connectivity.
- Target device connection. An authorized user can make a Telnet, SSH v2 or Raw connection to a target device. For Telnet or SSH to be used for target device connections, the Telnet or SSH service must be configured in the Security Profile that is in effect.
- Console system console connection. An administrator can log in either from a local terminal or from a computer with a terminal emulation program that is connected to the console port and can use the CLI utility. The CLI utility prompt (--:- cli->) displays at login.

More than one administrator can log into the console system and have an active CLI or web UI session. All sessions receive the following warning message when the configuration is changed by another administrator or by the system: *The appliance configuration has been altered from outside of your session*. Upon receipt of this message, each administrator needs to verify that changes made during the session were saved.

## 1.1.2 Web user interface (web UI)

Users and administrators can perform most tasks through the web user interface (web UI), which can be accessed with HTTP or HTTPS. The web UI runs in Microsoft Internet Explorer, Microsoft Edge, Mozilla Firefox, Google Chrome and Apple Safari on any supported computer that has network access to the console system. The list of supported client browsers and their versions are available in the release notes.

NOTE: When accessing the console system via the web UI, do not disable additional dialogs if prompted by your browser. Disabling dialogs will disable some functionality of the web UI.

## 1.1.3 IPv4 and IPv6 support

The console system supports dual stack IPv4 and IPv6 protocols. The administrator can use the web UI or CLI to configure support for IPv4 addresses only or for both IPv4 and IPv6 addresses. The following list describes the IPv6 support provided in the console system:

- DHCP client
- Dial-in and dial-out sessions (PPP links)
- Vertiv™ Avocent® DSView software integration
- ethO and eth1 Ethernet interfaces
- Firewall (IP tables) HTTP/HTTPs
- Linux kernel
- NTP client
- Remote authentication: Radius, Tacacs+, LDAP and Kerberos servers
- SNMP
- SSH and Telnet access
  - Syslog server

#### NOTE: IPSec is not supported with IPv6.

### 1.1.4 Flexible users and groups

An account can be defined for each user on the console system or on an authentication server. The admin and root users have accounts by default, and either can add and configure other user accounts. Access to ports can be optionally restricted based on authorizations an administrator can assign to custom user groups or individual users. For more information, see Users accounts and user groups on page 61.

### 1.1.5 Security

Security profiles determine which network services are enabled on the console system. Administrators can either allow all users to access enabled ports or allow the configuration of group and user authorizations to restrict access. You can also select a security profile, which defines which services (FTP, TFTP, ICMP, IPSec and Telnet) are enabled and SSH and HTTP/HTTPS access. The administrator can select either a preconfigured security profile or create a custom profile. For more information, see Security on page 21.

## 1.1.6 Authentication

Authentication can be performed locally, with One Time Passwords (OTP), a remote Kerberos, LDAP, RADIUS, TACACS+ authentication server or a Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView server. The console system also supports remote group authorizations for the LDAP, RADIUS and TACACS+ authentication methods. Fallback mechanisms are also available.

Any authentication method configured for the console system or the ports is used for authentication of any user who attempts to log in through Telnet, SSH or the web UI. Duo Push authentication can be used as the second factor of multi-factor authentication for appliance authentication. For more information, see Authentication on page 58.

## 1.1.7 VPN based on IPSec with NAT traversal

If IPSec is enabled in the selected security profile, an administrator can use the VPN feature to enable secure connections. For more information, see IPSec(VPN) on page 30.

## 1.1.8 Packet filtering

An administrator can configure a console system to filter packets like a firewall. Packet filtering is controlled by chains, which are named profiles with user-defined rules. The console system filter table contains a number of built-in chains that can be modified but not deleted. An administrator can also create and configure new chains.

## 1.1.9 SNMP

If SNMP is enabled in the selected security profile, an administrator can configure the Simple Network Management Protocol (SNMP) agent on the console system to answer requests sent by an SNMP management application.

The console system SNMP agent supports SNMP v1/v2 and v3, MIB-II and Enterprise MIB. For more information, see SNMP configuration on page 34.

NOTE: The text files with the Enterprise MIB (ACS8000-MIB.asn) and the TRAP MIB (ACS8000-TRAP-MIB.asn) are available in the appliance under the /usr/local/mibs directory.

## 1.1.10 Data logging, notifications, alarms and data buffering

An administrator can set up data logging, notifications and alarms to alert administrators of problems with email, SMS, SNMP trap or Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView software notifications. An administrator can also store buffered data locally, remotely or with Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView management software. Messages about the console system and connected servers or devices can also be sent to syslog servers.

## 1.1.11 Power management

The console system enables users who are authorized for power management to turn power on, turn power off and reset devices plugged into a connected power distribution unit (PDU). The power devices can be connected to any serial port or be network managed. Authorized users can also monitor and control a connected uninterruptible power supply (UPS) device. For more information, see Power management on page 71.

## 1.1.12 Auto discovery

An administrator can enable auto discovery to find the hostname of a target connected to a serial port. Auto discovery's default probe and answer strings have a broad range. An administrator can configure site-specific probe and answer strings. Auto discovery can also be configured to execute a command on the target to determine the hostname.

## 1.1.13 FIPS module

The 140 series of Federal Information Processing Standards (FIPS) are U.S. government computer security standards that specify requirements for cryptography modules.

The console system uses an embedded cryptographic module that is based on the FIPS 140-2 validated cryptographic module (certificate number 4282) running on a Linux ARM platform. For more information, see FIPS module on page 22.

## 1.1.14 RestAPI server


4

The console system provides a RESTful API (referred to as the RestAPI) for accessing and configuring the console system. For details on the RestAPI, see the Vertiv<sup>™</sup> Avocent<sup>®</sup> ACS800/8000 Advanced Console System Application Programming Interface (API) User Guide.

## **1.2 Configuration Examples**

The following graphic and table illustrate an Avocent ACS800/8000 advanced console system configuration with all possible options. Options vary by model and no model has all the options shown.

Figure 1.1 ACS8000 Advanced Console System Configuration with All Options Shown




Number	Description
1	Power buttons (dual power supply shown).
2	Cellular antennas for the cellular modem (not available on some models).
3	Connect a phone line to the Modem port for the internal modem.
4	SD card slot (not available on some models).
5	USB ports for supported USB devices (not available on some models).
6	Sensor port for a 1-Wire environmental sensor (not available on some models).
7	Digital In port for smoke, leak, pressure or dry contact sensors (not available on some models).
8	Console port for connecting a terminal or workstation. The console system is configured using a terminal or terminal emulator with session settings of: 9600, 8, N and 1, with no flow control.
9	Power supply (dual power supply shown).
10/11	LAN ports. The ports on the left are for copper interface connections. The ports on the right are for fiber interface connections. You may connect to either or both network ports for redundancy, however only one LAN1 and one LAN2 port may be used at the same time. If both LAN1 or LAN2 ports are connected, the fiber connection has priority.
12	Two USB ports on the rear of the console system for additional USB devices.
13	Serial ports. Using CAT 5e or CAT 6 cables and DB9 or DB25 console adaptors, connect the appropriate serial and power devices to the serial ports on the console system.
14	Status LEDs.
15	SIM card slot.

#### Table 1.1 ACS8000 Advanced Console System Configuration Descriptions

The following graphic and table illustrate the multi-protocol ports and LEDs.


#### Figure 1.2 Avocent ACS8000 Advanced Console System Multi-Protocol Ports and LEDs



### Table 1.2 Multi-Protocol Ports and LED Descriptions

Number	Description
1	Multi-protocol ports. These two ports can accept RS422 and RS485 pin-outs in addition to Cyclades and Cisco pin-outs.
2	LEDs. The STATUS LED is green when the console system is fully booted up and initialized. The P1 and P2 LEDs indicate an active power supply. P1 is green when Power Supply 1 is on. P2 is green when Power Supply 2 is on.


#### Figure 1.3 Inserting the SIM card



Number	Description	
1	Remove the screw to release the cover. Once the card is inserted, replace the cover and reinsert the screw.	
2	Remove the cover to expose the SIM card slot. Replace the cover once the card has been inserted.	
3	Insert the card.	

#### Table 1.3 Inserting the SIM Card Descriptions

### Figure 1.4 Typical ACS800 Advanced Console System Configuration



Number	Description
1	LEDs. The STATUS LED is green when the console system is fully booted up and initialized. The Power LED is green when power is being supplied to the console system.
2	Connect a phone line to the Modem port for the internal modem.
3	Sensor ports for 1-Wire environmental, smoke, leak, pressure or dry contact sensors.
4	USB ports for supported USB devices.
5	Serial ports. Using CAT 5e or CAT 6 cables and DB9 or DB25 console adaptors, connect the appropriate serial and power devices to the serial ports on the console system. All of the serial ports are multi-protocol and user selectable with RS485, RS422 and RS232 pinouts.
6	Copper LAN ports. You may connect to either or both network ports for redundancy.
7	Console port.
8	Power supply.

Table 1.4 Typical ACS800 Advanced Console System Descriptions

## 1.2.1 Serial port LED status

Each serial port has two LEDs that illuminate either green or yellow. Green LEDs indicate the status for physical connection with a serial port, remote connectivity (when applicable) and data transfer. Yellow LEDs indicate whether a serial port is being monitored along with the alert level (emergency, alert or none) of a monitored target. The following table describes the meaning of each LED status.

State	Description for Green LEDs	Description for Yellow LEDs
Off (not illuminated)	No physical connection	No data buffering
On (solid green or yellow)	Device is physically connected to the serial port	Data buffering is enabled for the serial port
Slow blink	Telnet, SSH or Raw session is active	Alert is active
Fast blink	TX or RX data activity	Emergency

#### Table 1.5 LED Status Descriptions

# 2 Getting Started

## 2.1 Installation

For information on installing your console system, see the ACS800 or ACS8000 Quick Installation Guide that shipped with your product.

## 2.2 Turning On the Console System

Depending on the model, the console system is supplied with single or dual AC or DC power supplies.

WARNING! Always execute the shutdown command through the web UI, CLI, RestAPI or Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView software under the Overview/Tools node before turning the console system off, then on again. This will ensure the reset doesn't occur while the file system in Flash is being accessed, and it helps avoiding Flash memory corruptions.

## 2.2.1 AC power

To turn on a console system with AC power:

- 1. Ensure the console system is turned off.
- 2. Plug the power cable into the console system and into a power source.
- 3. Turn the console system on.
- 4. Turn on the power switches of the connected devices.

### 2.2.2 DC power

DC power is connected to a DC-powered console system by way of three wires: Return (RTN), Ground (GND) and -48 VDC. For redundancy, there are two sets of wires that can be connected to two separate power sources.




WARNING! It is critical that the power source supports the DC power requirements of your console system. Make sure that your power source is the correct type and that your DC power cables are in good condition before proceeding. Failure to do so could result in personal injury or damage to the equipment.

The following diagram shows the connector configuration for DC power.

NOTE: DC Power is only available on the ACS8000 console system.

#### Figure 2.1 DC Power Connection Terminal Block



#### Table 2.1 DC Power Connection Details

Number	Description	Number	Description
1	Power switch, one for each power source	4	RTN (Return)
2	Connections for the first power source	5	GND (Ground)
3	Connections for the second power source	6	-48 VDC

#### To turn on a console system with DC power:

- 1. Ensure the console system is turned off.
- 2. Ensure DC power cables are not connected to a power source.
- 3. Remove the protective cover from the DC power block by sliding it to the left or right.
- 4. Loosen all three DC power connection terminal screws.
- 5. Connect your return lead to the RTN terminal, your ground lead to the GND terminal, your -48 VDC lead to the -48 VDC terminal and tighten the screws.
- 6. Slide the protective cover back into place over the DC terminal block.
- 7. If your console system has dual-input DC terminals, repeat steps 3-6 for the second terminal.
- 8. Connect the DC power cables to the DC power source and turn on the DC power source.
- 9. Turn on the console system.
- 10. Turn on the power switches of the connected devices.

## 2.3 Configuring a Console System

A console system may be configured at the appliance level through the command line interface accessed through the CONSOLE or Ethernet port. All terminal commands are accessed through a terminal or PC running terminal emulation software.

NOTE: To configure the console system using Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView software, see the Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView 4.5 Management Software Installer/User Guide. To configure the console system using the web UI, see Web User Interface Overview for Administrators on page 16. To configure the console system using the RestAPI, see the Vertiv<sup>™</sup> Avocent<sup>®</sup> ACS800/8000 Advanced Console System Application Programming Interface (API) User Guide. To configure the console system using Telnet or SSH, see the Vertiv<sup>™</sup> Avocent<sup>®</sup> ACS800/8000 Advanced Console System Command Reference Guide.

#### To connect a terminal to the console system:

1. Using a null modem cable, connect a terminal or a PC that is running terminal emulation software (such as HyperTerminal) to the CONSOLE port on the back panel of the console system. An RJ-45 to DB9 (female)

cross adaptor is provided.

The terminal settings are 9600 bits per second (bps), 8 bits, 1 stop bit, no parity and no flow control.

2. Turn on the console system. When the console system completes initialization, the terminal will display the login banner plus the login prompt.

### 2.3.1 Using Telnet or SSH

An authorized user can use a Telnet or SSH client to make a connection directly to the console of a device if all of the following are true:

The Telnet or SSH:

- protocol is enabled in the selected security profile.
- client is available, and it is enabled on the computer from which the connection is made.

#### To use Telnet to connect to a device through a serial port:

For this procedure, you need the username configured to access the serial port, the port name (for example, 14-35-60-p-1), device name (for example, ttyS1), TCP port alias (for example, 7001) or IP port alias (for example, 100.0.0.100) and the hostname of the console system or its IP address.

To use a Telnet client, enter the information in the dialog boxes of the client.

-or-

To use Telnet in a shell, enter the following command.

```
#telnet [hostname | IP address]
login: username:[portname | device name | TCP Port Alias]
-or-
#telnet [hostname | IP address] TCP Port Alias
login: username
-or-
#telnet IP Port Alias
login: username
```

#### To close a Telnet session:

Enter the Telnet hotkey defined for the client. The default is Ctrl ] + q to quit.

-or-

Enter the text session hotkey for the CLI prompt and then enter exit.

#### To use SSH to connect to a device through a serial port:

For this procedure, you need the username configured to access the serial port, the port name (for example, 14-35-60-p-1), TCP port alias (for example, 7001), device name (for example, ttyS1), and the hostname of the console system, IP address or IP Port alias (for example, 100.0.0100).

#### To use an SSH client:

Enter the information in the dialog boxes of the client.

-or-

#### To use SSH in a shell, enter the following command:

```
ssh -l username:port_name [hostname | IP_address]
-or-
ssh -l username:device_name [hostname | IP_address]
-or-
ssh -l username:TCP_Port_Alias [hostname | IP_address]
-or-
ssh -l username IP_Port_Alias
```

#### To close an SSH session:

At the beginning of a line, enter the hotkey defined for the SSH client followed by a period. The default is ~.

-or-

Enter the text session hotkey for the CLI prompt and then enter exit.

# 3 Accessing the Console System via the Web UI

Once you've connected your Avocent ACS800/8000 advanced console system to a network, you can access the console system with its web user interface (web UI). The web UI provides direct access to the console system via a graphical user interface instead of a command-based interface.

NOTE: For a new console system using factory defaults, LAN1 attempts to obtain an IP address using DHCP, and LAN2 has a static IP address of 192.168.161.10. Use LAN2 for initial configuration or use the Console port to discover the IPv4 DHCP-assigned address for LAN1.

NOTE: For instructions on accessing the console system via the CLI or Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView software, see the Vertiv<sup>™</sup> Avocent<sup>®</sup> ACS800/8000 Advanced Console System Command Reference Guide or the Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView 4.5 Management Software Installer/User Guide.

## 3.1 Wizard Mode

The Wizard mode is designed to simplify the setup and configuration process by guiding an administrator through the configuration steps. An administrator can configure all ports in the CAS Profile and set the Security Profile, Network and Users Settings using the Wizard.

By default, the first time an administrator accesses the console system through the web UI, the Wizard displays. Once the console system has been configured, Expert mode becomes the default and subsequent log-ins open in Expert mode. An administrator can toggle between Expert and Wizard modes by clicking the tab bar on the web UI administrator screen.

The following procedures describe how to configure the console system from the Wizard.

#### To configure security parameters and select a Security Profile:

- 1. Select System Security Security Profile.
- 2. Select the desired Security Profile. If using a Custom Security Profile, click the checkboxes and enter values as needed to configure the services, SSH and HTTP and HTTPS options to conform with your site security policy.
- 3. Pluggable devices, which include devices connected to SD card slot and USB ports, are disabled by default. To enable them, check the Enable Pluggable Device Detection box. Storage devices (SD card and USB storage) are enabled by default when Pluggable Device Detection is enabled. To disable this subset of pluggable devices, clear the Enable Pluggable Storage Devices box. Pluggable devices also include the 1-Wire Sensor port which is enabled by default. To disable the 1-Wire Sensor port, uncheck the Enable 1-Wire Support box.

# NOTE: These options appear for all console system models, even though some models do not have SD card or 1-Wire sensor ports. If your model does not have these ports, leave these options disabled.

- 4. Under the Bootp Configuration Retrieval heading, uncheck the box(es) to disable Bootp configuration retrieval and/or live configuration retrieval.
- 5. If you are not using Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView software to manage the appliance, uncheck the Allow Appliance to be Managed by DSView box.
- 6. Click Next to configure the Network or click the Network, Ports or Users link to open the appropriate screen.

#### To configure network parameters:

- 1. Select the *Network* link in the content area.
- 2. Enter the Hostname, Primary DNS, Domain and MTU in the appropriate fields.
- 3. Select the IPv4 or IPv6 method for the ETH0 interface. If using Static, enter the Address, Mask and Gateway in the appropriate fields.
- 4. Enable or disable LLDP (Link Layer Discovery Protocol).
- 5. Enable or disable IPv6 support.
- 6. Click Next to configure ports or click on the Security, Ports or Users link to open the appropriate screen.

#### To configure Ports:

- 1. Select the *Ports* link in the content area.
- 2. Check the box to enable all ports.
- 3. Use the appropriate drop-down menus to select the values for the RJ45 Pin-Out, Speed, Parity, Data Bits, Stop Bits, Flow Control, Protocol, Authentication Type and Data Buffering Status and Data Buffering Time Stamp.
- 4. Select the data buffering type. If using NFS, enter the NFS Server and NFS Path information in the appropriate fields.
- 5. Click Next to configure users or click on the Network, Security or Users link to open the appropriate screen.

#### To configure users and change passwords:

- 1. Select the Users link in the content area.
- Click a username (*admin* or *root*) and enter the new password in the Password and Confirm Password fields.
   -or-
- 3. Click Add to add a user. Enter the new username and password in the appropriate fields.
- 4. (Optional) To force the user to change their password the next time they log in, select the User must change password at next login checkbox.
- 5. Assign the user to one or more groups.
- 6. (Optional) Configure account expiration and password expiration.
- 7. Click Next.
- 8. Repeat steps 3-7 as needed to configure new user accounts and assign them to default groups.

NOTE: By default, all configured users can access all enabled ports. Additional configuration is needed if your site security policy requires you to restrict user access to ports.

9. Click Save, then click Finish.

## 3.2 Web User Interface Overview for Administrators

NOTE: For an overview of the web user interface (UI) for regular users, see Web UI Overview for Regular Users on page 79.


#### To log into the web UI:

- 1. Open a web browser and enter the console system IP address in the address field.
- 2 Log in with your username and password. The default username is **admin**. The first time you log in as admin, leave the password field blank. You are prompted to create a new password.

NOTE: By default, the root user is disabled. An admin can enable the root user from the Users - Local Accounts - User Names page.

The following figure shows a typical web UI screen for an administrator.

#### Figure 3.1 Administrator Web UI Screen



#### Table 3.1 Web UI Screen Areas

Number	Description
1	Top option bar. The name of the appliance and of the logged in user appear on the left side. Refresh, Print, Logout and Help buttons appear on the right.
2	Tab bar. Displays whether the admin is in Expert or Wizard mode.
3	Side navigation bar (sidebar). Menu options for configuration, viewing of system information and access to devices. The options change based on user rights.
4	Content area. Contents change based on the options selected in the side navigation bar.

## 3.3 Expert Mode

The following tabs are available in the side navigation bar of the web UI when an administrator is in Expert mode.

## 3.3.1 Access

All the devices connected to the console system can be viewed from the Access icon.

To view and connect to devices using the web UI:

- 1. Select Access in the side navigation bar. The content area displays the name of the console system and a list of names or aliases for all installed and configured devices the user is authorized to access.
- 2. Select Serial Viewer from the Action column to open a connection to the selected serial port.

-or-

Select Appliance Viewer from the Action column to open a connection to the console system.

NOTE: The HTML5 viewer is the default viewer to open; however, if an administrator has selected the JNLP viewer, the Java applet viewer appears.

3. If you are not automatically logged in, log in when prompted.

### 3.3.2 System tools

Click System Tools to display icons which can be clicked to reboot or shut down the console system, upgrade the console system's firmware, save or restore its configuration, generate or download certificates, export files, run diagnostics or open a terminal session with the console system.

### Upgrading firmware

The console system supports the storage of two firmware images. As the firmware is upgraded, the image not currently running will be overwritten with the new firmware. The latest firmware can be downloaded from the Vertiv website and accessed by the console system using a File Transfer Protocol (FTP), Secure File Transfer Protocol (SFTP) or Secure Copy Protocol (SCP) server. Firmware can also be downloaded via a web browser from the user's local machine.

To view the console system's current firmware version, from the sidebar of the Expert tab, click System-Information.

#### To upgrade a console system's firmware:

- From <u>http://www.Vertiv.com</u> browse to the product updates section and find the firmware for your console system.
- 2. Save the new firmware to a server accessible via FTP, SFTP or SCP, or to your desktop.
- 3. From the sidebar of the console system's web UI, click System Tools, then click Upgrade Firmware.
- 4. Download the file from the server you selected in step 2.
  - a. Click the Remote Server radio button, then use the drop-down menu to select the protocol of the server where you saved the file.
  - b. Enter the IP address for the server where the firmware is saved in the appropriate field.
  - c. Enter the username and password for the server in the appropriate fields.
  - d. Enter the file directory where the firmware is saved and the filename for the firmware in the appropriate fields.

-or-

Download the file from your desktop by selecting My Computer.

- a. Click Choose File or Browse to open a window and browse to the file.
- 5. Click *Download*. The console system will download the firmware from the specified site and will display a message when the download is complete.
- 6. Click Install.
- 7. Once the new firmware is installed, reboot the console system.

### **Configuration files**

An administrator can create a backup image of the console system's configuration. During creation, no changes should be made to the configuration. The backup configuration file may be uploaded to a remote server, stored on a console system local file or saved to the web user's computer. Configuration files can be saved as a compressed file, CLI script or XML file.

#### To save the current configuration file:

- 1. From the sidebar of the Expert tab, click System Tools.
- 2. Click Save Configuration.
- 3. Use the drop-down menu to select the file format.
- 4. Upload the file to a remote server.
  - a. Click the Remote Server radio button, then use the drop-down menu to select the protocol of the server where you want to save the file.
  - b. Enter the IP address for the server where the file will be saved in the appropriate field.
  - c. Enter the username and password for the server in the appropriate fields.
  - d. Enter the file directory where the configuration file will be saved and the filename in the appropriate fields.

-or-

Save the file locally by clicking the Local File radio button, then enter the filename.

NOTE: The filename can include the full path to where the file will be saved. Specifying the full path permits the file to be saved to a USB storage device that is mounted, for example /media/sda1/filename. If the full path is not specified, the file is written to /mnt/hdUser/backup/<filename>.

-or-

Save the file to your computer by clicking the My Computer radio button. The file will be saved in your Downloads folder.

5. Click Save.

#### To restore a previous configuration:

- 1. From the sidebar of the Expert tab, click System Tools.
- 2. Click Restore Configuration.
- 3. Restore the file from a remote server.
  - a. Click the Remote Server radio button, then use the drop-down menu to select the protocol of the server where the configuration file is saved.
  - b. Enter the IP address of the server where the file is saved in the appropriate field.
  - c. Enter the username and password for the server in the appropriate fields.
  - d. Enter the path and filename for the configuration file.

-or-

Restore from a local file by clicking the Local radio button and entering the filename.

-or-

Restore the file from your computer by clicking the My Computer radio button, then click *Choose File* or *Browse* and browse to where the file is saved on your computer and click *Open*.

4. Click Restore.

### **Configuration integrity**

In order to ensure configuration integrity, the console system permits an administrator to generate and verify a digital signature (MD5) of the console system's configuration. The console system compares its MD5 checksum value against a known MD5 checksum value to verify its configuration and keep it protected from corruption.

An administrator can specify a running configuration as trusted and instruct the console system to generate an MD5 tag for the trusted configuration. An administrator can also verify the configuration by comparing it to another known or trusted configuration. The console system will declare the configuration to either be Unchanged or Modified after the verification is complete.

Configuration integrity works with and relies on the console system's saved and restored configuration files. It's also dependent on the zero-touch provisioning feature.

NOTE: In order to use configuration integrity, you must save the configuration using the compressed file option. The compressed file format captures more configuration data to ensure the accuracy of the configuration integrity results. Saving the configuration in either the CLI script or XML file formats will produce invalid configuration integrity results.

The console system generates an event notification each time an MD5 tag is generated. For more information about events, see Event list on page 69.

#### To generate an MD5 tag:

- 1. From the sidebar of the console system's web UI, click System Tools and then click Configuration Integrity.
- 2. Click the Generate MD5 Tag for the Running Configuration radio button and click *Execute*.
- 3. The generated MD5 tag displays on the screen as a 32-character hexadecimal value and is also saved on the console system as the value to compare against later. An administrator can cut and paste this string to use on other systems.

#### To verify an MD5 tag:

- 1. From the sidebar of the console system's web UI, click System Tools and then click Configuration Integrity.
- 2. Click the Verify Running Configuration radio button.
- 3. Leave the MD5 field blank to verify the running configuration.

-or-

Enter an MD5 checksum string to verify a known configuration.

4. Click Execute.

### **HTTPS certificate**

You can generate a new self-signed certificate, a certificate signing request (CSR), or download a signed certificate to the appliance from an FTP server or from your desktop.

#### To generate a new self-signed certificate:

- 1. From the sidebar of the Expert tab, click System Tools.
- 2. Click Generate / Download Certificate.
- To generate a new certificate, click the Generate Self-Signed Certificate radio button and enter the desired information in the self-signed certificate fields: Country, State or Province, City or Locality, Organization, Organization Unit, Common Name, Subject Alternative Names, Email Address, Netscape Comment and a Pass Phrase if desired.

-or-

To generate a certificate signing request, click the Generate Certificate Signing Request radio button and enter the desired information in the certificate signing request fields: Country, State or Province, City or Locality, Organization, Organization Unit, Common Name, Subject Alternative Names, Email Address, and Netscape Comment. Check the Generate new key checkbox to also generate a new private key for the ACS console system and enter a Pass Phrase if desired.

-or-

To download a signed certificate from an FTP, SFTP or SCP server, click the Remote Server radio button and enter all information about the server: IP Address, Username, Password, File Directory, File Name and Pass Phrase if required.

-or-

To download a certificate from your desktop, click the Download Certificate From My Computer radio button, click *Choose File* or *Browse* to browse to where the file is saved and click *Open*. A Pass Phrase may be provided if one is required.

- 4. Click Generate/Download. The certificate's information will be displayed.
- 5. Click Apply. The message shows Applying the new certificate will terminate all HTTP/HTTPS sessions. The restart of your browser is required. Are you sure you want to continue?
- 6. Click OK to continue. The certificate will be saved and the browser will restart to use the new certificate.

#### NOTE: All http/https sessions will close, and the user will need to re-establish the connection.

### **Export files**

An administrator can export files from the console system directly to their client computer.

#### To export a file:

- 1. From the sidebar of the Expert tab, click System Tools.
- 2. Click Export File.
- 3. Select the Export Type from the drop-down menu.
- 4. Click *Export*. The file will be saved in your Downloads folder.

The following Export Types are supported:

- DBGDump Log file containing information on the configuration and state of the appliance. Refer to the Diagnostics section on page 78.
- DBGMon Zip Zip file containing the state of the appliance at regular intervals. Refer to the Diagnostics section on page 78.
- DLog Log file containing error messages and events.
- Modem PPPD Log Log file containing the results of the modem pppd and chat processes.
- IPSec Log Log file of the IPSec process.

- Zero-touch Log Log file of the zero-touch provisioning process.
- Caller ID Log Log file of the most recent Caller ID history.
- Restore Config Log Log file of the last restore configuration from CLI format.
- Other A user-specified absolute path and filename that must reside underneath one of the following paths: /mnt/hdUser, /var/log, /tmp, /var/apache2/logs.

## 3.3.3 System

Click *System* to display information about the console system and allow an administrator to configure the console system's system parameters. The following tabs are listed under System in the side navigation bar.

### Security

#### Security profile

A Security Profile determines which services are enabled on the console system.

During initial configuration, the console system administrator must configure security parameters to conform with the site security policy. The following security features can be configured either in the web UI, CLI, RestAPI or the Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView software:

- Configure the session idle time-out
- Enable or disable RPC
- Enable or disable pluggable device detection, storage devices and 1-Wire support
- Ability to configure serial port access for all users, or allow the configuration of group and user-specific authorizations to restrict access
- Select a Security Profile, which defines:
  - Enabled services (FTP, TFTP, ICMP, IPSec, SNMP and Telnet)
  - SSH and HTTP/HTTPS access
  - Enable or disable Bootp Configuration retrieval, Bootp interface and enable or disable Live Configuration
     Retrieval

The administrator can select either a preconfigured Security Profile or create a custom profile.

All the services and the SSH and HTTP/HTTPS configuration options that are enabled and disabled for each Security Profile are shown in the Wizard - Security and the System - Security - Security Profile pages.

#### To configure a Security Profile:

- 1. Select System Security Security Profile.
- 2. In the Idle Timeout field, enter the number of seconds before the console system times out open but idle sessions.

NOTE: This value applies to any user session to the appliance via HTTP, HTTPS, SSH, Telnet or CONSOLE port. It will not overwrite the value configured for the user's authorization group. The new idle time-out will be applied to new sessions only.

- 3. Under the Enabled Services section, enable or disable the RPC checkbox.
- 4. Under the Pluggable Devices section, enable or disable pluggable device detection for USB and SD devices. If enabled, the USB storage and SD card can be disabled to restrict the type of pluggable devices for security reasons. The 1-wire support can also be disabled in this section.

NOTE: These options appear for all console system models, even though some models do not have SD card or 1-Wire sensor ports. If your model does not have these ports, leave these options disabled.

NOTE: Disabling Pluggable Device Detection or changing the Storage Device setting will only be effective after a reboot.

- 5. Under the Serial Devices heading, select whether port access is controlled by user and group authorization or whether port access settings to apply to all users.
- 6. Under Bootp Configuration retrieval, enable or disable the service.
- 7. Enable/disable SSH authentication via username/password.
- 8. Under the Security Profile heading, select the Custom, Moderate, Open or Secure radio button.

NOTE: The Custom security profile provides the HTTP Strict Transport Security setting, which can be enabled to instruct the client browser to always use https for connecting to the appliance.

9. Click Save.

#### **FIPS** module

The console system uses an embedded cryptographic module that is based on the FIPS 140-2 validated cryptographic module (certificate number 4282) running on a Linux ARM platform.

If an administrator enables the FIPS module, the console system will use the FIPS Object Module to perform encryption operations. The FIPS module is disabled by default.

When the FIPS module is enabled, the Monitoring - FIPS mode page will show what service (SSHv2, HTTPS, SNMPv3 and ADSAP2) is in FIPS mode. All security functions and cryptographic algorithms used by the service are performed in FIPS 140-2 Approved mode.

#### To enable the FIPS module:

- 1. Select System Security FIPS 140.
- 2. Check the box to Enable the FIPS 140-2 Module and click Save.

The console system will automatically reboot. During the reboot, the console system will erase SSH keys, update the configuration of HTTPD, SSHD, ADSAP2d and SNMPD files and test the integrity of the FIPS Object Module. Once the reboot is complete, the console system will accept SSH and HTTPS connections using only FIPS-approved ciphers.

When FIPS is enabled, the following restrictions apply:

For SSH sessions:

- AES 128/192/256 are the only encryption ciphers that will be accepted.
- HMAC-SHA2 256/512 are the only message integrity algorithms that will be accepted.
- RSA-SHA2 256/512 are the only host key algorithms that will be accepted.

HTTPS sessions will accept only the SSL v 3.1(TLSv1) protocol to establish the SSL tunnel with one of the following encryption ciphers:

- AES-256-SHA
- AES-128-SHA
- Triple DES SHA (DES-CBC3-SHA)

SNMP version 3 requests will be accepted when authentication is SHA and the encryption cipher is AES.

#### Vertiv<sup>™</sup> Avocent® DSView software security

You can also configure Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView software security settings. When the console system is managed by the Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView software, the Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView server will supply the certificate to the console system. Under normal conditions, the Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView software will manage the certificate to clear and replace it with a new certificate as needed. If communication with the software is lost, the Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView server will be unable to clear the certificate and the console system cannot be used. Click the *Clear DSView Certificate* button to configure the console system in Trust All mode.

#### To configure Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView software security settings:

- 1. Select System Security DSView.
- 2. Click the Allow appliance to be managed by DSView checkbox.
- 3. Select the radio button for the appropriate certificate size.
- 4. Click Save.

### Date and time

The console system provides two options for setting the date and time. It can retrieve the date and time from a Network Time Protocol (NTP) server, or you can set the date and time manually so that the console system's internal clock is used to provide time and date information.

# NOTE: The Current Time displayed in the Date & Time screen shows only the time when the screen was opened. It does not continue to update in real time.

#### To set the time and date using NTP:

- 1. Click System Date and Time.
- 2. Select the Enable network time protocol radio button.
- 3. Enter one or two NTP server sites of your choice. The NTP client will attempt to poll both if necessary.
- 4. If your NTP server requires authentication, then check Enable authentication and enter the following information that agrees with the settings on the NTP server:
  - Key ID: A number 1-65535.
  - Key Type: MD5 or SHA1.
  - Key: Up to a 40-character string.
- 5. Click Save.

#### To set the time and date manually:

- 1. Click System Date and Time.
- 2. Select the Set manually radio button.
- 3. Using the drop-down menus, select the required date and time and click Save.

#### To set the time zone using a predefined time zone:

- 1. Click System Date and Time Time Zone.
- 2. Select the Predefined radio button.
- 3. Select the required time zone from the drop-down menu and click Save.

#### To define custom time zone settings:

- 1. Click System- Date and Time Time Zone.
- 2. Select the Define Time Zone radio button.

- 3. Enter the Time Zone Name and Standard Time Acronym of your choice.
- 4. Enter the GMT Offset.
- 5. If needed, check the Enable Daylight Savings Time box and select or enter the required values.
- 6. Click Save.

### Help and language

Click System - Help and Language and use the drop-down menu to select the console system's language.

# NOTE: Language applies to SSH, Telnet and Console Port sessions to the console system. Browser language is determined by the browser.

#### **Online help**

When the online help feature is configured for your console system, clicking the *Help* button from any form on the web UI opens a new window and redirects its content to the configured path for the online help product documentation.

Enter the full URL of the online help, ending in /index.html, on the local web server in the Online Help URL field. Click Save.

NOTE: Using the online help feature from the Vertiv server is not always possible due to firewall configurations, nor is it recommended. It is generally advisable for you to use the online help system provided with the product or download the online help .zip file and run it from a local server.

The system administrator can download the online help from Vertiv<sup>™</sup>. For more information on downloading the online help, contact Technical Support.

Once the online help file is obtained (in zip format), the files must be extracted and put into a user-selected directory under the web server's root directory. The web server must be publicly accessible.

### General

Click System - General to create a login banner or select the viewer type.

#### Login banner

An administrator can configure a login banner to display when a user begins a SSHv2, Telnet, Console or web UI session.

#### To create a login banner:

- 1. Click System General in the side navigation bar.
- 2. Check the Enable Login Banner box.
- 3. In the Login Banner field, enter the text you want displayed upon login.
- 4. To force the user to acknowledge the banner before login, check the Enable Login Banner Acknowledgement box.
- 5. Click Save.

#### **Serial viewer**

By default, the console system uses a basic HTML5 serial viewer. It also supports a more robust Java-based serial viewer. An administrator can configure which serial viewer is used for the serial ports and console system.

#### NOTE: The HTML5 serial viewer supports a maximum of 10 sessions per port with a limit of 48 total sessions.

#### To configure the serial viewer:

- 1. Click System General in the side navigation bar.
- 2. Select either HTML5 Viewer or JNLP Viewer, then click Save.

#### Java-based serial viewer

NOTE: Java 1.8.0.91 or later is recommended. You must have the 32-bit version installed in order to run the serial viewer.

The following table describes the available buttons in the Java applet.

#### Table 3.2 Java Applet Buttons for Connecting to the Console System

Button	Purpose
SendBreak	To send a break to the terminal
Disconnect	To disconnect from the Java applet

NOTE: Using the serial or appliance viewers may require disabling the client browser's popup blocker.

NOTE: When the viewer is run, the browser may ask for permission to run the Mindterm application. Granting this permission is required for the viewer applet to run.

### **Boot configuration**

Boot Configuration defines the location from which the console system loads the operating system. The console system can boot from its internal firmware or from the network. By default, the console system boots from internal firmware in Flash memory. Clicking *System-Boot Configuration* displays the Boot Configuration screen.

If you need to boot from the network, make sure the following prerequisites are met:

- A TFTP server must be available on the network
- A firmware file must be downloaded from Vertiv and made available on the TFTP server
- The boot filename and the IP address of the TFTP server is known

#### To configure boot configuration:

- 1. Click System Boot Configuration.
- 2. Under Boot Mode, select From Flash, and select Image 1 or Image 2.

-or-

Select From Network and enter the following information:

- Appliance IP Address: Enter the fixed IP address or a DHCP assigned IP address to the console system.
- TFTP Server IP: Enter the IP address of the TFTP boot server.
- Filename: Enter the filename of the boot firmware.
- 3. Using the drop-down menu, select whether the Watchdog Timer is enabled. If the Watchdog Timer is enabled, the console system reboots if the software crashes.
- 4. Using the drop-down menu, select the console port speed and click Save.

### Information

Click System - Information to view the console system's identity, versions, power and CPU information.

### Usage

Click System - Usage to view memory and Flash usage.

## 3.3.4 Network

Click *Network* to view and configure the Hostname, DNS, IPv6, Bonding, IPv4 and IPv6 static routes, Hosts, Firewall, IPSec (VPN), SNMP, DHCP Server and Certificate Management network options.

### Settings

Click Network - Settings to make changes to the configured network settings.

From this page, an administrator can configure the console system's hostname and DNS settings, which includes the primary and secondary DNS, domain and search addresses. An administrator can also enable IPv6 and configure it to get the DNS and/or domain from DHCPv6.

Link Layer Discovery Protocol (LLDP) can be enabled by selecting the checkbox.

For a fault tolerant network configuration, the Bonding option may be selected to combine eth0 and eth1 into a single highavailability network interface using the active-backup bonding mode. Interface eth0 is the normal active interface with eth1 as the backup; if the carrier signal is lost on eth0, eth1 becomes the active interface. The eth0 MAC address is always used in bonding mode, no matter which interface is active.

NOTE: After enabling or disabling bonding, you must reboot the console system for the change to take effect.

#### **Routing type**

The console system supports multiple routing tables for flexible policy routing. Multiple routing tables can not be enabled at the same time network failover or bonding is enabled.

#### To enable multiple routing tables:

- 1. Click Network Settings.
- 2 Under Multiple Routing, click the Enable IPv4 Multiple Routing Tables radio button.
- 3. In addition to eth0 and eth1, select whether any interfaces should be added to the tables by choosing the desired interface from the Additional Interface drop-down menu.
- 4. Click Save.

### **Network failover**

To ensure a console system can be relied upon to provide access to critical devices during a network outage, it should be configured for network failover. Failover can occur when a primary interface goes down or when a certain IP/gateway becomes inaccessible. Failover can be enabled using a secondary network or PPP (dialout) connection. If dialout is configured, pppO or LTE will be available as a secondary interface but cannot be used as the primary interface.

Using the Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView software with a console system will ensure the console system can always be accessible when in a failover situation, because the console system will "phone home" and update its IP address within the Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView software.

From the Network-Settings page, an administrator can configure a secondary network interface to be used for failover. The primary interface sets the system default gateway while the secondary interface is used when the primary interface is not available. An administrator can also select one of four triggers that enable the failover:

- Primary Interface Down
- Unreachable Primary Default Gateway
- Unreachable DSView
- Unreachable IP Address

If the IPSec tunnel has been configured (see IPSec(VPN) on page 30), an administrator can configure the IPSec tunnel to be established over the secondary interface when it is up.

#### To enable Network Failover:

- 1. From the sidebar of the Expert tab, click *Network-Settings*.
- 2. Under the Routing heading, click the Enable Network Failover radio button.
- 3. Use the drop-down menus to select the primary and secondary interfaces as well as the VPN connection name.
- 4. Click the radio button next to the trigger you want to use to initiate the failover.
- 5. Click Save.

You can also configure failover using the cellular modem, for models that come with one. For more information, see Using the cellular modem in failover on page 56.

#### NOTE: Cellular can be used for failover if it is not already being used as the primary interface.

### **Devices**

An administrator can select, enable and configure the IP addresses assigned to the network interfaces and view the MAC address. Besides the two standard Ethernet interfaces, the list of network interfaces includes an entry for any USB Ethernet device that may be installed.

#### To configure a network device:

- 1. Select *Network Devices*. The Devices screen appears with a list of network interfaces and their status (enabled or disabled).
- 2. Click the name of the network device to configure.
- 3. Check the box if you want to set the network device as the primary interface. By default, ethO is set as the primary interface.
- 4. Select the status (either Enabled or Disabled) from the drop-down menu.
- 5. Select one of the following IPv4 method options:
  - Select DHCP to have the IPv4 IP address set by the DHCP server.
  - Select Static to enter the IPv4 IP address, subnet mask and gateway address manually.
  - Select IPv4 address unconfigured to disable IPv4.
- 6. Select one of the following IPv6 method options:
  - Select Stateless if the link is restricted to the local IP address.
  - Select DHCPv6 to have the IPv6 IP address set by the DHCP server.
  - Select Static to enter the IPv6 IP address and prefix length manually.
  - Select IPv6 address unconfigured to disable IPv6.
- 7. Use the drop-down to change the mode if necessary. The default is *Auto*, but if the network cannot handle auto negotiation, then there is a No Negotiate option.
- 8. Adjust the MTU value if necessary.

#### NOTE: The MAC Address for the device will be displayed after this option.

### IPv4 and IPv6 static routes

#### To add static routes:

- 1. Select *Network IPv4 Static Routes* or *IPv6 Static Routes*. Any existing static routes are listed with their Destination IP/Mask, Gateway, Interface and Metric values shown.
- 2. Click Add.
- 3. Select *Default* to configure the default route.

-or-

Select Host IP Or Network to enter custom settings for Destination IP/Mask.

Enter the required Destination IP/Mask Bits with the syntax <destination IP>/<CIDR> in the Destination IP/Mask Bits field.

- 4. Enter the IP address of the gateway in the Gateway field.
- 5. Enter the interface name (eth0, eth1 or ppp0) in the Interface field when the route is by interface.
- 6. Enter the number of hops to the destination in the Metric field, then click Save.

### Hosts

An administrator can configure a table of host names, IP addresses and host aliases for the local network.

#### To add a host:

- 1. Select Network Hosts.
- 2. Click Add to add a new host.
- 3. Enter the IP address, hostname and alias of the host you want to add, then click Save.

#### To edit a host:

- 1. Select Network Hosts.
- 2. Click on the IP address of the hostname you want to edit.
- 3. Enter a new hostname and alias, if applicable, then click Save.

### Firewall

Administrators can configure the console system to act as a firewall. By default, three built-in chains accept all INPUT, FORWARD and OUTPUT packets. Select *Add*, *Delete* or *Change Policy* to add a user chain, delete user-added chains and to change the built-in chains policy. Default chains can have their policy changed (Change Policy) to accept or drop but cannot be deleted. Clicking on the chain name allows you to configure rules for chains.

Firewall configuration is available by clicking on *Network - Firewall*. Separate but identical configuration screens are available from either the IPv4 Filter Table or IPv6 Filter Table menu options.

Only the policy can be edited for a default chain; default chain policy options are ACCEPT and DROP.

When a chain is added, only a named entry for the chain is created. One or more rules must be configured for a chain after it is added.

#### Configuring the firewall

For each rule, an action (either ACCEPT, DROP, LOG, REJECT or RETURN) must be selected from the Target pull-down menu. The selected action is performed on an IP packet that matches all the criteria specified in the rule.

If LOG is selected from the Target pull-down menu, the administrator can configure a Log Level and a Log Prefix.

If *REJECT* is selected from the Target pull-down menu, the administrator can select an option from the Reject with pulldown menu; the packet is dropped and a reply packet of the selected type is sent.

### **Protocol options**

Different fields are activated for each option in the Protocol pull-down menu.

If Numeric is selected from the Protocol menu, enter a Protocol Number in the text field.

If *TCP* is selected from the Protocol menu, a TCP Options Section is activated for entering source and destination ports and TCP flags.

If UDP is selected from the Protocol menu, the UDP section is activated for entering source and destination ports.

Table 3.3 Firewall Configuration - TCP and UDP Options Fields

Field/Menu Option	Definition
Source Port - or - Destination Port	A single IP address or a range of IP addresses.
TCP Flags	[TCP only] SYN (synchronize), ACK (acknowledge), FIN (finish), RST (reset), URG (urgent) and PSH (push). The conditions in the pull-down menu for each flag are: Any, Set or Unset.

If ICMP is selected from the Protocol menu, the ICMP Type pull-down menu is activated.

If an administrator enters the Ethernet interface (eth0 or eth1) in the input or output interface fields and selects an option (2nd and further packets, All packets and fragments or Unfragmented packets and 1st packets) from the Fragments pulldown menu, the target action is performed on packets from or to the specified interface if they meet the criteria in the selected Fragments menu option.

#### To add a chain:

- 1. Select Network Firewall.
- 2. Select either IPv4 Filter Table or IPv6 Filter Table as needed.
- 3. Click Add.
- 4. Enter the name of the chain to be added.
- 5. Click Save.

#### NOTE: Spaces are not allowed in the chain name.

6. Add one or more rules to complete the chain configuration.

#### To change the policy for a default chain:

#### NOTE: User-defined chains cannot be edited. To rename a user-added chain, delete it and create a new one.

- 1. Select Network Firewall.
- 2. Select either IPv4 Filter Table or IPv6 Filter Table as needed.
- 3. Select the checkbox next to the name of the chain you want to change (FORWARD, INPUT, OUTPUT).
- 4. Click Change Policy and select Accept or Drop from the drop-down menu.
- 5. Click Save.

#### To add a rule:

- 1. Select Network Firewall.
- 2. Select either IPv4 Filter Table or IPv6 Filter Table as needed.
- 3. From the chain list, click the name of the chain you want to add a rule to.
- 4. Click Add and configure the rule as needed, then click Save.

#### To edit a rule:

- 1. Select Network Firewall.
- 2. Select either IPv4 Filter Table or IPv6 Filter Table as needed.
- 3. From the chain list, click the name of the chain with the rule you want to edit.
- 4. Select the rule you want to edit and click Edit.
- 5. Modify the rule as needed and click Save.

## 3.3.5 IPSec(VPN)

A Virtual Private Network (VPN) enables secure communication between the console system and a remote network by utilizing a gateway and creating a secure connection between the console system and the gateway. The IPSec protocol is used to construct the secure tunnel and provides encryption and authentication services at the IP level of the protocol stack.

The console system uses the Linux strongSwan IPSec solution.

NOTE: When using Certificates for authentication, the console system supports one certificate per tunnel. Multiple certificates are not supported. Certificates (in PKCS12 format) can be loaded from the System Tools menu.

#### NOTE: IPv6 tunnels are not supported.

#### To enable IPSec on the console system:

- 1. From the sidebar of the Expert tab, click System Security Security Profile.
- 2. Under Security Profile, click the Custom radio button.
- 3. Check the Enable IPSec box, then click Save.

#### To create a tunnel on the console system:

- 1. From the sidebar of the Expert tab, click Network IPSec(VPN), then click Add.
- 2. Enter a name for the connection.
- 3. Select the IKE version from the drop-down menu.
- 4. For the Boot Action, select either Start, Add, Ignore or Route.
- 5. Configure the parameters for the Remote ("Right") Side and Local ("Left") Side of the tunnel. These parameters are described in Table 3.4.
- 6. The Show Advanced Settings checkbox may be used to configure IPSec Advanced Settings. The advanced settings are described in Table 3.5. Most users will not need to modify these settings.
- Click Save. The IPSec configuration saves, and IPSec restarts. The VPN connection appears in the list on the Network – IPSec(VPN) page. If the Boot Action is set to Start, then the VPN connection will start immediately. If the Boot Action is set to Add, then the VPN connection may be started by clicking on the connection name and clicking on the *Connect* button.

Item	Description
Connection Name	An arbitrary name that is only relevant on the console system to refer to the specific VPN connection. This name does not have to match any setting at the remote side.
IKE Version	IKEv2/IKEv1: Defines the Internet Key Exchange protocol which will be used to establish the VPN connection. Must be the same on the local and remote side. IKEv2 is the newer, more secure option.
Boot Action	Add: The VPN connection will be loaded, but the IPSec tunnel will not be automatically started. Select <i>Add</i> setting if the VPN is used only for failover. Start: The VPN connection will be loaded and the IPSec tunnel will be established immediately when IPSec starts (when the console system boots up, or after saving the IPSec configuration). Select <i>Start</i> setting if the VPN should stay up all the time. Ignore: Select <i>Ignore</i> if the connection will not be used. Route: The VPN connection will be loaded, but the IPSec tunnel will not be started until traffic is detected. Select <i>Route</i> to activate this setting.
Aggressive	Yes/No: This option is only used if the IKE Version is set to IKEv1. Select Yes to establish IKE Phase 1 using aggressive mode. Select No to establish IKE Phase 1 using main mode, which is more secure.
DPD Action	None/Restart. Dead Peer Detection (DPD)Action determines if the console system will attempt to restart the tunnel if the remote peer is declared dead.
Remote ("Right") Side – th	is is the remote side of the VPN tunnel, to which the console system is connecting.
Remote Side ID	Identifies the remote side for authentication. Leave blank to identify the remote side by IP address.
Remote Side IP Address	The public-network IP address of the remote side, such as a gateway device.
Remote Side Subnet	The private subnet being accessed behind agateway on the remote side.
Local ("Left") Side – this is	s the local side of the VPN tunnel. This is the console system side.
Local Side ID	Identifies the console system for authentication. Leave blank to use the IP address to identify the console system.
Local side Virtual IP	The internal source IP address used to address the console system in the tunnel. If this is configured with an IP address, then that address will be requested from the peer, which may respond with a different address. If this is set to %config, then an IP address will be requested from the peer.
Local Side IP Address	The address of the local interface that the console system will use for the VPN connection. Enter <b>%any</b> for any interface to be used. The %any setting is recommended if the cellular modem is being used for the VPN, since the IP address will be assigned by the cellular provider.
Local Side Subnet	This is the private subnet behind the console system. If this is left blank, then only the console system itself is accessible over the tunnel.
IPsec(VPN) Authentication	RSA Certificate: Choose a certificate to be used for authentication of the IPsec tunnel. To load a certificate, go to the System Tools page and click <i>IPSec(PKCS12) Files</i> . The loaded files may be viewed on the Network - IPSec(PKCS12) page. If the Enable Fallback checkbox is checked, then if the VPN connection with a new certificate fails, the VPN connection will be attempted with the previously configured certificate.
	PSK and XAuth: Enter the pre-shared secret which is also configured at the remote side, and the username and password.
	Pre-Shared Secret: Enter the pre-shared secret which is also configured at the remote side.

#### Table 3.4 IPSec(VPN) Configuration Settings

### IPSec(VPN) advanced settings

The IPSec(VPN) configuration page includes the advanced settings for the ipsec.conf file. These settings, described in the following table, are displayed when the Show Advanced Settings checkbox is enabled. Most users will not need to modify these settings.

#### Table 3.5 IPSec(VPN) Advanced Settings

Name	Description
IKE (Internet Key Exchange) Cipher Suite	Protocols used to exchange cryptographic keys. The suite includes algorithms for Encryption (confidentiality), Hash (message authentication) and DH group (key exchange) protocols when setting up the VPN.
ESP (Encapsulating Security Payload) Cipher Suite	Protocols used to exchange cryptographic keys. The suite includes algorithms for Encryption (confidentiality), Hash (message authentication) and DH group (key exchange) protocols when setting up the VPN. If DH group is used, the higher group numbers are more secure, but take a longer time to compute the key.
Reauthentication	Specifies whether the device should reauthenticate when an IKE Security Association (SA) changes. (An SA describes how two or more devices will communicate securely.)
IKE Lifetime	Specifies how long the keying channel of a connection (ISAKMP or IKE SA) should last before being renegotiated.
Key Lifetime	Specifies how long a particular instance of a connection (a set of encryption/authentication keys for user packets) should last, from successful negotiation to expiry.
Rekey	Specifies whether a connection should be renegotiated when it is about to expire.
Keying Tries	Specifies how many attempts (a positive integer or %forever) should be made to negotiate a connection, or a replacement for one, before giving up. The default is 3.
Rekey Margin	Specifies how long before connection expiry or keying-channel expiry, should attempts to negotiate a replacement begin.
DPD Delay	Specifies the period time interval with which R_U_THERE messages/INFORMATIONAL exchanges are sent to the peer.

### Verification

#### To verify the IPSec status and test communication from the Network page:

- 1. Go to Network IPSec(VPN) and click on a VPN connection name.
- 2. Check the Show Diagnostics box to view detailed information about the connection, including the Local Virtual IP Address, which will be used to address the console system in the tunnel. If the Connect/Disconnect buttons are used, then the result of the command will be displayed in the Last Result field. The Ping button may be used to ping a target device on the remote side of the tunnel.

-or-

#### To verify the IPSec status and test communication from the console system Shell prompt:

- 1. Log into the console system as **root**.
- 2. At the shell prompt, enter the command ipsec status or ipsec statusall.
- 3. To ping a target device on the remote side of the tunnel, enter the command **ping**.
- 4. To connect and disconnect the tunnel, enter the commands **ipsec up <connectionname>** and **ipsec down <connectionname>**, specifying the name of the VPN connection.

### **IPSec logging**

For further diagnostic information, IPSec logging may be enabled. Refer to the Diagnostics section on page 78.

## 3.3.6 SNMP configuration

An administrator can configure SNMP, which is needed if notifications are to be sent to an SNMP management application.

NOTE: The Avocent ACS800/8000 advanced console system Enterprise MIB text file is available in the appliance at: /usr/local/mibs/ACS8000-MIB.asn. The Avocent ACS800/8000 advanced console system Enterprise TRAP MIB text file is available in the appliance at: /usr/local/mibs/ACS8000-TRAP-MIB.asn. Both files are also available at www.Vertiv.com.

#### To configure SNMP:

- 1. Click Network SNMP.
- 2. Click the System button.
  - a. Enter the SysContact information (email address of the console system's administrator, for example, acs8000\_admin@vertiv.com).
  - b. Enter the SysLocation information (physical location of the console system, for example, Avocent\_ ACS8000), then click Save to go back to the SNMP screen.
- 3. Click Add to add a new community or v3 user.
- 4. Enter the community name for SNMP v1/v2 or the user name for SNMP v3 in the Name field and enter the OID.
- 5. Select the desired permission from the pull-down menu. Choices are Read and Write or Read Only.
- 6. If the required SNMP version is v1 or v2, click the *Version v1, v2* button, then enter the source (valid entry is the subnet address).

-or-

If the required SNMP version is v1 or v2 using an IPv6 network, click the *Version v1,v2 for IPv6 network* button, then enter the source (valid entry is the subnet address).

-or-

If the required SNMP version is v3, click the *Version v3* button, then select the Authentication Type (*MD5* or *SHA*), enter the authentication passphrase or password, select the Encryption Method (*DES* or *AES*), enter the privacy passphrase and select the Minimum Security Level (*NoAuthNoPriv*, *AuthNoPriv*, *AuthPriv*).

7. Click Save.

NOTE: For SNMP v1/v2c, the console system will allow an administrator to configure the same community name with different sources (filters) to have access to specific object identifiers (OIDs).

### **DHCP** server

The console system can act as a DHCP server for devices connected to one of the ethernet interfaces. This can be for a single device connected directly to the ethernet port or for a network of devices attached to a network switch that is attached to the console system's ethernet port.

#### To configure the DHCP Server:

- 1. Click Network DHCP Server Settings.
- 2. Use the drop-down to select the desired Interface Device.
- 3. Check the Enable DHCP Server box.
- 4. Enter the desired subnet address. This is the address/mask which will be used for address assignments.

NOTE: The Interface Device chosen above must be assigned a static address in this same subnet via the Network – Devices settings.

- 5. Enter a default lease time in hours. This is the time which will be assigned to a lease if the client does not ask for a specific expiration time.
- 6. Enter a max lease time in hours.
- 7. Enter the start and end IP addresses. This sets the range of IP addresses used for dynamic IP address assignment (the address pool). Any reserved address assignments must be outside of this range.
- 8. Enter a vendor class identifier, if desired. If a vendor class identifier is specified, then only devices which report this identifier will be assigned an address by the DHCP server.
- 9. If using the DHCP server with Zero-touch Provisioning, enter the server name and file name.

Once configured, the DHCP server will listen on the specified network interface for DHCP requests and will automatically assign IP address to client devices. The DHCP server may also be used to distribute data to devices for Zero-touch Provisioning.

#### To view or add assigned addresses:

- 1. Click Network DHCP Server Assigned Addresses.
- 2. The table shows a list of assigned IP Addresses with the associated MAC Address, Host Name.
- 3. Select one or more checkboxes of addresses identified as "Reserved" and click the *Unreserve* button to remove the reserved address.
- 4. Click Add to add a new reserved address.
- 5. On the Add Reserved Address page, enter the Host Name and MAC Address of the client device along with an IP Address from outside the range of the address pool defined in the DHCP server configuration.
- 6. If using Zero-touch Provisioning, optional server and file names can be entered.

### **Certificate management**

The console system contains an Automatic Certificate Management Environment (ACME) client that can automatically request and renew digital certificates.

#### To configure the ACME client:

- 1. From the sidebar of the Expert tab, click Network Certificate Management.
- 2. Select the ACMEv2 radio button.
- 3. Enter the Domain Name being requested for the certificate. The Certificate Authority validates that the requester is in control of this domain name.
- 4. Enter the ACME Directory URL to use for client connections.
- 5. Enter a valid Email Address for the ACME server to use to alert the user when an issued certificate is due for renewal.
- 6. Select the desired Challenge Type from the drop-down menu. This is the domain validation method that the ACME server should use to verify that the client is in control of the previously entered domain name. The ACME client supports *http-01*, *tls-alpn-01* and *dns-01*.
- 7. Click Save.

The Network – Certificate Management – Status page shows status information for the ACME client including whether the certificate is valid and when it will be scheduled for renewal.

The Status Output window displays the current state of the ACME client and the downloaded certificate.

The Log File window shows the messages passed between the ACME client and server during the most recent certificate renewal process. The certificate itself can be viewed on the *Network - IPSec(PKCS12)* page.

## NOTE: The ACME client checks once per hour if the certificate is due for renewal. The certificate renewal process is initiated when the certificate's remaining lifespan reaches 33%.

### 3.3.7 Ports

An administrator can enable and configure serial ports, internal modem, the CAS Profile and the Dial-In Profile from the Ports tab in the side navigation bar.

The console system's serial ports may work in several different roles, depending on the profile configured for a port.

### Serial ports

On the Serial Ports table, you can specify the connection profile (CAS, Dial-In, Dial-Out, Power or Socket Client) based on the type of connected device and you can clone the port, reset to factory defaults, enable/disable ports or open a serial session.

The table displays the port number, device ID, status, name, profile, action, target, signals and settings. The Settings column contains the pin-out being used for the port with the following abbreviations:

CYC - Cyclades CIS - Cisco 422 - RS422 485 - RS485

#### NOTE: The pin-out may not display if no device is connected to the port.

The following tables show the available RJ-45 Pin-Out definitions:

#### Table 3.6 Cyclades Serial Port Pin-Out

Pin No.	Signal Name	Input/Output
1	RTS	OUT
2	DTR	OUT
3	TxD	OUT
4	GND	N/A
5	CTS	IN
6	RxD	IN
7	DCD/DSR	IN
8	Not Used	N/A

### Table 3.7 Cisco Serial Port Pin-Out

Pin No.	Signal Name	Input/Output
1	CTS	IN
2	DCD/DSR	IN
3	RxD	IN
4	GND	N/A
5	Not Used	N/A
6	TxD	OUT
7	DTR	OUT
8	RTS	OUT

### To enable or disable one or more serial ports:

- 1. Select Ports Serial Ports.
- 2. Click the checkbox for each port you want to enable or disable.
- 3. Click Enable or Disable.

#### To configure or edit one or more serial ports with the CAS profile:

- 1. Select Ports Serial Ports.
- 2. Click the checkbox for each port you want to configure.
- 3. Click Set CAS. Use the drop-down menus to enable or disable the port and set the RJ-45 pin-out, speed, parity, data bits, stop bits and flow control.

## NOTE: Selecting AUTO for the RJ-45 pin-out enables automatic detection for either Cyclades or Cisco pin-outs for RS- 232 devices.

- 4. Click Next or click the CAS link.
  - a. Enter the port name (when only one port was selected) or the port name prefix (when multiple ports were selected). The port name will be <port name prefix>-p-<port number>.
  - b. Check the box to enable auto discovery. In this case, the port name will be used when auto discovery fails to discover the server name.
  - c. Check the box to enable speed auto detection.

## NOTE: Auto speed detection requires additional configuration in the CAS Profile-Auto Discovery Settings screen.

- d. Use the appropriate drop-down menus to set the protocol and authentication type.
- e. Enter the text session, power session and RESTful hotkeys in the appropriate fields.
- f. Enter the TCP port alias for each protocol type (Telnet, SSH and Raw Mode) in the appropriate field.
- g. Enter the IPv4 or IPv6 alias and its interface in the appropriate field.
- h. To allow a session only if DCD is on and to enable auto answer, check the appropriate boxes.
- i. Use the drop-down menu to select the DTR mode and enter the DTR off interval.
- j. Use the drop-down menus to enable or disable line feed suppression and NULL after CR suppression.
- k. Enter the transmission interval, break sequence and break interval in the appropriate fields.

## NOTE: The transmission interval defines the delay (in milliseconds) before the transmission of data to the Ethernet is received through a serial port. The default is 20ms.

- I. Use the drop-down menu to enable or disable the Multi-Session Menu. For more information, see Multi-Session Menu on page 42.
- m. Use the drop-down menus to enable or disable log in/out multisession notification and informational message notification.
- 5. Click *Next* or click the *Data Buffering* link and use the drop-down menus to enable and configure data buffering.
- 6. Click Next or click the Alerts link.
  - a. Click Enable Alerts to enable detection of alerts.
  - b. Click Add to add an alert string. In the Alerts String field, enter the string. In the Script field, enter the shell script that will run when the match happens. Check the Emergency box to cause the serial port LED to quickly blink amber whenever this alert occurs. A non-emergency alert slowly blinks. Click Next to return to the Alerts screen.

NOTE: The console system allows an administrator to associate one shell script to the alert string. When there is a match with the alert string, the console system will call the script passing the port number and the line where the match occurs as arguments.

- c. Check the box next to an existing alert and click Delete to delete the string.
- d. Click Delete Any to delete all strings whether selected or not.

## NOTE: Clicking *Delete Any* will delete all alert strings. Selecting all the alert strings and clicking *Delete* is not the same function as it will not delete alert strings not shown in the table.

- 7. Click Next or click the Power link.
  - a. Click *Add* to add a new outlet. Click *Selected PDU* and select a PDU from the list of detected PDUs. Enter the outlet(s) in the Outlets field and click *Next*.
  - b. Check the box next to an existing merged outlet and click Delete to delete it.

### NOTE: Power is only available when a single serial port is selected.

8. Click Save.

### Table 3.8 CAS Profile Parameters

Parameter	Description
Physical	
Status	Defines the status of the serial port as either enabled or disabled. Default: Disabled.
RJ-45 Pin-Out	Defines the serial port pin-out as Auto, Cyclades or Cisco. Ports 1 and 2 also support RS-422 and RS-485 pin-outs. Default: Auto.
Speed	Defines the speed as 300, 600, 1200, 1800, 2400, 4800, 9600, 19200, 38400, 57600, 115200 or 230400. Default: 9600.
Parity	Defines the parity as either Even, Odd or None. Default: None.
Data Bits	Defines the data bits as either 5, 6, 7 or 8. Default: 8.
Stop Bits	Defines the stop bits as either 1 or 2. Default: 1.
Flow Control	Defines the flow control as none, hardware, software, RxON software or TxON software. Default: None.
CAS	
Port Name	Name associated with the serial port (as an alias). Default: <appliance address="" mac="">-p-<port number="">.</port></appliance>
Enable Auto Discovery	The target name will be discovered and will be associated with this serial port. If it fails, the Port Name will be used. Default: Disabled.
Enable Speed Auto Detection	Tries to discover the speed of the serial port. This feature requires additional configuration under the CAS Profile / Auto Discovery / Settings page. Default: Disabled.
Protocol	The protocol that will be used by authorized users to access the serial port/target. The console system accepts three protocols for connection to the target: Telnet for telnet connection, SSH for secure connection and Raw Mode for raw socket connection. An administrator can configure the port to accept one, two or all three types. NOTE: Raw protocol requires the configuration of the Raw Mode Port Alias. Default value: SSH.
Authentication Type	Authentication type that will be used to authenticate the user during target session. Default: Local.
Text Session Hot Key	Hotkey to suspend the target session and go to the CLI prompt. Not available for Raw. Default: Ctrl-Z. Note: The default escape character for ts_menu is Ctrl-X.
Power Session Hot Key	Hotkey to suspend the target session and display Power Management Menu to control the outlets merged to the target. Not available for Raw. Default: Ctrl-P. Note: The default escape character for ts_menu is Ctrl-X.
RESTful Hot Key	Hotkey to suspend the target session and display the RESTful menu, which is used to perform user-defined RESTful actions. Default: not configured (blank).
TCP Port Alias	Telnet Port Alias: TCP port to connect directly to a serial port using Telnet protocol for the connection. SSH Port Alias: TCP port to connect directly to a serial port using SSH protocol for the connection. Raw Mode Port Alias: TCP port to connect directly to a serial port using raw socket for the connection.
Port IPv4/IPv6 Alias	IPv4/IPv6 address used to connect directly to a serial port. Default: not configured (blank).
Port IPv4/IPv6 Alias Interface	Interface (ETH0/ETH1) associated with the IPv4/IPv6 alias. Default: ETH0.
Allow Session Only if DCD is On	When the DCD is OFF, the appliance will deny access for this serial port. Default: Disabled (allow access if DCD is OFF).
Enable Auto Answer	When the input data matches one input string configured in Auto Answer, the output string will be transmitted to the serial port. Default: Disabled.
DTR Mode	DTR Mode can be set to the following: Always On. Normal - the DTR status will depend on the existence of a CAS session. Off Interval - when the CAS session is closed, the DTR will stay down during this interval. Default: Normal.
DTR Off Interval	Interval in seconds used by DTR Mode Off Interval in milliseconds. Default: 100.
Line Feed Suppression	Enables the suppression of the LF character after the CR character. Default: Disabled.

Parameter	Description
Null After CR Suppression	Enables the suppression of the NULL character after the CR character. Default: Disabled.
Transmission Interval	The interval the port waits to send data to a remote client in milliseconds. Default: 20.
Break Sequence	An administrator can configure the control key as the break sequence, entering ^ before the letter. Not available for Raw. Default: ~break.
Break Interval	Interval for the break signal in milliseconds. Not available for Raw. Default: 500.
Show Multi- Session Menu	Enables the multi-session menu when connecting to a port that is already being accessed by another user. Default: Disabled.
Log In/Out Multi- Session Notification	Enables the notification to multi-session users when a new user logs in or a user logs out. Not available for Raw. Default: Disabled.
Informational Message Notification	Displays an information message when a target session is opened. Not available for Raw. Default: Enabled.
Data Buffering	
Status	Enables or disables data buffering. Default: Disabled.
Туре	Displays the type of data buffering: Local - stores the data buffering file in the local file system. NFS - stores the data buffering file in the NFS server. Syslog - sends the data to the syslog server. DSView - sends the data to the Vertiv <sup>™</sup> Avocent <sup>®</sup> DSView software. Default: Local.
Local Type	When the type is set to local, specifies where on the local system the data buffering files are stored. Options are the built-in memory (mmcblk0) or connected USB storage and SD card storage locations. Default: mmcblk0.
Time Stamp	When enabled, adds the time stamp to the data buffering line for a Local or NFS database. Default: Disabled.
Log-in/out Message	Includes special notification for logins and logouts in data buffering. Default: Disabled.
Serial Session Logging	Enabled - stores data at all times. Disabled - stores data when a CAS session is not opened. Default: Enabled.
Alerts	
Status	A special event notification will be generated when input data matches one of the alert strings. Default: Disabled. Click the Enable Alerts button to enable.
Alert Strings	Strings used to generate event notifications. Default: Empty.
Scripts	Name of shell script that will be called when there is match of the alert string in the line. The script will be called with two arguments: the port number and the line where the match happened.
Emergency	Marking an alert as an Emergency causes the serial port's LED to quickly blink amber when this alert occurs rather than slowly blinking for a non-emergency.

### Table 3.8 CAS Profile Parameters (continued)

### To configure the Dial-in Profile for a serial port with a connected modem:

- 1. Select Ports Serial Ports.
- 2. Click the checkbox for a serial port with a connected modem.
- 3. Click the Set Dial-In button and use the drop-down menus to configure the dial-in settings.
- 4. Configure the PPP parameters (address, authentication and so on) and click Save.

### Table 3.9 Dial-in Parameters

Parameter	Description
Status	Enables or disables the port. Default: Disabled.
Speed	The speed that will be used by mgetty to configure the serial device. Default: 38400 bps.
Init Chat	Chat for modem initialization. Default: "" \d\d\d+++\d\d\ATZ OK +VCID=1OK.
PPP Address	Configures the local and the remote IP address for the the PPP link. If <i>Accept Configuration from Remote Peer</i> is selected, the remote peer should send both IP addresses (local and remote) during negotiation. Default: No Address.
Local IPv4/IPv6 Address	Configures the local IPv4/IPv6 address for this PPP connection.
Remote IPv4/IPv6 Address	Configures the remote IPv4/IPv6 address for this PPP connection.
PPP Authentication Protocol	<ul> <li>Uses the radio button to select: none, PAP, CHAP or EAP.</li> <li>None - no authentication.</li> <li>PAP - use PAP protocol and the authentication type configured in the PPP authentication type (it is configured in the Authentication / Unit Authentication page).</li> <li>CHAP - use CHAP protocol. The configuration of the CHAP secrets should be done while editing the file /etc/ppp/chap-secrets.</li> <li>EAP - use EAP protocol. Available authentications: CHAP, SRP-SHA1 and TLS. The configuration of the secrets for CHAP should be done while editing the file /etc/ppp/chap-secrets.</li> <li>EAP - use EAP protocol. Available authentications: CHAP, SRP-SHA1 and TLS. The configuration of the secrets for CHAP should be done while editing the file /etc/ppp/chap-secrets.</li> <li>Note: EAP authentication is only available with Windows XP operating systems.</li> <li>Default: None.</li> </ul>
СНАР	Configure the CHAP-interval, CHAP-max-challenge and CHAP-restart. Default values: • CHAP Interval = 0. • CHAP Max Challenge = 10. • CHAP Restart = 3.
PPP Idle Timeout	Number of seconds being idle before PPP times out. Default: 0 (no time-out).

### To configure or to edit one or more serial ports with a connected PDU:

- 1. Select Ports Serial Ports.
- 2. Click the checkbox for one or more serial ports with a connected PDU.
- 3. Click the Set Power button and use the drop-down menus to configure the physical settings.
- 4. Click Next or click the Power link.
  - a. Use the drop-down menu to select the PDU type.
  - b. Check the box to enable speed auto detection.
  - c. Configure the polling rate.
  - d. For Avocent/Cyclades PDUs, enter the power cycle interval and then use the drop-down menus to enable or disable Syslog, Buzzer and SW Overcurrent Protection.
- 5. Click Save.

#### Table 3.10 Power Parameters

Parameter	Description
Physical	
RJ-45 Pin-Out	Defines the serial port pinout as Auto, Cyclades or Cisco. Default: Auto.
Status	Defines the status of the serial port as either enabled or disabled. Default: Disabled.
Speed	Defines the speed as 300,600,1200, 1800, 2400, 4800, 9600, 19200, 38400, 57600, 115200 or 230400. Default: 9600.
Parity	Defines the parity as either Even, Odd or None. Default: None.
Data Bits	Defines the data bits as either 5, 6, 7 or 8. Default: 8.
Stop Bits	Defines the stop bits as either 1 or 2. Default: 1.
Flow Control	Defines the flow control as none, hardware, software, RXON software or TXON software. Default: None.
Power	
UPS Type	Defines the type or vendor of the UPS connected to the serial port. Vertiv™ Liebert® GXT4 and Vertiv™ Liebert® GXT5 UPSes are supported. Default: Auto.
PDU Type	Defines the type or vendor of the PDU connected to the serial port. Default: Auto.         Auto - the vendor is detected.         Avocent-Cyclades - the Avocent®-Cyclades PM PDU family.         Vertiv - Vertiv™ PDUs         SPC - SPC power control device family         ServerTech/Server Tech PRO2 - Server Tech family.         Raritan - Raritan PX G2 PDU family.         APC - APC rPDU2 family.         Eaton - Eaton ePDU G3 PDUs.         Geist - the Vertiv™ Geist™ PDU family.
Enable Speed Auto Detection	When enabled, detects the speed of the port. Default: Disabled.
Polling Rate	The interval in seconds to update information from the PDU. Default: 20.
For Avocent/Cyclades PDUs	
Power Cycle Interval	The interval in seconds between Off and On actions for the power cycle command. Default: 15.
Syslog	When enabled, the PDU will send syslog messages to the appliance. Default: Enabled.
Buzzer	Enables or disables the PDU's buzzer. Default: Enabled.
SW Overcurrent Protection	When enabled, the software's overcurrent protection is on. Default: Disabled.

### To copy/clone the configuration of one port to other ports:

- 1. Select Ports Serial Ports.
- 2. Click the checkbox for the serial port you want to clone.
- 3. Click Clone.
- 4. Enter the serial port(s) to be configured in the Copy Configuration To field and click Save.

NOTE: If the selected port is configured as a CAS Profile, the following parameters will not be copied: Port Name, TCP Port Alias, IPv4 Port Alias, IPv6 Port Alias and Power (merged outlets).

### To reset one or more serial ports to their factory configuration:

- 1. Select Ports Serial Ports.
- 2. Click the checkbox for one or more serial ports you want to reset to their factory configuration, then click the *Reset To Factory* button.

### NOTE: Serial ports are set to the CAS Profile and disabled in the factory configuration.

### Multi-Session Menu

An administrator can enable or disable the Multi-Session Menu. When enabled, users can access the menu from the web UI, CLI or the Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView software, and multiple users can connect simultaneously to a serial port. To connect to a port or start a shared session, the user must have permission to access the port. If more than one session to a serial port is being established, the console system displays the Multi-Session Menu. If the session being established is the first with the serial port, a normal session with the target opens. A first-session user can still access the Multi-Session Menu by typing the text hotkey (Ctrl-Z by default).

### To enable the Multi-Session Menu:

- 1. From the sidebar of the Expert tab, click Ports-Serial Ports.
- 2. Click the port for which you want to enable the Multi-Session Menu.
- 3. Click Set CAS CAS and near the bottom of the CAS Settings, use the drop-down menu to enable Show Multi-Session Menu.
- 4. Click Save.

The Multi-Session Menu includes options that are dependent on the access rights of the user. If a user does not have rights to an option, that option is not displayed. For example, Options 0, 2 and 5 from the following table are displayed for a user who only has permission to open read-only sessions.

#### Table 3.11 Multi-Session Menu Options

Number	Option	Description
0	Quit	Closes the client session.
1	Initiate a regular session	Opens a read/write session.
2	Initiate a sniff session	Opens a read-only session.
3	Send messages to another user	Sends a message to all users who are sharing the serial port.
4	Kill session(s)	Displays all sessions and asks to close one or more shared sessions.
5	List shared session(s)	Lists all other shared sessions.
6	Show Data buffering	Shows the content of the target data buffering file.
7	Clean Data buffering	Resets the content of the target data buffering file.

### **Internal Modem**

From the Internal Modem screen, if the port name displays ttyM1, then the internal modem is present and can be enabled and configured. If there are no entries in the Internal Modem table, then the internal modem is not present and this port cannot be used.

For models with a cellular modem, the port name displays as ttyM1 and the device type displays as LTE Modem. The cellular modem can only be configured for dial-out mode. By default, the cellular modem is disabled. For more information on configuring a cellular modem, see Cellular modem on page 51.

### To configure or edit the internal modem:

- 1. Select Ports Internal Modem and check the checkbox for the modem device.
- 2. Click the Set Dial-In or Set Dial-Out button and use the drop-down menus to configure the settings.
- 3. Configure the PPP parameters (address, authentication, etc.).
- 4. Click Save.

### **CAS** Profile

The CAS (Console Access Server) profile provides remote access to serial RS-232 console ports on your devices. Using a CAS profile, you can configure authentication, port configuration (such as speed and flow control), port aliasing, target auto discovery, data buffering type, port alerts, power integration and so on.

An administrator can configure the CAS profile by clicking Ports - CAS Profile.

### Auto discovery

The auto discovery feature will discover the target name of the server connected to the serial port. This name will be used as the alias of the serial port.

When auto discovery is enabled for a certain serial port, the appliance will attempt to communicate with the target device to determine the device's hostname at the following times:

- Upon appliance startup
- Upon target connection (DCD ON event)
- When the serial port is changed to enabled

### Auto discovery probe type

When auto discovery is initiated, the appliance will send probe strings and start analyzing target device answers using regular expressions. There are predefined probe and match strings as well as customer-defined ones.

For each probe string sent, all regular expressions defined by the match strings will be tested. After the last cycle, the sequence restarts. This procedure will run for a certain period (given by the auto discovery time-out parameter) or until the target is successfully detected. If auto discovery fails, the target name will be reset to the configured target name or to the corresponding unique default target name.

### NOTE: The configured target name will be used only after the auto discovery process fails.

# NOTE: The auto discovery process starts when there is variation in the DCD signal from OFF to ON (disconnect/connect the target's cable, turn off/on the target) and when the configuration of the serial port goes from disabled to enabled and there is a target connected in the port.

The probe strings will be used to stimulate the server (such as "\r": a single carriage return).

The match strings are regular expressions where "%H" is a placeholder for the target name you want to detect, such as %H .\*ogin:

or xxx%Hyyy

The first one will extract target name from things such as: MyServer Login: and will result in a target name of MyServer.

And the second one from things such as: Server xxxTARGETyyy and will result in a target name of TARGET.

### To configure the strings for probe/match used by auto discovery:

Perform this procedure to change the default settings or the probe or match strings used in auto discovery.

- 1. Select *Ports CAS Profile Auto Discovery*. The Settings, Probe Strings, Match Strings and Commands options appear in the side navigation bar.
- 2. To change the default auto discovery time-out or probe time-out, perform the following steps.
  - a. Select Settings.
  - b. Enter a new value in the Auto Discovery Timeout and Probe Timeout fields.
  - c. Select a speed from the Default Speed on Auto Discovery Failure drop-down menu and Probe Speed List.
  - d. Click Save.
- 3. To add a new probe or match string or delete an existing string, perform the following steps.
  - a. Select Probe Strings or Match Strings.
  - b. Click Add, then enter the new probe or match string in the field and click Save.

-or-

Click the checkbox for the desired probe or match string and click Delete.

4. Click Save.

### Auto discovery command type

When auto discovery is initiated, the appliance will attempt to login to the target device and issue a specified command. The output of the command will be analyzed to look for a hostname. After executing the command, the appliance will log out of the target device.

#### To add new commands for auto discovery:

Perform this procedure to create custom commands for auto discovery.

- 1. Select Ports CAS Profile Auto Discovery Commands.
- 2. A table is shown with all currently defined commands including the built-in commands.
- 3. Click Add.
- 4. Enter a unique name for this new command entry.
- 5. Enter the command. This is the complete command including any arguments or parameters, to execute on the target device.
  - a. If the command is left blank, the command prompt of the target device will be used to try to determine the hostname.
  - b. The account being used (as specified by the Username/Password for this port) must have permission to execute the command on the target device.
- 6. Enter a match string. This is a regular expression as used by the Probe type.
  - a. Whatever response the target device produces for the executed command will be matched against this regular expression. If the response matches, then the part of the response corresponding to the %H portion of the match string will be used as the port alias for this serial port.
- 7. Enter a logout command. If left blank, the appliance will attempt to use the command "logout" to logout of the target device.
- 8. Enter a login prompt and password prompt. If these are left blank, the appliance will look for "login: " and "password: " respectively. Case is ignored for this comparison. These prompts are plain strings and not regular expressions.
- 9. Enter a command prompt. If left blank, the appliance will look for "\$ " or "# " to recognize a command prompt from the target device.

- a. The specified string need only be present somewhere in the line output by the target device in order to be recognized as a command prompt. It does not have to be at the beginning, end, nor match the entire line.
- 10. Click Save.

### Auto discovery status

Status and log files are provided for debugging of the discovery process.

### To view the auto discovery status:

- 1. Select Monitoring Auto Discovery Status.
- 2. A table is displayed showing any ports that have Auto Discovery enabled.
- 3. The table shows the port number, the auto discovery type and the name. If discovery was unsuccessful or not attempted, the name will be the port name configured on the CAS page for the port.
- 4. Under the Port column, click the port number link to display the log of the most recent discovery attempt for that port.
- 5. To export the log to the client computer, click Export Log (optional).

The log information shows the strings sent to the target device and the target device's responses. This information helps to create custom probe/match strings or commands for auto discovery.

### Auto discovery regular expressions

When defining regular expressions for the match strings in both the probe and command methods, the following are some of the basic rules shown in the ACS console system default match strings. More detailed regular expression instructions are readily available on the internet.

### Table 3.12 Auto Discovery Regular Expressions

Rule	Description
%Н	Represents the portion of the string that is to be considered the target's hostname. This must be present or the match string will be ignored.
	Matches any single character.
*	Matches zero or more of the preceding character or set of characters.
?	Matches zero or one of the preceding character or set of characters.
^	Matches the beginning of the response. When used inside brackets, it negates the character set. ([^a] means any characters other than "a")
\$	Matches the end of the response.
١	Used to escape special characters like "(", "\", etc.
[]	Brackets are used to define a set of characters.
-	When used inside brackets, it specifies a range of characters. ([a-z] means any character between "a" and "z."
I	When used inside brackets, the pipe character is a logical "or" when escaped with a "\". So "[6\ 8]000" will match either 6000 or 8000.

### Auto answer

The auto answer feature can be enabled per port. When the input data received on a port matches an input string configured in Auto Answer, the corresponding output string will be transmitted to the serial port. Default: Disabled.

#### To configure the input/output strings used by auto answer:

- 1. Select Ports CAS Profile Auto Answer.
- 2. To add an auto answer input and output string, click *Add*. Enter a new string in the Input String or Output String fields and click *Save*.

-or-

To delete an auto input and output string, select the checkbox next to the string you want to delete. Click *Delete*, then click *Save*.

### Pool of ports

An administrator can create a pool of serial ports where each serial port in the pool shares a pool name, Telnet Port Alias, SSH Port Alias, Raw Mode Port Alias, IPv4 Alias and IPv6 Alias. The first available port in the pool is used as the serial port for connection.

NOTE: The multiple session access right does not have any effect when using a pool of CAS ports. When all ports in the pool are taken, the connection to the pool is denied.

NOTE: All ports in the pool must share the same CAS protocol. The protocol is validated during the connection to the serial port. If the protocol does not match, the connection will be denied.

### To configure a pool of CAS ports:

- 1. Click Ports CAS Profile Pool of Ports.
- 2. To create a pool, click Add.

-or-

To edit an existing pool, click the name of the desired pool.

-or-

To delete a pool, check the box next to the desired pool and click Delete.

- 3. Enter the parameters for the pool in the appropriate fields.
- 4. On the left side of the Pool Members field, select the desired ports and click Add.

-or-

On the right side of the Pool Members field, select the desired ports and click *Remove*.

5. Click Save.

NOTE: A serial port can only belong to one pool at a time, but a user can create an empty pool and add ports to it later.

Parameter	Description
Pool Name	The name of the pool. The pool name is mandatory and should follow hostname guidelines, not exceed 64 characters and start with a letter.
Port Alias	<ul> <li>The Port Alias where the pool responds for each protocol.</li> <li>Telnet Port Alias for telnet protocol. It is optional.</li> <li>SSH Port Alias for ssh protocol. It is optional.</li> <li>Raw Mode Port Alias for raw mode protocol.</li> <li>It is mandatory when Raw Mode is configured as protocol for the ports.</li> </ul>
Pool IPv4 Alias	The IPv4 address used by the pool. This parameter is optional.
Pool IPv4 Alias Interface	The interface used by the IPv4 Alias. Default: Eth0.
Pool IPv6 Alias	The IPv6 address used by the pool. This parameter is optional.
Pool IPv6 Alias Interface	The interface used by the IPv6 Alias. Default: Eth0.

### Table 3.13 Pool of CAS Ports Parameters

### **RESTful client**

The console system supports a programmable RESTful client interface. This is used to send pre-configured HTTP requests to another device's RESTful API and should not be confused with the RestAPI which is used to communicate with and configure the console system itself. For details about the ACS8000 console system RestAPI, see the Vertiv<sup>™</sup> Avocent<sup>®</sup> ACS800/8000 Advanced Console System Application Programming Interface (API) User Guide.

After configuration of RESTful URLs, the console system performs, from within a serial session, menu-selected GET and POST operations to pre-programmed HTTP/HTTPS URLs for server resources on the network.

### NOTE: URL options must be configured using either HTTP or HTTPS with the RESTful client menu.

### To configure the RESTful client:

- 1. Click Ports CAS Profile RESTful Settings.
- 2. Enter the Action Name, URL, POST Data, Username and Password in the appropriate fields and use the dropdown menu to select *GET* or *POST* as the HTTP Method for each RESTful option.
- 3. Click Save.

When configuring actions, the following context variables can be used.

### Table 3.14 Context Variables Descriptions

Context Variable	Description
\$PORT	Identifies the serial port (1-48) when the menu is invoked.
\$PORTNAME	The name of the port.
\$IPPORTALIAS	The IPv4 alias of the port.
\$TCPPORTALIAS	The TCP (Telnet port) alias of the port.
\$ACSHOSTNAME	The host name of the console system.
\$ACSIPADDR	The IP address of the console system.

## NOTE: Certain HTTP POSTs use the HTTP request body to send appropriate information to servers, usually coded as XML or JSON.

### To enable the RESTful client:

1. If port access applies to all users, from the side navigation bar of the *Expert* tab, click *System - Security - Security Profile*, then under Serial Devices, click the RESTful Menu checkbox and click *Save*.

-or-

If port access is controlled by authorization assigned to users groups, from the side navigation bar of the Expert tab, click Users - Authorization - Groups.

- a. Click the group for which you want to enable the RESTful client.
- b. From the side navigation bar, click Access Rights Serial.
- c. Click the port for which you want to enable the RESTful menu. Under Target Access Rights, click the RESTful Menu box.
- 2. From the side navigation bar of the Expert tab, click Ports Serial Ports.
- 3. Click the port for which you want to enable the RESTful menu and then click CAS at the top of the window.
- 4. In the RESTful Hot Key field, enter the hotkey you want to use to initiate the RESTful client and click *Save*. **NOTE: The hotkey is not set by default.**

### Using the RESTful client interface

After opening a serial session, press the RESTful hot key to open the RESTful client interface for the current session. A RESTful Menu is displayed with numbered options. Enter the number of the RESTful client request you want to perform. By default, Exit and Help are the first two requests in the menu. You can configure up to eight additional requests from the web UI of the console system.

### Dial-in profile

An administrator can configure secure dial-in settings such as OTP login, PPP connections, PPP/PAP authentication, callback and OTP users for PPP connections.

### NOTE: If pluggable devices are being used for dial-out, dial-in should be disabled.

### To configure secure dial-in settings for ports with the Dial-in Profile:

- 1. Select Ports Dial-In Profile Settings.
- 2. From the Log In To Appliance drop-down menu, choose one of the following options to enable logging into the console system through the modem or to select a condition for which logging in is allowed.
  - a. To allow callback connections only, select Callback.

-or-

- b. To allow any connection, select Enable.
- 3. From the OTP Login Authentication drop-down menu, select *Enable* to enable OTP authentication.
- 4. From the PPP Connection drop-down menu, choose one of the following options to enable PPP connections.
  - a. To allow PPP callback connections only, select Callback.

-or-

- b. To allow any connection, select *Enable*.
- 5. When the PAP authentication protocol is configured for the port, select the authentication type from the PPP/PAP Authentication menu.
- 6. Use the drop-down menu to enable or disable the caller ID filter.
- 7. Click Save.

### To configure callback users and phone numbers for ports with the Dial-in Profile:

- 1. Select Ports Dial-In Profile Secure Dial-In Callback Users.
- 2. Click Add.
- 3. Enter the name and phone number used to perform the callback in the appropriate fields and click Save.

### To configure PPP OTP users for ports with the Dial-in Profile:

- 1. Select Ports Dial-In Profile Secure Dial-In PPP OTP Users.
- 2. Click Add.
- 3. Enter the username and passphrase in the appropriate fields and click Save.

### NOTE: This PPP OTP user will establish PPP connection after being successfully authenticated.

### To configure EAP-TLS as PPP authentication for ports with the Dial-in Profile:

- 1. Select Ports Internal Modem.
- 2. Check the box next to the port where the modem is connected and click Set Dial-In.
- 3. Configure the PPP Address settings. For example, set the PPP Address to Local Configuration using 10.0.0.1 as the Local IPv4 Address and 10.0.0.2 as the Remote IPv4 Address.
- 4. For PPP Authentication, select the By Appliance radio button, and then select the EAP radio button for the protocol. Click *Save*.
- 5. Select Ports Dial-In Profile Settings.
- 6. Use the drop-down menu to enable the PPP Connection and click Save.
- 7. Copy the certificates and keys to the /etc/ppp/cert file. They must be named server.crt (the ACS800/8000 certificate), ca.crt (the Certificate Authority's certificate) and server.key (the ACS800/8000 asymmetric key).

### To configure CHAP secrets for ports with the Dial-in Profile:

- 1. Select Ports Dial-In Profile Secure Dial-In CHAP Secrets.
- 2. Click Add.
- 3. Enter the username and secret in the appropriate fields and click Save.

### Caller ID

You can filter incoming calls based on caller ID by enabling the Caller ID Filter in the Secure Dial-In settings. When enabled, the incoming caller ID number must be listed for the call to be answered. By default, it is disabled.

You can add numbers directly, by range or by prefix.

To enter a number directly, enter the number without any symbols. For example: 8881234567.

You can enter a range by inserting a hyphen (-) between two caller ID numbers. Any number between and including those two numbers will be accepted. For example: 8881234560-8881234569.

### NOTE: The range must be less than 100 phone numbers.

You can enter a prefix by putting an asterisk (\*) after a partial phone number. The incoming call will be answered if the phone number begins with the partial number specified. For example: 8881234\*.

If the Caller ID Filter is enabled and no numbers are specified, then all calls are blocked. Blocked calls are not answered and ring until timing out. If the Caller ID feature is disabled, then all calls are answered.

### To enter a list of caller ID numbers:

- 1. Select Ports Dial-In Profile Secure Dial-In Caller ID.
- 2. Click Add and enter the caller ID number, range or prefix.
- 3. Click Save.

### To delete a caller ID number from the list:

- 1. Select Ports Dial-In Profile Secure Dial-In Caller ID.
- 2. Check the box next to the number to be deleted.
- 3. Click Delete.

### **Dial-out profile**

#### To configure the Dial-out profile for a serial port with a connected modem:

- 1. Select Ports Serial Ports.
- 2. Click the checkbox for a serial port with a connected modem.
- 3. Click the Set Dial-out button.
- 4. Use the drop-down to enable/disable the port.
- 5. Configure the phone number to dial on-demand in the field Phone No.
- 6. Use the drop-down to configure the modem speed.
- 7. Configure the initial chat with modem in the Init Chat field.
- 8. Configure the PPP parameters (address, authentication and so on) and click Save.

NOTE: The Dial-out profile will work only to establish PPP link on-demand. The administrator must configure static route to have packages routed to the PPP interface.

#### Table 3.15 Dial-out Parameters

Parameter	Description
Status	Enables or disables the port. Default: Disabled.
Phone No.	The phone number to dial to.
Speed	The speed that will be used to configure the serial device and communicate with the connected modem.
Init Chat	Chat for modem initialization.
Local IPv4/IPv6 Address	Configures the local IPv4/IPv6 address for this PPP connection. If empty, PPP will accept the address from the remote peer.
Remote IPv4/IPv6 Address	Configures the remote IPv4/IPv6 address for this PPP connection. If empty, PPP will accept the address from the remote peer.
PPP Authentication Protocol	Configures which end of the connection controls this PPP authentication and selects the method to be used.
PPP Idle Timeout	Number of seconds being idle before PPP times out. Default: 0 (no time-out).
СНАР	Configures CHAP specific PPP authentication settings.

### Socket client profile

### To configure the socket client profile for a serial port with a connected device:

- 1. Select Ports Serial Ports.
- 2. Click the checkbox for a serial port with a connected device.
- 3. Click Set Socket Client and use the drop-down menus to configure the physical settings.
- 4. Configure the Socket Client Settings (remote server address, TCP port and event trigger) and click Save.

Parameter	Description
RJ-45 Pin-Out	Defines the serial port pinout.
Status	Defines the status of the serial port as either enabled or disabled. Default: Disabled.
Speed	Defines the speed as 300, 600, 1200, 1800, 2400, 4800, 9600, 19200, 38400, 57600, 115200 or 230400. Default: 9600.
Parity	Defines the parity as Even, Odd or None. Default: None.
Data Bits	Defines the data bits as 5, 6, 7 or 8. Default: 8.
Stop Bits	Defines the stop bits as 1 or 2. Default: 1.
Flow Control	Defines the flow control as none, hardware, software, RxON software or TxON software. Default: None.
Remote Server	IPv4 or IPv6 address of the remote server.
Remote TCP Port	TCP port to be used to establish a connection with a remote server.
Establish Connection	Configure the event that will trigger the establishment of the connection: DCD Regards or Always.

### Table 3.16 Socket Client Parameters

### 3.3.8 Cellular modem

The Avocent ACS800/8000 advanced console system cellular modem configuration interface is similar to the internal 56k modem configuration interface.

### To configure or edit the internal cellular modem:

- 1. Select Ports Internal Modem.
- 2. Click the *ttyM1* link to open the modem's dial-out configuration page.

NOTE: The cellular modem can only be configured for dial-out mode.

- 3. Use the drop-down menu to enable the modem by changing the Status to *AlwaysOn*. When set to *AlwaysOn*, the modem comes up after each reboot.
- 4. The APN field contains the default Access Point Name for the provider. The APN name likely must be changed to whatever your provider has configured for your specific SIM account.
- 5. Enable or disable the option to replace the default route.
- 6. Click Save to apply the changes.

### Status

The Status field is set to Disabled by default. Setting it to AlwaysOn starts the point-to-point daemon (pppd) and brings up the cellular modem. When set to AlwaysOn, the cellular modem comes up after each reboot.

When Status is set to Failover, the cellular modem only comes up when network failover occurs if the modem is set as the secondary device in the Network Settings.

### Details

The Details section shows the CCID and IMSI numbers read from the SIM card. If these numbers are not present, or show something invalid for the number, then there was a problem reading the SIM card. Verify the SIM card is installed properly. The IMEI number is from the chipset of the cell modem.

### **Cell Status**

The Cell Status line indicates the current state of the cellular modem.

The first field on this line indicates if the cellular modem is Disabled, configured for Failover usage, or is Enabled.

The second field is present when the modem is not Disabled and indicates one of the following:

- Down The modem is not connected and is not currently attempting to connect.
- Registering The modem is trying to register with the provider's network.
- Connecting The modem is trying to connect.
- Up The modem has established a connection and the IP address assigned to the modem connection is displayed as well.

### APN

The Access Point Name (APN), which is listed in the chat script. From this field, you can change the APN without having to edit the chat script directly.

### **Replace Default Route**

Checking the Replace Default Route option makes the cellular modem the default gateway whenever the modem is active. The original gateway is restored when the cellular modem is shut down. This is similar to entering a static route but useful to make the cellular modem the default gateway for internet access.

NOTE: Replace Default Route should not be checked when using the modem in failover mode. The failover logic handles updating the routes automatically.

### **Signal Quality function**

The Signal Quality field reports the strength of the cellular signal in terms of a number of bars (out of 7 max) and a decibel level. The field is only populated once a signal check has been done by clicking on the Signal Check button at the top of the page. Signal Quality will report something like: 6 of 7 bars, -83 dBm.

The Signal Check cannot be done while the modem is in session.

### **SIM PIN entry**

If the SIM PIN Status field is reporting anything other than "Ready", then you may need to enter a PIN or unlock code to unlock the SIM card. Click the SIM PIN/Password button at the top of the page to enter your PIN or PUK to unlock the SIM card.

### **Advanced Settings**

Checking the Show Advanced Settings box displays additional cellular modem settings that rarely need to be used unless debugging or being configured by an advanced user.

### **Persist Mode**

When Persist Mode is enabled, the console system tries to bring the cellular modem back up if the ppp daemon shuts down for any reason. When disabled, the cellular modem stays down if the ppp daemon shuts down (for example, if cellular service is lost). By default, Persist Mode is enabled.

### Keep Alive

When Keep Alive mode is enabled, the console system periodically sends a ping across the cellular network to keep the carrier side from disconnecting the connection due to lack of activity. The user can specify the Interval in seconds as well as an IP Address to which to send a ping message. The default Interval is 60 seconds, and the default IP Address is 8.8.8.8.

### **Use Cell Provider DNS**

When Use Cell Provider DNS is enabled, the console system will use the DNS settings provided by the cellular provider whenever the cellular modem is up. By default, Use Cell Provider DNS is enabled. The user can disable this by unchecking the box to continue to use the DNS settings from the Network – Settings page when the cellular modem is up.

### Debug Level

The Debug Level setting controls the amount of debug information that is logged by various cellular modem processes. A level of 0, the default, means there is no debug logging. Levels of 1 or 2 have increasing levels of debug information output to the Modem PPPD log.

The Debug Level should be left at 0 unless actively debugging the cellular connection as the extra data logging can impact performance. Whenever the Debug Level is non-zero, a "Cell Modem Debug Enabled" warning message is shown at the top page as a reminder.

### MTU Size

The MTU (Maximum Transmission Unit) Size defaults to 1400 bytes. This default is what has been recommended for certain carriers.

### **EPS Mode**

The EPS (Evolved Packet System) Mode controls the mode of operation for EPS by the cellular modem. When set to the default setting of "Default", the console system sets the EPS mode based on predetermined values for the carrier. This value should only be changed by an advanced user or at the carrier recommendation if there are problems with the cellular connection. The values 0 through 3 correspond to the following modes of operation: PS mode 2, CS/PS mode1, CS/PS mode 2 and PS mode 1.

### PDP Type

The PDP Type specifies the packet data protocol. When set to the default setting of "Default", the console system sets the PDP Type based on predetermined values for the carrier. This value should only be changed by an advanced user or at the carrier recommendation if there are problems with the cellular connection.

### Init Chat

The current chat script is displayed in an editable window. You can make custom changes to the chat script from this window. The default chat script is predetermined by the service provider.

### NOTE: For most users, the default chat script should be used.

### **PPP** Authentication

The PPP Authentication defaults to none but can be used to configure which end of the connection controls the PPP authentication and to select a method to be used. The appliance supports PAP, CHAP and EAP. The Remote Peer setting supports PAP and CHAP and allows for entering the Username and Passphrase.

### **PPP Idle Timeout**

The PPP Idle Timeout specifies the number of seconds before PPP times out on an idle connection. The default is 0 which means there is no timeout.

### **CHAP Settings**

This allows changing the CHAP Settings. The default values are 0 seconds for the Chap-interval, 10 bytes for the Chap-max-challenge, and 3 seconds for the Chap-restart.

### Verifying the cellular connection status

The Cell Status line on the Dial-Out on Demand screen indicates if the cellular modem is up and what IP address it has been assigned.

- 1. Select Ports Internal Modem.
- 2. To open the modem's dial-out configuration page, click the *ttyM1* link.
- 3. The Cell Status should include "Up:" followed by an IP address if the modem has connected to the cellular network successfully.

### An alternative way to find the IP Address assigned by the cellular provider:

- 1. Select Monitoring Network Devices.
- 2. The table should contain a line for an LTE-Modem. This line will contain a valid IPv4 Address entry if the modem was able to connect to the cellular network and was successfully assigned an IP address.
- 3. The link status should show as Up.

The IP address is an address on the private network service. The IPv4 address is not fixed and may change each time you reboot or re-establish the cell network connection unless your SIM has been assigned a static IP address by the carrier.

### To view the Modem PPPD log:

- 1. Select Monitoring Modem PPPD Log.
- 2 The most recent log output from the PPP daemon is shown with the most recent entries shown first.
- 3. The full log file can be saved to the client computer by clicking the Export Log button.

The PPPD log should show a successful connection including a valid "local IP address."

The amount of debugging information included in the PPPD log can be controlled by setting the cellular modem's Debug Level under the Advanced Settings section of the *Ports – Internal Modem – ttyM1* page.

### Using the cellular modem in failover

The cellular modem can be automatically brought up and used as a network failover device when the main network interface isn't working.

### Set the internal modem to be used for failover:

- 1. Select Ports Internal Modem ttyM1.
- 2. Use the drop-down menu to select Failover for the device Status.
- 3. Click Save.

#### Enable network failover:

- 1. Select Network Settings.
- 2. Select Enable Network Failover.
- 3. Use the drop-down menu to select *LTE* for the Secondary Interface.
- 4. Select the desired Trigger such as Primary Interface Down.
- 5. Click Save.

With failover enabled, if primary interface goes down, then the cellular modem is triggered to come up. With the typical service provider, this only provides internet access. A server on the internet can't log in directly. A different type of service, or provider, may be able to provide access.

### Using the cellular modem in failover with IPSec

The other alternative is to use a VPN service with the cellular modem. Configure the VPN to connect via IPSec to a secure gateway with a public IP address, and then you can access the console system through the IPSec tunnel.

### Setup the IPSec service:

- 1. Go to System Security Security Profile page, scroll down, and check the Enable IPSec box.
- 2. Click Save to apply the changes.
- 3. Go to the Network IPSec(VPN) page, and add a new VPN profile.
- 4. Enter the VPN parameters.
- 5. When used for failover, the IPSec Boot Action should be set to Add.
- 6. For IPSec configuration information., refer to the IPSec(VPN) section on page 29.
- 7. When finished, click Save.

#### Setup the Network for failover:

- 1. Navigate to the Network Settings.
- 2. Select the VPN connection name that was added above to use for failover.
- 3. Click Save to apply the changes.

When a failover event occurs, such as ethO going down, the console system will bring up the cellular modem and then start the VPN. The LAN clients on the remote gateway can access the console system via the tunnel virtual IP address.

### 3.3.9 Pluggable devices

The console system supports a variety of pluggable devices connected to its USB ports. Some models also support a single SD card in the SD card slot.

NOTE: When a pluggable device is not in the current list of supported pluggable devices, the console system may attempt to configure the device with standard settings, allowing it to work normally. Also, when a pluggable device is not listed in the internal database, the Device Info column may show no text at all or show different text based on the type of card. One example is Unknown device f024 (rev 01).

#### To install and detect a pluggable device:

- 1. From the side navigation bar, select *Pluggable Devices*.
- 2. Click *Enable Pluggable Device Detection* to detect connected pluggable devices, unless it has already been enabled from the System Security page.
- 3. Connect a device to a USB port or insert an SD card into the SD card slot on the console system.
- 4. The Pluggable Devices table displays all detected pluggable devices.

NOTE: To disable pluggable device detection, click Disable Pluggable Device Detection.

#### To eject or delete a pluggable device:

- 1. From the side navigation bar, select *Pluggable Devices*.
- 2. Select the checkbox next to the pluggable device you want to eject or delete.
- 3. Click Eject or Delete as desired. Click Save.

NOTE: Always eject a pluggable device from the web UI before physically removing the device.

### **Device configuration**

Storage devices are automatically mounted and configured once detected by the console system unless storage device support is disabled. Ethernet cards, modems and USB console devices must be configured.

#### NOTE: Configuration of wireless devices takes effect only after the device is ejected and re-inserted.

#### To configure a pluggable device:

- 1. From the side navigation bar, click *Pluggable Devices*.
- 2. For a network device, click its name to configure its network parameters.

-or-

For a modem (V.92), click the box next to its name and then click either Set Dial-In or Set Dial-Out to configure its dial-in or dial-out parameters.

-or-

For a USB console device, click the box next to its name and then click *Set Console* to add it to the system as another port. You can either accept the default port assignment or enter an unused port in the Port field and click *Assign*. Then go to the *Ports* - *Serial Ports* page to configure and enable the added port.

### **USB** console mapping

USB console devices will default to a port based on the number of console system serial ports. The following table shows the default port assignments.

### Table 3.17 ACS80X USB Console Mapping

		USB Ports			
Model	Top Left	Bottom Left	Top Right	Bottom Right	
ACS802	3	4	5	6	
ACS804	5	6	7	8	
ACS808	9	10	11	12	

#### Table 3.18 ACS80XX USB Console Mapping

	Back USB Ports						Front USB Ports	
Model	Top Left	Bottom Left	Top Middle	Bottom Middle	Top Right	Bottom Right	Тор	Bottom
ACS8008	9	10	11	12	13	14	15	16
ACS8016	17	18	19	20	21	22	23	24
ACS8032	33	34	35	36	37	38	39	40
ACS8048	49	50	51	52	53	54	55	56

If the default assigned port is already in use or if the USB device is not plugged directly into the console system, the next available port after the reserved ports will be used. For example, on an ACS808 console system, port 13 is the next available port.

### Hot plugging

Serial console devices can be unplugged and plugged back into the same USB port without interrupting any open serial sessions. In most cases, the USB device receives the same Linux-assigned device name. In some cases, a different device name is assigned if the original name appears in use.

NOTE: The device must be plugged back into the same port in order for hot plugging to work.

### Unrecognized console devices

Some USB devices are not recognized as a console Device Type. If a device that should be a USB console shows up in the Pluggable Devices list with a different Device Type, such as modem, then it can be forced to be treated as a console by editing the /etc/udev/console.whitelist file.

### To add a device to the console.whitelist:

- 1. Log into the appliance as the root user and go to the Linux command prompt.
- 2. With the unrecognized device plugged in, enter the lsusb command.

[root@ACS8048 ~]# lsusb Bus 001 Device 003: ID 0424:2514 Bus 001 Device 009: ID 03f0:013f Bus 001 Device 004: ID 0424:2514 Bus 001 Device 002: ID 0424:2514 Bus 001 Device 001: ID 1d6b:0002

- 3. Identify the unrecognized device. The 0424:2514 and 1d6b:0002 are internal to the Vertiv<sup>™</sup> Avocent<sup>®</sup> ACS console system. In this example, the unrecognized device is ID 03f0:013f. The ID is in USB VID:PID format.
- 4. Add a line at the end of the console.whitelist file that consists of just the VID and PID with a space separating them instead of a colon, then restart the udev process as follows:

```
[root@ACS8048 ~]# echo "03f0 013f" >> /etc/udev/console.whitelist
[root@ACS8048 ~]# /etc/init.d/udev restart
```

5. The device should now show up in the Pluggable Devices list as a console Device Type and can be configured as a console as normal.

### 3.3.10 Authentication

Authentication can be performed locally, with OTP, or remotely on a LDAP, Radius, Kerberos or TACACS+ authentication server. If the console system is managed by a Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView server, Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView software authentication is also supported. The console system also supports remote group authorizations for the LDAP, Radius, Kerberos and TACACS+ authentication methods.

Fallback mechanisms of the following types are available:

Local authentication can be tried first, followed by remote, if the local authentication fails (Local/Remote\_Method).

-or-

Remote authentication may be tried first, followed by local (Remote\_Method/Local).

-or-

Local authentication may be tried only if a remote authentication server is down (Remote\_Method\_Down\_Local).

An administrator can configure authentication using the CLI utility, the web UI or the RestAPI. The default authentication method for the console system and the serial ports is Local. Any authentication method that is configured for the console system or the ports is used for authentication of any user who attempts to log in through Telnet, SSH or the web UI.

### Appliance authentication

The console system authenticates for the console system and the ports, either in groups or individually.

## NOTE: It is advised when using group authorization that you use the same authentication for both the console system and all serial ports or use Single Sign-on Authentication to facilitate group authorization.

When Single Sign-on Authentication is disabled, the console system uses the individual configuration based in the destination of the access: the console system itself or each serial port. Users must use their password each time they access an individual port. If enabled, Single Sign-on Authentication will use the authentication server you choose from the pull-down menu for all access and no further authentication will be needed.

NOTE: Selecting *unconfigured* from the pull-down menu will allow the ports to continue to use individual authentication servers and will require your password the first time you access any port. After that, the port will not require password authentication if Single Sign-on Authentication is enabled.

### To set authentication for the console system:

- 1. Click Authentication Appliance Authentication.
- 2. Select the desired authentication server from the Authentication Type drop-down menu.
- 3. Select *Enable fallback to Local type for root user in appliance console port* when the remote authentication fails and an administrator wants to access the appliance via console port as the root user.
- 4. Select *Enable single sign-on* to enable single sign-on authentication and select the desired authentication server from the Authentication Type drop-down menu.
- 5. Click Save.

### **Duo Push multi-factor authentication**

Duo Push can be added as a second factor to previously configured appliance authentication.

### To enable Duo Push multi-factor authentication for the console system:

- 1. Click Authentication Appliance Authentication.
- 2. Check the Enable MFA box.
- 3. Select the desired authentication from the MFA Type drop-down menu.
- 4. From the Apply MFA To drop-down menu, select whether MFA should be applied to external authentication servers, local authentication servers or both.
- 5. Click Save.

When the Enable MFA box is checked, the fallback option disables MFA for the Local type.

### Radius challenge with token

Support is provided for using a token with Radius Challenge and a remote Radius Authentication Server.

### To enable this token-based multi-factor authentication for the console system:

- 1. Click Authentication Appliance Authentication.
- 2. Select Enable MFA Token field.
- 3. Click Save.

When this multi-factor authentication is enabled, the console system will include an MFA Token field when logging in to the Web UI in addition to the Username and Password fields.

This MFA Token field is intended to be used with a one-time password authenticator such as a USB authentication key. When logging in to the Web UI, the token must be entered before the login procedure is initiated. Typically, a user will enter their username and password and will then press a button on the USB authentication key to fill in the MFA Token field. When the remote authentication server processes the username and password, it will then ask the console system for the additional challenge information and the console system will provide the previously entered MFA Token.

The Web UI does NOT support entering a username and password and then later asking the user for a token or code.

### Authentication servers

When using an authentication server, you must configure its IP address and, in most cases, other parameters before it can be used. The following authentication servers require configuration: RADIUS, TACACS+, LDAP(S)|AD, Kerberos, Duo and Vertiv<sup>™</sup> Avocent® DSView servers.

### To configure a RADIUS authentication server:

- 1. Select Authentication Authentication Servers RADIUS.
- 2. Enter the IP addresses of the First Authentication Server and First Accounting Server.
- 3. If used, enter the IP addresses for the Second Authentication Server and Second Accounting Server.

### NOTE: Leave the accounting fields blank if the authentication server is not setup for accounting.

- 4. Enter your secret word or passphrase in the Secret field (applies to both first and second authentication and accounting servers), then re-enter the secret word or passphrase in the Confirm Secret field.
- 5. Enter the desired number of seconds for server time-out in the Timeout field.
- 6. Enter the desired number of retries in the Retries field.
- 7. If you select the Enable Service-Type attribute to specify the authorization group checkbox, enter the authorization group name for each of the following Service Types: Login, Framed, Callback Login, Callback Framed, Outbound and Administrative.
- 8. Click Save.

### To configure a TACACS+ authentication server:

- 1. Select Authentication Authentication Servers TACACS+.
- 2. Enter the IP addresses for the First Authentication Server and First Accounting Server.
- 3. If used, enter the IP addresses of the Second Authentication Server and Second Accounting Server.
- 4. Select the desired service (PPP or raccess) from the Service drop-down menu.
- 5. Enter your secret word or passphrase in the Secret field (applies to both first and second authentication and accounting servers), then re-enter the secret word or passphrase in the Confirm Secret field.
- 6. Enter the desired number of seconds for server time-out in the Timeout field.
- 7. Enter the desired number of retries in the Retries field.
- 8. Select the desired TACACS+ Version from the drop-down menu.
- 9. If you select the Enable User-Level attribute to specify the authorization group checkbox, enter the authorization group name for up to 15 User-Levels.
- 10. Click Save.

### To configure an LDAP(S)|AD authentication server:

- 1. Select Authentication Authentication Servers LDAP(S)/AD.
- 2. Enter the IP address of the server.
- 3. Enter the Base.
- 4. At the Secure drop-down menu, select Off, On or Start\_TLS.
- 5. Enter the Database User Name.
- 6. Enter your Database Password, then re-type the database password in the Confirm Password field.
- 7. Enter your desired Login Attributes.
- 8. Enter your desired Object Class.
- 9. Click Save.

#### To configure a Kerberos authentication server:

- 1. Select Authentication Authentication Servers Kerberos.
- 2. Enter the IP address (Realm) of the server.
- 3. Enter the Realm Domain Name (example: AVOCENT.com).
- 4. Enter the Domain Name (example: .avocent.com).
- 5. Click Save.

### To configure a Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView authentication server:

- 1. Select Authentication Authentication Servers DSView.
- 2. Enter IP Address 1 4 for the Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView servers in the relevant fields.
- 3. Click Save.

### To configure a Duo authentication server:

- 1. Select Authentication Authentication Servers Duo.
- 2. Enter the Integration Key.
- 3. Enter the Secret Key.
- 4. Enter the API Hostname (example: api-12345678.duosecurity.com).
- 5. At the Failmode drop-down menu, select Safe or Secure.
- 6. Click Save.

The requested Duo settings are available to the administrator of the Duo account via the Duo Dashboard.

### 3.3.11 Users accounts and user groups

Access to ports and other privileges can be managed based on authorizations that an administrator can assign to custom user groups and individual user accounts.

Groups and users can also be authorized to manage power while connected to devices. The console system has two default users (admin and root) and four pre-defined user groups: admin, appliance-admin, shell-login-profile and user.

A user account must be defined for each user on the console system or on an authentication server. The admin and root users have accounts by default, and either administrator can add and configure other user accounts. Each local user account is assigned to one or more of the user groups.

# NOTE: When a user is removed from all groups, that user's privileges revert to those of the default user group. For this reason, it is recommended custom groups be used and the default user group is not granted additional privileges.

By default, all users have access to all ports on the console system. In order to authorize access via user groups, an administrator must enable port access to be controlled by authorizations assigned to user groups.

### To enable port access to be controlled by authorizations assigned to user groups:

- 1. From the Expert tab of the side navigation bar, click System Security Security Profile.
- 2. Under the Serial Devices heading, click Controlled by Access Rights assigned to User Groups and specific users button, then click *Save*.

### Local accounts

The console system has two local user accounts by factory default:

- admin: Performs the initial network configuration. The admin user is a member of the admin group and can configure the console system and ports as well as user and group authorizations.
  - root: Has the same administrative permissions as the admin user but also has unlimited privileges from the shell. The root user is a member of the admin and shell-login-profile groups. When a root user logs in via the CONSOLE port, SSH or Telnet, the session is pre-defined by the login profile to go directly to shell. The login profile can be customized so that it does not go directly to shell.

NOTE: By default, the root user is disabled. An admin can enable the root user from the Users - Local Accounts - User Names page.

## NOTE: If the admin and root account passwords are lost, contact Technical Support for password recovery information.

#### To view user appliance access rights:

- 1. Click Users Local Accounts User Names. The list of usernames displays in the content area.
- 2. Click a username under the User Name heading. The content area displays the user information for the selected user.

NOTE: When any username is selected, both the content area and side navigation bar change. The side navigation bar displays specific menu options for Members and Access Rights (which include Serial, Power and Appliance rights).

3. From the side navigation bar, click Access Rights - Serial or Access Rights - Power to access the screens displaying the fixed access rights and permissions for the selected user.

### NOTE: The Serial and Power screens are read-only and cannot be changed.

- 4. From the side navigation bar, click Access Rights Appliance. The Appliance Access Rights screen appears and lists all access rights available to the user. Available appliance access rights are:
  - View Appliance Information
  - Disconnect Sessions
  - Reboot Appliance
  - Appliance Flash Upgrade and Reboot Appliance
  - Configure Appliance Settings
  - Configure User Accounts
  - Backup/Restore Configuration
  - Shell Access
  - Transfer Files
  - Dial-In Access

### To add new users:

- 1. Click Users Local Accounts User Names. The User Names screen is displayed with a list of all users.
- 2. Click Add. The Local User Information screen is displayed.
- 3. The *Status* is set to *Enabled* by default, but this setting allows an account to be disabled temporarily without deleting it entirely.
- 4. Enter the new username and enter a password, then confirm the password.
- 5. Select or deselect User must change password at the next login checkbox.
- 6. To add the user to an available user group, select the user group name in the box on the left and click *Add* (user is the default group). You can remove a user group from the box at right by selecting it and clicking *Remove.*
- 7. Enter the desired parameters for Password Expiration.
  - Minimum Days: Enter the minimum number of days allowed between password changes. Password changes attempted sooner will be rejected. To disable the restriction on the number of days allowed between password changes, leave this field empty.
  - Maximum Days: Enter the maximum number of days a password is valid. After this period, a password change will be forced. To disable the restriction for the maximum number of days a password is valid, leave this field empty.
  - Inactive Days: Enter the number of days after the password expires before the account is permanently disabled. The default is disabled (-1).
  - Warning Days: Enter the number of days that a warning is issued to the user prior to expiration. Entering O will cause the warning to be issued on the expiration day. To disable the warning, leave this field empty.
- 8. Enter the desired Account Expiration date (YYYY-MM-DD).
- 9. Click Save.

### To configure password rules:

- 1. Click Users Local Accounts Password Rules.
- 2. If password complexity is desired (recommended), make sure Check Password Complexity is selected.
- 3. If password complexity is enabled, enter the desired values for password complexity.
- 4. Enter the desired values for Default Expiration.
- 5. Enter the desired values for Account Lockout.
  - Number of Permitted Failed Attempts: Enter the number of attempts that are allowed to fail before the account is locked. A value of 0 is disabled. The default is 10.

- Account lockout duration after each failed login: Enter the number of minutes that the appliance should block another login attempt after each failed login. The default of 0 is disabled and is recommended. With this value set, a simple mistake will lockout the user for some number of minutes.
- Unlock account after: Enter the desired value in minutes for the account to be locked after the number of Permitted Failed Attempts is exceeded. A value of 0 is disabled. The default is 30 minutes. This is recommended to be used to prevent brute force attacks.
- 6. Check the Use Legacy Password Scheme checkbox if you want the ACS console system to use the legacy admin/avocent and root/linux passwords after a factory default instead of the admin account having a blank password and the root account being disabled.
- 7. Click Save.

### **User groups**

User groups are given access and authorizations either by default or as assigned by an administrator. Administrators can alter the permissions and access rights of users belonging to the appliance-admin or user groups or create additional groups with custom permissions and access rights. Administrators can add, delete or modify permissions and access rights for users from any group at any time.

If an administrator configures the console system to restrict user access to ports, the administrator can assign users to groups that are authorized for port access. The administrator can also authorize groups for power management and data buffer management.

This document and the software refer to users whose accounts are configured on remote authentication servers as remote users. Remote users do not need local accounts.

# NOTE: When a user is removed from all groups, that user's privileges revert to those of the default user group. For this reason, it is recommended custom groups be used and the default user group is not granted additional privileges.

Radius, TACACS+ and LDAP authentication services allow group configuration. If a remote user is configured as a member of a remote group, the authentication server provides the group name to the console system when it authenticates the user. A local group by the same name must also be configured on the console system. If an authentication server authenticates a remote user but does not return a group, then the remote user is, by default, assigned to the user group.

### admin

Members of the admin group have full administrative privileges that cannot be changed. They have the same access and configuration authorizations as the default admin user. Administrators can configure ports, add users and manage power devices connected to the console system.

#### To view admin appliance access rights:

- 1. Click Users Authorization Groups. The Group Names screen is displayed, showing the three default user groups along with any groups that have been created.
- 2 Click on *admin* under the Group Name heading. The content area will display the Members screen listing all members belonging to the admin group (default members are admin and root users).

NOTE: When any Group Name is selected, both the content area and side navigation bar change. The side navigation bar will display specific menu options for Members and Access Rights (which include Serial, Power and Appliance rights).

3. In the side navigation bar, click Access Rights - Serial or Access Rights - Power to access the screens displaying the fixed access rights and permissions for members of the admin group pertaining to serial ports and power management.

### NOTE: The Serial and Power screens are read-only and cannot be changed.

- 4. In the side navigation bar, click on *Access Rights Appliance*. The Appliance Access Rights screen appears and lists all access rights available to a member belonging to the admin group. All appliance access rights are shown enabled (checked). Available appliance access rights are:
  - View Appliance Information
  - Disconnect Sessions
  - Reboot Appliance
  - Appliance Flash Upgrade and Reboot Appliance
  - Configure Appliance Settings
  - Configure User Accounts
  - Backup/Restore Configuration
  - Shell Access
  - Transfer Files
  - Dial-In Access

NOTE: The Appliance Access Rights screen for the admin and appliance-admin user groups is read-only and cannot be changed. Unchecking any box and clicking *Save* will result in an error message. The console system will maintain all rights selected.

### appliance-admin

Appliance-admin user group members have access to the serial ports and power management options, unless that access is restricted by the security profile. Members of the group also share all of the appliance access rights as admin except for Configure User Accounts and Shell Access, which are permanently disabled for this group.

#### user

User group members have access to target devices, unless that access is restricted by an administrator. When a security profile restricts port access globally, an administrator may grant port access to members of the user group. User group members have no access rights for the console system.

Administrators can add appliance access rights and permissions. Administrators can also add users to custom user groups to add permissions and access rights as needed. By default, all selections on the Appliance Access Rights screen will be disabled.

NOTE: The Appliance Access Rights screen for the user group can be changed at any time by an administrator. This will change the access rights for all members of the console system's user group.

#### shell-login-profile

Members of the shell-login-profile group have access to the shell after logging in. By default, the root user belongs to this group. This is not a protected group and can be deleted.

### Managing user groups

Administrators and members of the admin group can create custom user groups that contain any users.

#### To create a custom user group:

- 1. Click Users Authorization Groups. The Groups screen is displayed and contains a list of the three default user groups and any additional custom user groups that have been created.
- 2. Click *Add* in the content area.
- 3. Enter the name of the new user group you are creating.
- 4. Click Save.

#### To add members to a user group:

- 1. Click Users Authorization Groups.
- 2. Click the user group name.
- 3. Click *Add*. The Members Assignment screen is displayed showing a list of available users in the left box and an empty box on the right.
- 4. Move users from the Available Users box on the left to the box on the right by double-clicking on the username, or by selecting the name and clicking the *Add* button. You can remove any names from the box on the right by double-clicking on the name or by selecting the name and clicking the *Remove* button.
- 5. If you want to add remote users to the new user group (these must be valid names in your remote authentication server), add them in the New Remote Users field.
- 6. Click Save.

### To remove members from a user group:

- 1. Click Users Authorization Groups.
- 2. Click the user group name.
- 3. Check the box(es) of the member(s) you want to remove. Click Delete to delete the selected members.

#### To configure a session idle time-out and/or login profile for a group:

- 1. Click Users Authorization Groups.
- 2. Click on the name of the group whose session idle time-out and/or login profile you want to set. In the side navigation bar, click *Login Profile*.
- 3. Select the radio button to use either the global settings for the Session Timeout or to use custom settings for the user group. If using custom settings, enter the custom session timeout (in seconds) in the field.
- 4. Check the Enable Log-In Profile box.
- 5. Click *ts\_menu* to use the ts\_menu application when a member of the selected user group opens a session in the console system. Enter the ts\_menu options in the Options field.

-or-

Click *CLI* to use CLI when opening a session. Enter the CLI command in the CLI cmd field and check the box if you want to exit after executing the command.

6. Click Save.

NOTE: If the user belongs to multiple groups, the login profile used will be the first enabled login profile based on alphabetical order of the group.

### Table 3.19 ts\_menu Options

Command	Description			
-р	Displays TCP port			
-i	Displays local IPv4 assigned to the serial port			
-i6	Displays local IPv6 assigned to the serial port			
-u <name></name>	Username to be used in the target session			
-e <[^]char>	Escape character used to close the target session. Default value: Ctrl-X			
-	Sorted lists ports and exit			
-ro	Read-Only mode			
<portname></portname>	Connect directly to a serial port			
-t	Idle time-out in seconds to choose the target			

### To add access to serial ports for a user group:

- 1. Click Users Authorization Groups.
- 2. Click the new user group name.
- 3. In the side navigation bar, click Access Rights.
- 4. In the content area, click Add.
- 5. To move serial target devices from the Available Target box on the left to the box on the right: double-click on the serial target name.

-or-

Select one or more targets and click Add.

6. To remove targets from the box on the right: double click the serial target name

-or-

Select one or more targets and click Remove.

- 7. Select the desired access rights.
- 8. Click *Save*. The Serial screen will appear and show the serial target devices you have authorized for use by the user group with configured permission(s).
- 9. Edit the access rights by selecting the checkbox next to one or more of the target names in the list as needed and click *Edit*. The Target Access Rights screen is displayed with the access rights. Select the desired access rights and click *Save*.

### To assign PDU access for a user group:

NOTE: Assigning PDU access to a user group gives them full access to all power management functions for that PDU. If you want the user group to have access to outlets only, use the procedure *To assign outlet access for a new custom user group* below.

- 1. Click on Users Authorization Groups.
- 2. Click on the user group name.
- 3. In the side navigation bar, click Access Rights Power.
- 4. In the content area, click *Add*. The PDU Assignment screen appears with the list of available PDUs in the left box.
- 5. Move PDU devices from the Available PDU box on the left to the box on the right by double-clicking on the PDU name, or by selecting the PDU and clicking the *Add* button. You can remove any PDUs from the box on the right by double-clicking on the PDU name or by selecting the PDU and clicking the *Remove* button.

- You can specify a custom PDU ID in the field at bottom and assign it a custom PDU ID.
   NOTE: The custom PDU ID is for assigning user group authorization to manage PDUs that have not yet been connected to the console system.
- 7. Click Save.

#### To assign outlet access for a new custom user group:

NOTE: Assigning outlet access to user groups allows group members to turn outlets on or off, and enable locking and power cycle capabilities on compatible PDUs.

- 1. Click Users Authorization Groups.
- 2. Click on the new user group name.
- 3. In the side navigation bar, click Access Rights Power Outlets.
- 4. Click Add. The Add Outlet screen is displayed.
- 5. For connected PDUs, click the Select PDU button to activate the Connected PDUs and Outlets fields.
- 6. Select Connected PDU from the pull-down menu.
- 7. Enter the outlets assigned to the user group.

NOTE: Outlets can be specified individually, (for example 1, 3, 6, 8) or as a range (for example 1-4) or a combination of both, (for example 1-4, 6, 8 which assigns access to outlets 1, 2, 3, 4, 6 and 8).

- 8. If a custom PDU ID has been created for future use, and you want to pre-assign outlets, click the *Custom* button to enter the custom PDU ID name and specify the outlets.
- 9. Click Save.

#### To assign UPS access for a user group:

- 1. Click Users Authorization Groups.
- 2. Click the user group name.
- 3. From the side navigation bar, click Access Rights Power UPS.
- 4. From the content area, click *Add*. The UPS assignment screen appears with the list of available UPS devices in the left box.
- 5. Move UPS devices from the Available UPS box on the left to the box on the right by double-clicking the UPS name, or by selecting the UPS and clicking *Add*. You can remove any UPS devices from the box on the right by double-clicking the UPS name, or by selecting the UPS and clicking *Remove*.
- You can specify a custom UPS ID in the field at the bottom of the page and assign it a custom UPS ID.
   NOTE: The custom UPS ID is for assigning user group authorization to manage UPS devices that have not yet been connected to the console system.

### To assign appliance access rights for custom user groups:

- 1. Click Users Authorization Groups.
- 2. Click the new user group name.
- 3. In the side navigation bar, click Access Rights Appliance.
- 4. Select the desired appliance access rights and click Save.

#### To configure a group in a TACACS+ authentication server:

- 1. On the server, add raccess service to the user configuration.
- 2. Define which group(s) the user belongs to in the raccess service following this syntax:

group\_name = <Group1>[,<Group2,...,GroupN>];

For example:

In the console system, configure a new authorization group TACACS\_1, and configure the access rights for this group. In the TACACS+ server, configure the user "regina" with the following attribute: raccess = group name=TACACS 1;

Then, configure the user "special" with the following attribute: raccess = group name=admin;

During the authentication phase, the console system will receive the attribute raccess from the TACACS+ server. The user regina belongs to the authorization group TACACS\_1 and the user special belongs to the authorization group admin.

#### To configure a group in a RADIUS authentication server:

Define which group(s) the user belongs to in the attribute FRAMED\_FILTER\_ID with the following syntax:

[:group\_name=]<acs800/8000\_group1>[,<acs800/8000\_group2>];

#### NOTE: The group names should be separated by a comma and end with a semi-colon.

#### NOTE: The ACS800/8000 console system accepts multiple FRAMED\_FILTER\_ID attributes.

For example:

In the console system, configure new authorization groups RADIUS\_1 and RADIUS\_2, and configure the access rights for these groups. In the Radius server, configure the user regina with the following attribute:

```
FramedFilterID = group_name=RADIUS_1,RADIUS_2;
```

-or-

```
FramedFilterID = RADIUS 1, RADIUS 2;
```

-or-

```
FramedFilterID = RADIUS_1;
FramedFilterID += RADIUS 2;
```

Then, configure the user special with the following attribute:

FramedFilterID = group\_name=admin;

During the authentication phase, the console system will receive the attribute FramedFilterID from the RADIUS server. The user regina belongs to authorization group RADIUS\_1 and RADIUS\_2 and the user special belongs to authorization group admin.

### To configure a group in an LDAP authentication server:

On the LDAP server, edit the info attribute for the user and add the following syntax.

info: group name=<Group1>[,<Group2>,...,<GroupN>];

### Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView software access rights

An administrator can configure how the Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView software's viewer session rights will be mapped to the console system's access rights when a user accesses a target via the Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView software's serial viewer.

#### To configure the map of Vertiv™ Avocent® DSView software access rights to console system access rights:

- 1. Click Users Authorization DSView Access Rights.
- 2. Select the desired access rights and click Save.

### 3.3.12 Events and logs

The console system will generate notifications for a variety of events. You can configure the console system to direct or store those event notifications to various destinations for immediate use or for analysis later.

### **Event list**

The Event List screen lists console system events, each of which can be configured for SNMP Traps, Syslog, DSView, Email and SMS.

#### To configure Events:

- 1. Click Events and Logs Events.
- 2. Locate the events for which you want notification sent and select the checkbox(es) next to the event number(s).
- 3. Click Edit.
- 4. If you want an event notification sent for any configured event destination type, click its associated Send checkbox.
- 5. Click *Save*. The Events page appears with a checkmark in the column below the destination type if the Send box was checked on the Events Settings screen.

### **Event destinations**

#### To configure event destinations:

- 1. Click on Event and Logs Event Destinations.
- 2. Under the Syslog heading, use the drop-down menu to select the Facility.

Select *Remote Server - IPv4* to enable syslog messages to be sent to one or more remote IPv4 syslog servers and enter the IPv4 Address or Hostname and the UDP port for each remote syslog server.

-or-

Select *Remote Server - IPv6* to enable syslog messages to be sent to one or more remote IPv6 syslog servers and enter the IPv6 Address or Hostname and the UDP port for each remote syslog server.

- 3. Select Appliance Console to send messages to the console system's console.
- 4. Select Root Session to send syslog messages to all sessions where you are logged in as root user.

- 5. Under the SNMP Trap heading, choose the version of SNMP. If SNMPv1/v2c is selected, enter the name of the community defined in one or more of the SNMP trap servers in the Community field. If SNMPv3 is selected, choose an SNMPv3 user name from the pulldown list. (SNMPv3 users may be added on the *Network SNMP* page.) Enter the IP addresses of up to five servers in the server fields.
- 6. Under the SMS heading, enter the SMS Server, Port and Pager Number information in the appropriate fields.
- 7. Under the Email heading, enter the Server, Port and Destination Email information in the appropriate fields.
- Under the DSView heading, enter the IP address of the Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView server where event notifications will be sent in the Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView server field. Enter the syslog server port number for the Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView server, the SSH information and the buffer warning information in the appropriate fields.
- 9. Click Save.

### Trap forward

The console system will receive SNMP traps and forward them to a remote SNMP trap server.

#### To add a SNMP trap server to forward traps:

- 1. Click Events and Logs Trap Forward.
- 2. Click Add.
- 3. Enter the IP address of the remote server and the UDP port.
- 4. Enter the OID to filter traps to send to this server (optional).

#### To edit SNMP trap server configuration:

- 1. Click Events and Logs Trap Forward.
- 2. Click the index of the server to be edited.
- 3. Update the UDP port and/or the OID and click Save.

### Data buffering

When data buffering is enabled on one or more serial ports, the settings on the Events and Logs - Data Buffering page apply to the type (destination) of the buffering. Segment size, which is specified in kilobytes, determines the size of each data buffering file saved. Spare segments determine how many additional historical buffering files of segment size are retained and named with suffix .1, .2 etc.

#### To configure data buffering:

- 1. Select Events and Logs Data Buffering.
- 2. Enter the segment size in kilobytes and spare segments in the Local Data Buffering Settings section.
- 3. In the NFS Data Buffering Settings section, enter the following information: NFS Server, NFS Path, Segment Size (Kbytes) and Spare Segments.

# NOTE: RPC service must be enabled in the Security Profile screen before configuring NFS Data Buffering Settings.

- 4. To segment data buffering files every day based in hour, enter the time in the Close Log Files and Open New Ones at Time (HH:MM) field. This will be valid for local and NFS data buffering.
- 5. To configure data buffer storage on a syslog server in the Syslog Data Buffering Settings section, select a facility number from the drop-down menu: *Log Local 0, Log Local 1, Log Local 2, Log Local 3, Log Local 4 or Log Local 5.*
- 6. Click Save.

#### To enable data buffering:

- 1. Select Ports Serial Ports.
- 2. Click on the port where you want to enable data buffering.
- 3. Under the Data Buffering tab, use the drop-down menu next to Status to Enable data buffering.

NOTE: Local data buffering files are written to the /mnt/hdUser/db directory using the port name as the filename.

### **Appliance logging**

When Appliance Logging is enabled, the commands (input) and output from SSH and Telnet sessions to the appliance are recorded for auditing purposes.

#### To configure appliance logging:

- 1. Click Enable appliance session data logging.
- 2. Select the destination for appliance session data logs from the pull-down menu. Choices are *Local*, *NFS*, *Syslog* and *DSView*.
  - a. If using local as the destination, use the drop-down menu to select the local destination. Destination *mmcblk0* is the built-in flash storage. SD card (if present and enabled) is *mmcblk1*. USB devices (if present and enabled) are *sda1*, *sda2* and so on.

# NOTE: When the local destination is mmcblk0, the logging directory on the appliance is /mnt/hdUser/db. When the local destination is mmcblk1 or a USB device the logging directory is the top (root) directory of that device.

- 3. Enable or disable timestamping the appliance session data logs.
- 4. Click Enable appliance session data logging alerts.
- 5. Enter the desired alert strings (up to ten) in the fields provided.
- 6. Click Save.

#### Sensors

The console system contains an internal sensor to monitor the board temperature. See Sensors on page 75.

### 3.3.13 Power management

Connected power devices can be used for remote power management. The console system enables users who are authorized for power management to turn power on, turn power off and reset devices that are plugged into a connected PDU. Authorized users can also monitor and control the following Uninterruptible Power Supply (UPS) devices: Vertiv<sup>™</sup> Liebert<sup>®</sup> GXT4 or GXT5.

The following types of PDUs can be connected to any serial port.

- Vertiv™ Geist™ Rack Power Distribution Units (rPDUs). Up to nine PDUs may be chained together and managed from a single serial port.
- Vertiv™ Geist™ Rack Transfer Switch (RTS).
- Vertiv<sup>™</sup> MPH2 Rack Power Distribution Units (PDUs) as well as Vertiv<sup>™</sup> MPX and MPH rack PDUs with RPC2 cards installed.
- Avocent<sup>®</sup> Power Management Power Distribution Unit (PM PDU).
- Cyclades PM Intelligent Power Distribution Units (IPDUs) With Cyclades PM IPDUs, up to 128 outlets can be daisy-chained and managed from a single serial port.
- Avocent<sup>®</sup> SPC power control devices.

- Server Technology CDU Series Rack PDUs. One additional level of power devices can be daisy-chained with ServerTech expansion units.
- Server Technology PRO1 and PRO2 Series PDUs. One additional level of power devices can be daisy-chained with ServerTech expansion units.
- Server Technology PRO3X Series Rack PDUs.
- Eaton ePDU G3 PDUs. Up to eight ePDUs can be chained together and managed from a single serial port.
- Raritan PX G2 PDUs.
- APC rPDU/rPDU2 PDUs.

#### NOTE: The term PDU refers to any of these types of power devices.

The console system automatically recognizes and supports the PDU device types listed above when the corresponding serial port is configured for power management.

NOTE: The login credentials for each supported PDU type must be entered on the Power Management – Login page before the PDU is connected.

#### PDUs

#### To manage a PDU:

- 1. Select Power Management PDUs.
- 2. Select the checkbox next to the PDU you want to manage.
- 3. Click On, Off, Cycle, Reboot PDU, Reset HW Overcurrent Protection or Factory Defaults if desired. A confirmation appears. Click OK.

#### NOTE: The power controls (On, Off and Cycle) will be applied to all outlets of the PDU.

- 4. To change the PDU ID, click Rename and enter the name in the New PDU ID field.
- 5. Click Save.
- 6. To rediscover a connected PDU, for instance to detect newly attached sensors, select the PDU and click Refresh.

#### To upgrade firmware:

- 1. Select the checkbox next to the PDU you want to upgrade and click the Upgrade Firmware button.
- 2. Select Remote Site and enter the remote server information.

-or-

Select *My Computer* and browse to the location where you saved the firmware file.

- 3. Click Download to download the firmware to the console system.
- 4. When the download finishes, the console system displays the current and downloaded firmware versions. If the downloaded version information is correct, click *Upgrade Now* to start the upgrade of the firmware in the PDU.
- 5. Once the upgrade has started, click *Finish*. A message stating the upgrade has successfully started will display. The PDU Overview page displays the upgrade status. The PDU reboots when the upgrade is complete.

#### To view a PDU's information and manage outlets:

- 1. Select Power Management PDUs.
- 2. Click the name of the PDU you want to view or manage.
- 3. The Outlet Table with power controls window appears and the side navigation bar displays a list of options.
- 4. To manage outlets of PDU:
  - a. Check the box(es) of the outlet number(s) you want to manage.
  - b. Click On, Off, Cycle, Lock or Unlock to perform that function for the selected outlet(s).

- 5. Click Information in the side navigation bar to view a PDU's information.
- 6. Click Overview in the side navigation bar to view data monitoring information.
- 7. Click *Current, Voltage, Power Consumption, Energy Consumption* or *Environment* in the side navigation bar to view a table with appropriate information. Click *Reset Values* to clear Max, Min and Average values.
- 8. For a Vertiv<sup>™</sup> Geist<sup>™</sup> RTS, click *Inlets* to view information about the power sources.

#### To configure a PDU:

- 1. Click *Settings* to expand the side navigation bar.
- 2. Click Outlets.
- 3. Click on an outlet number to change its settings. Click Save, then click Close.

-or-

Check two or more boxes next to the outlets for which you want to change settings. Click *Edit* to change the settings for the outlets you selected. Click *Save*.

- 4. Click PDU to view and configure PDU settings. Click Save when finished.
- 5. Click Phases or Banks.
  - a. Click on the name of a phase or bank to change its settings, or click one or more boxes next to the phase (s) or bank(s) you want to change.
  - b. Click Save to save the settings and click Close to return to the Phase screen.

#### NOTE: The PDU model type determines the available parameters in the Settings window.

6. For a Vertiv<sup>™</sup> Geist<sup>™</sup> RTS, click *RTS* to configure the Transfer settings.

#### UPS

The following types of UPS devices can be connected to any serial port:

- Vertiv<sup>™</sup> Liebert<sup>®</sup> GXT4
- Vertiv<sup>™</sup> Liebert<sup>®</sup> GXT5

#### To manage a UPS:

- 1. Select Power Management UPS.
- 2. Select the checkbox next to the UPS you want to manage.
- 3. Click *Turn Output Off, Turn Output On,* or *Cycle Output* if desired. An option appears to insert the desired delay time before the operation is performed. Click the button to perform the operation.
- 4. To change the UPS ID, click *Rename* and enter the name in the New UPS ID field.
- 5. Click Save.

#### To view a UPS device's information:

- 1. Select Power Management UPS.
- 2. Click the name of the UPS you want to view or manage.
- 3. Click the options in the side navigation bar to view UPS information.

#### To configure a UPS:

- 1. Click Settings to expand the side navigation bar.
- 2. Click on the options in the side navigation bar to configure the UPS.

### Login

An administrator can change the login password for a supported PDU type. This password is used by the console system to communicate with the PDU. (Only one password is supported for all PDUs of the same type.)

#### To change a PDU password:

- 1. Select Power Management Login.
- 2. Enter the new password for each type of PDU you want to change.
- 3. Click Save.

### **Outlet groups**

By selecting the *Outlet Groups* tab, you can view status, outlet and power consumption for outlet groups, as well as configure them. You can also turn on, turn off or cycle selected outlet groups.

#### To manage outlet groups:

- 1. Select Power Management Outlet Groups.
- 2. Check the box next to the name of the Outlet Group you want to manage.
- 3. Click the On, Off or Cycle radio button, if desired.

-or-

- 4. Click Add to add an outlet group. The Add Group screen appears. Enter the name in the Group Name field.
- 5. Click Save.

#### To view and change outlet group information:

- 1. Select Power Management Outlet Groups.
- 2. Click the name of the outlet group you want to view or manage.
- 3. To add outlets, click *Add* to add a new outlet to the group. Fill the fields and click *Save* to return to the Outlet Group Details table.
- 4. To delete outlets, check one or more boxes next to the outlet(s) you want to remove from the group. Click *Delete*, then click *Close* when finished.

### **Network PDUs**

Power devices connected to the network with SNMP (read/write) enabled can be used for remote power management. The console system enables authorized users to turn power on and turn power off in devices that are plugged into the network PDU.

#### NOTE: SNMP must be enabled and have one community with write permission enabled in the PDU.

By selecting the Network PDUs node, an administrator can add new Network PDUs or edit configuration of current ones.

The following functionalities are supported for Network PDUs: Power Control (turn on, turn off and cycle/reboot) outlets, rename the PDU and rename the outlets. Additional functionality, including monitoring and firmware upgrade, is available for some PDU types, such as Geist (including Vertiv<sup>™</sup> Geist<sup>™</sup> RTSes), Vertiv and Server Technology.

#### To add a network PDU:

- 1. Select Power Management Network PDUs.
- 2. Click Add.
- 3. Enter the IP address of the network PDU.
- 4. Select the PDU type.
- 5. Enter the interval to poll the PDU for the status of the outlets.

6. Enter the SNMP community name that has write permission in the PDU.

### **Network UPS**

The console system supports the following devices with an installed Vertiv™ Liebert® Intellislot™ Unity card:

- Vertiv<sup>™</sup> Liebert<sup>®</sup> GXT4 devices
- Vertiv<sup>™</sup> Liebert<sup>®</sup> PSI5 UPSes
- Vertiv<sup>™</sup> Liebert<sup>®</sup> APS UPSes
- Vertiv<sup>™</sup> Liebert<sup>®</sup> iCOM<sup>™</sup> Edge devices

The console system supports Vertiv<sup>™</sup> Liebert<sup>®</sup> GXT5 UPS devices with an installed Vertiv<sup>™</sup> Liebert<sup>®</sup> Intellislot<sup>™</sup> RDU101 Communications card.

These devices, connected to the network with SNMP (read/write) enabled, may be monitored and controlled. The console system enables authorized users to monitor battery information, system input and output information, and to control output receptacles.

#### NOTE: SNMP must be enabled and have one community with write permission enabled in the UPS communications card.

By selecting the Network UPS node, an administrator can add new network UPS devices or edit the configuration of current ones.

# 3.3.14 Sensors

### Internal

The console system has sensors that monitor the internal temperature. You can specify an operating range for the console system that fits its environment. There are two internal temperature sensors that can generate event notifications: the CPU temperature sensor and the Board temperature sensor.

# CAUTION: Do not use values that exceed the maximum and minimum temperatures. See Appendix A for more information.

#### To configure the temperature sensors:

- 1. Click Sensors Appliance Internal to open the Internal page displaying both the CPU and Board temperature sensors.
- 2. In the Maximum Temperature field for either the CPU or Board temperature sensor, enter the temperature in degrees Celsius that, if exceeded, will generate an event notification.
- 3. In the Maximum Temperature Threshold field for either the CPU or Board temperature sensor, enter the temperature threshold in degrees Celsius below the maximum temperature.

NOTE: The Maximum Temperature Threshold field will define a region around the maximum temperature. When the temperature exceeds the Maximum Temperature plus Threshold, an event notification will be generated. When the temperature falls below the Maximum Temperature minus Threshold, an even notification that the console system has returned to normal operating temperature will be generated. This is also true for setting the minimum temperature threshold.

- 4. In the Minimum Temperature field, enter the temperature in degrees Celsius that, if the console system's temperature falls below, will generate an event notification.
- 5. In the Minimum Temperature Threshold field, enter the temperature threshold in degrees Celsius above the minimum temperature.
- 6. Click Save.

#### 1-Wire external sensors

An external 1-Wire sensor can be connected to the SENSOR port on the front of the console system with a CAT 5 cable. By default, 1-Wire sensor support is enabled. It can be disabled via the Security Profile page.

Multiple 1-Wire sensors can be daisy chained together and connected to the console system if the individual sensors provide a second chaining port.

#### To configure a 1-wire sensor:

From the side navigation bar, click Sensors - Appliance - 1-Wire. Detected sensors display in a table with the sensor type and present value information.

NOTE: This option appears for all console system models, even though some models do not have a SENSOR port. If your model does not have a SENSOR port, leave this option disabled.

NOTE: If a connected sensor does not display, click Update List to refresh the page.

NOTE: Sensor configuration options are dependent on the sensor type. Sensors have common configuration settings for Name and Location.

#### Contact sensors (SN-2D/SN-3C)

This sensor type can generate an event notification when one of their inputs change state. An input can be *Disabled, Alarm* when open or *Alarm* when closed.

#### **External temperature**

This sensor type can generate an event notification when the temperature crosses a user-defined threshold. The measurement unit can be configured as *Celsius* or *Fahrenheit*. The thresholds for Low Warning, Low Critical, High Warning or High Critical must be set to allow event generation. Additionally, the alarm state must be set to *Enabled* to generate an alert.

#### **External humidity**

This sensor type can generate an event notification when the humidity crosses a user-defined threshold. The thresholds for Low Warning, Low Critical, High Warning, or High Critical must be set to allow event generation. Additionally, the alarm state must be set to *Enabled* to generate an alert.

#### **Differential pressure (SN-DP)**

This sensor type can generate an event notification when the differential pressure crosses a user-defined threshold. The thresholds for Low Warning, Low Critical, High Warning, or High Critical must be set to allow event generation. Additionally, the alarm state must be set to *Enabled* to generate an alert.

#### Leak sensor (SN-L)

This sensor type can generate two types of alarms: a leak alarm, which occurs when a leak is detected; and a cable fail alarm, which occurs when a cabling connection problem is detected. One configuration parameter is the Filter Time (seconds). This is the time, in seconds, the leak must persist before an event is generated.

### **Digital In sensors**

External Digital In sensors can be connected to the DIGITAL IN port on the front of the console system with a CAT 5 cable. The RJ45 connector contains four digital in signals and has the following pinout:

#### Table 3.20 Digital In RJ45 Pin-Out

Pin No.	Signal Name
1	12V @ 0.5A
2	Not Used
3	Digital In #1
4	GND
5	GND
6	Digital In #2
7	Digital In #3
8	Digital In #4

The four digital inputs are intended for use with dry-contact type switches such as motion, door, smoke or leak sensors.

The console system outputs a 12V signal to the device, and if the device is "closed" then the 12V signal is returned to the console system on the appropriate Digital In pin. The console system then reports this status as open or closed in the UI.

A single sensor, such as a Liebert AD-S or AD-IM, can be plugged directly into the Digital In port. The sensor will appear as one of the 4 digital inputs based on which hardcoded pin the sensor uses for its output signal (3, 6, 7 or 8). Up to four sensors can be supported by splitting out the wires from the RJ45 Digital In port and wiring 12V, GND, and one of the Digital In pins to each individual sensor.

#### To configure a Digital In sensor:

- 1. From the side navigation bar, click Sensors Appliance Digital In. Detected digital inputs display in a table.
- 2. Click the number associated with the position of the sensor to open the settings page.
- 3. Enter the name and location of the sensor and use the drop-down menu to select the sensor type.
- 4. A Digital In sensor can be configured to generate an event by configuring the Alarm parameter. Use the dropdown menu to select *Alarm when open*, *Alarm when closed* or *Disabled*.

NOTE: This option appears for all console system models, even though some models do not have a DIGITAL IN port. If your model does not have a DIGITAL IN port, leave this option disabled.

#### **Digital Out sensors**

The ACS800 advanced console system supports two digital outputs. The digital outputs are remote-controlled relay ports that can be used to open or close an electric circuit.

Looking at the Digital Out port on the front of the appliance, the four pins of the green connector form two switches. Switch 1 (Position 1) uses the two pins on the left and Switch 2 (Position 2) uses the two pins on the right.

Each of the two Digital Out ports work as a simple switch that is either open or closed. By default, on power up, the switch will be open (Off).

The internal relays support a maximum current of 12A and a maximum voltage of 300V.

#### NOTE: Digital outputs are not supported on the ACS8000 advanced console system.

#### To configure a Digital Out sensor:

- 1. From the side navigation bar, click Digital Out.
- 2. Click the number associated with the position of the sensor to open the settings page.
- 3. If desired, enter a name for the sensor.
- 4. Use the drop-down menu to turn ON or OFF an electric circuit, then click Save.

# 3.3.15 Active sessions

The console system allows multiple users to log in and run sessions simultaneously. The active sessions feature allows you to view all active sessions and kill any unwanted sessions. Click *Active Sessions* to view all open sessions on the console system.

NOTE: If you start another session with the console system while viewing this screen, it will not be visible until you click *Refresh* at the top of the web UI window.

#### To kill an active session:

- 1. Click *Active Sessions*. The Active Sessions screen appears and lists all open sessions to the console system by the user's workstation IP.
- 2. Select the checkbox next to the session you want to kill, then click the *Kill* button. After a few seconds, the Active Session screen will redisplay the open sessions, minus the one you killed.

# 3.3.16 Monitoring

When you click *Monitoring*, a variety of network and console port information is available for viewing. The following table shows the types of information available.

Screen Name	Definition	
Network - Devices	Shows Ethernet ports and USB network adaptor, Status (enabled/disabled), IPv4 Address, IPv4 Mask, IPv6 Address and Link Status (up/down).	
Network - IPv4 Routing Table	Shows Destination, Gateway, Genmask, Flags, Metric, Ref, Use and Iface (interface).	
Network - IPv6 Routing Table	Shows Destination, NextHop, Flags, Metric, Ref, Use and Iface (interface).	
Serial Ports	Shows Device Name, Profile, Settings, Target, Signals, TX Bytes, RX Bytes, Frame Error, Parity Error, Break and Overrun. The Reset Counter button allows administrators to reset the statistic counters for selected ports. Not all USB console port devices report statistics.	
Scheduled Tasks	Shows the current scheduled tasks including name, status, task type, schedule, last run time and last result. Allows an administrator to add, delete, enable, disable and run individual tasks.	
FIPS Mode	Shows Service Name and Mode Indication.	
Zero-touch Log	Shows the Zero-touch Provisioning log file and allows an administrator to clear it or export it.	
Caller ID Log	Shows the last 20 calls and allows an administrator to clear it or export it.	
Modem PPPD Log	Shows the most recent entries in the Modem PPPD Log and allows an administrator to clear it or export it.	
IPSec Tunnel Status	Shows the IPSec connection details including connection name, status, remote IP address, remote subnet, local IP address, local virtual IP address and established time. Allows an administrator to connect or disconnect individual connections.	
Auto Discovery Status	Shows the status of auto discovery for any serial ports that have Auto Discovery enabled. Shows the port, type of discovery, and resulting name. Allows an administrator to view the detailed log file for a port and export it.	

#### Table 3.21 Monitoring Screens

# 3.3.17 Change password

An administrator or user can change their own password from this screen.

#### To change your own password:

- 1. Select Change Password.
- 2. Enter the old password and new password in the appropriate fields.
- 3. Confirm the new password, then click Save.

# 3.4 Web UI Overview for Regular Users

A regular (non admin) user has limited access by default, as shown in the table below. The access rights are determined according to the individual username or by the "user" group as a whole and can be changed by an administrator to grant a regular user more or less rights.

#### Table 3.22 Web UI Options for Regular Users

Menu Option	Description
Access	Displays all the devices the user can access. Click on Serial Viewer in a device's Action column to launch a terminal session with that device.
Power Management PDUs Outlet Groups	Click <i>PDUs</i> to turn on, turn off, cycle, reboot, reset the HW overcurrent protection, return to factory defaults or rename PDUs connected to the console system. Click <i>Outlet Groups</i> to manage groups of outlets on connected PDUs. Click <i>UPS</i> to monitor and control connected UPS devices.
Monitoring – Serial Ports	Shows Device Name, Profile, Settings, Target, Signals, TX Bytes, RX Bytes, Frame Error, Parity Error, Break and Overrun. The Reset Counters button allows administrators to reset the statistic counters for selected ports.
Change Password Change your own password.	

# 3.5 Scheduled Tasks

The console system allows the user to schedule certain tasks to be run on the console system at regular intervals. This includes various built-in tasks that the user can choose from, as well as the ability to run a script of their own that the user has copied to the console system's file system.

Scheduled Tasks are monitored and scheduled via the Scheduled Tasks page underneath the Monitoring folder of the Web UI.

#### To add a Scheduled Task:

- 1. Click Monitoring Scheduled Tasks.
- 2. Click the Add button.
- 3. Choose one of the built-in tasks or choose Custom to create a new task that executes your own script.
  - a. Different tasks may have different parameters to configure.
  - b. The built-in tasks vary depending on the model of console system and the features it includes (modems, etc).
- 4. Enter a task name of your choosing for the task.
- 5. The Status defaults to Enabled, but tasks can be temporarily disabled without deleting them completely by changing the status at a later time.
- 6. Choose the desired Frequency for running the task.
  - a. Hourly tasks are run at the Time specified, ignoring the HH: portion of the time.
  - b. Daily tasks are run at the Time specified.
  - c. Weekly tasks allow for specifying the day of the week.
  - d. Monthly tasks allow for specifying the date of the month.
- 7. Enter the time for running the task in HH:MM format where HH 24-hour notation between 0 and 23.

- 8. For a Custom script, enter the full command line including any necessary arguments required to run your script or utility.
- 9. Click Save to save the new task.

The Monitoring - Scheduled Tasks page shows a table of all the tasks on the system.

The table includes the task name, status (enabled/disabled), task type, scheduled, last run time (if any), and last result.

From this list, you can also delete, enable and disable individual tasks or multiple tasks selected by checking one or more of the checkboxes.

One or more tasks can be run instantly (instead of waiting for their scheduled time) by selecting one or more checkboxes and clicking the *Run Now* button. After running the test, the UI page may need to be refreshed in order to see the results. Use the *Refresh* button in the top right of the UI.

Last Result will report "Not Attempted" if the task has not yet run, otherwise it will report a Succeeded or Failed message based on the task run.

#### To edit a Scheduled Task:

- 1. Click Monitoring Scheduled Tasks.
- 2. Click the individual task's name in the *Task Name* column. The name is a link that is typically shown in blue and underlined.
- 3. Make any desired changes.
  - a. The *Task Name* and *Type* are not changeable once the task has been created. To change either of these, the task must be deleted and re-created.
- 4. Click Save to save any changes or click Close to exit without changing anything.

#### **Cell Modem IP Test**

This task type tests to make sure that the internal cellular modem has internet connectivity. This task can only run when the cellular modem is not already in use. It is meant to provide a way to verify that the cellular connection will work if it is needed for failover.

The IP Address option specifies the IP address that the ACS8000 console system will attempt to communicate with over the cellular link. This IP address must not be on either LAN that is connected to the ACS console system LAN ports.

When the task runs, it will first check to make sure that the modem isn't already in use and that the network isn't already in failover mode.

The task will bring up the cellular modem interface, temporarily modify the routing table to force the IP Address being tested to go over the cellular interface, and then attempt to contact that IP address using the ping mechanism. After the connectivity is checked, the task will undo the routing table change and return the task results.

The result will be one of the following strings:

- Succeeded The test ran and was successfully able to communicate with the specified IP address.
- Failed: No connectivity The test ran but did not get a successful response from the IP address.
- Failed: Modem is in use The test did not run because the modem is in use.
- Failed: Failover is active The test did not run because the network is in failover.
- Failed: Interface not up The test was not able to bring the modem interface up.
- Failed: Invalid argument Script was invoked incorrectly.
- Failed: Unknown error Other error encountered while running script.

SNMP can be used to monitor the results of the Cell Modem IP Test by reading the following objects:

- acsModemsTableCellTestLastStarted (.1.3.6.1.4.1.10418.26.2.8.2.1.36) reports the timestamp of the last time the Cell Modem IP Test started running.
- acsModemsTableCellTestLastResult (.1.3.6.1.4.1.10418.26.2.8.2.1.37) reports the result of the last time the Cell Modem IP Test was run.

#### **Cell Modem Signal Check**

This task type attempts to check the signal quality of the internal cellular modem.

If successful, the Last Result should show "Succeeded:" followed by the result of the signal check.

The signal check result for a successful test will be similar to "Succeeded: 6 of 7 bars, -83 dBm".

The signal check result may be "Succeeded: Unknown, BitErrRate Unknown" if the test was able to run but couldn't determine signal quality.

If the signal check fails to run, the result will be "Failed: 1."

#### Save Config CLI

This task type saves the current ACS8000 console system configuration in CLI format to the /mnt/hdUser partition in the backup directory. The task can take a minute or two to run depending on the appliance.

If successful, the Last Result will show something like:

"Succeeded. File: /mnt/hdUser/backup/cliconf\_20210428\_184649.cli"

If the task fails, it will report "Failed: #" with an error code number following it.

This is meant mostly as an example of what kind of task is possible. Saving configs to the /mnt/hdUser partition requires the admin to go in and remove the old configs periodically or they will eventually fill up the file system.

#### Custom

The Custom task type allows the user to run their own script as a scheduled task. The Script field contains the full command line required to run the script.

If the Script field doesn't start with a "/" character, then it is assumed that the script is located in the /etc/task\_scripts directory. Scripts located in this directory will be saved as part of the compressed configuration of the ACS appliance.

The script can be located anywhere in the system including the /mnt/hdUser partition as long as the full path to the script is specified in the Script field.

The Script field should also contain any necessary arguments for the script.

Custom tasks will generate the same three events as other scheduled tasks. The determination to generate the Failed event is based on the return status of the script. A return status of 0 is considered a success. Anything else is considered failure and the return status will be reported as part of the Result in the Failed message.

If the return status of the script indicates success, then the result string will be "Succeeded: " followed by up to 256 characters of output that the script wrote to stdout. On failure, the result string will be "Failed: #" where the "#" is the non-zero exit code status returned by the script.

An example script is located at /etc/task\_scripts/example.sh.

#### Events

Three events are used by the Scheduled Tasks:

- 140 Scheduled Task Started which reports the task name.
- 141 Scheduled Task Completed which reports the task name and result.
- 141 Scheduled Task Failed which reports the task name and result.

As with other events, the user can decide whether to enable or disable individual events and can generate traps, send the events to Syslog, the Vertiv™ Avocent® DSView software, email or SMS. By default, these three events are only set to send messages to Syslog.

# 3.6 Diagnostics

The console system provides some diagnostic capability to help with debugging problems in the system.

#### To access the Diagnostics page:

- 1. Click System Tools Diagnostics.
- 2 Use the radio button to select the desired diagnostic option.

- 3. Select any required options.
- 4. Click Run to execute the diagnostic procedure or start one that continues to run in the background.
- 5. Click Stop to stop execution of a procedure that runs in the background.
- 6. Click *Export* to save the associated output file to your client computer.

#### **Debug Dump**

This utility captures a lot of information on the state of the appliance, as well as the current configuration in CLI script format, at the time that it is run.

It can be exported as ACSExport\_dbgdump.log.

#### **Debug Monitor**

This process runs in the background and captures the state of the appliance at regular intervals. This should only be used when debugging a problem that occurs over time as it can impact the performance of the system.

This process writes the state into a log file every 5 minutes and keeps the four most recent log files.

When it is first enabled, a copy of the initial state of the appliance is written to a base log file (similar to Debug Dump but with no configuration information).

All five of these log files can be exported as a combined zip file named ACSExport\_dbgmon.zip.

#### Debug USB

This procedure helps to debug problems with USB device enumeration. Prior to starting the procedure, the USB device being debugged should be unplugged from the system.

#### To gather debugging information for the USB:

- 1. Select Debug USB and click Run to start the procedure. This enables additional USB level debug logging.
- 2. Click *OK* when the dialog box prompts you, then insert the USB device. The dialog box disappears and the screen returns to the Diagnostics page with further instructions in red.
- 3. The enumeration process takes several seconds. After it has completed, click Stop.

The system will disable the additional debug logging and create a log file of all the gathered information.

The log file can be exported as ACSExport\_dbgUsb.log.

#### Debug IPSec

This option controls the level of debug for various IPSec subsystems.

#### To change the debug logging level:

- 1. Use the drop-down menus to choose the desired options and click *Run*. This will restart the IPSec process with the new debug levels.
- 2. To restore the debug levels to their default settings and restart the IPSec process, click Stop.

The IPSec log file can be exported as ACSExport\_ipsec.log.

#### **Enhanced Debug Logging**

The console system writes internal logging information and events to the /var/log/dlog.log file. Selecting this option allows the user to turn on additional logging information for certain subsystems.

#### To configure the Enhanced Debug Logging option:

- 1. Select the Enhanced Debug Logging radio button.
- 2. Select or deselect the desired additional logging options.
- 3. Click *Run* to apply the changes.

The logging file can be exported as ACSExport\_dlog.log.

This page intentionally left blank

# Appendices

# **Appendix A: Technical Specifications**

#### Table A.1 Technical Specifications for the ACS8000 Advanced Console System Hardware

Category	Value	
General Information		
CPU	Dual Core ARM Cortex-A9 @ 766MHz	
Memory	1GB DDR3L / 16GB eMMC FLASH	
	Two dual media 1000Base-TX Copper/1Gbps SFP Fiber ports	
	• Up to 48 serial ports with autosensing and switching support of Cyclades and Cisco pinouts	
	• Two of the serial ports support RS232/422/485 multi-protocol with autosensing and switching support of Cyclades and Cisco pinouts in RS232 mode	
	One serial console port	
Interfaces	• Eight USB 2.0 host ports (front ports not available on some models)	
	One SD card slot (not available on some models)	
	Optional V.92/56K analog MODEM port or Cellular MODEM	
	• 1-Wire interface for external sensors (not available on some models)	
	• Single RJ45 connector with four digital-in ports for external contact closure sensors (not available on some models)	
Power Information	·	
Power Supply	Internal 100-240 VAC, 50/60 Hz Optional Dual entry, redundant power supplies-48 VDC option available	
Power Consumption	Nominal voltage 120 VAC: Typical 0.17A, 20W, Maximum 0.25A, 30W Nominal voltage 230 VAC: Typical 0.1 A, 23 W, Maximum 0.15A, 35W Nominal voltage -48 VDC (20% tolerance) Typical 0.5 A	
Ambient Atmospheric	Condition Ratings	
Operating Temperature	32 °F to 122°F (0° C to 50°C) (DC powered units) 14°F to 158°F (-10° C to 70°C) (AC powered units)	
Storage Temperature	-4°F to 158°F (-20°C to 70°C)	
Humidity	20% to 80% relative humidity (non-condensing) across the operating temperature range	
Dimensions		
Height x Width x Depth	1.7 x 17.1 x 9.5 in (4.318 x 43.434 x 24.13 cm)	
Weight	6-7 pounds (2.722- 3.175 kg) depending on the model	

Category	Value	
General Information		
CPU	Dual Core ARM Cortex-A9 @ 766 MHz	
Memory	1GB DDR3L / 16GB eMMC FLASH	
	Two dual media 1000Base-TX Copper ports	
	• Up to eight serial ports with autosensing and switching support of Cyclades and Cisco pinouts	
	• All serial ports support RS232/422/485 multi-protocol with autosensing and switching support of Cyclades and Cisco pinouts in RS232 mode	
	One serial console port	
Interfaces	Four USB 20 host ports	
	• V.92/56K analog MODEM port	
	• 1-Wire interface for external sensors	
	Single RJ45 connector with four digital inputs for contact closure sensors	
	Digital output connectors providing four output signals.	
Power Information		
Power Supply	Internal 100-240 VAC, 50/60 Hz	
Power Consumption	Nominal voltage 120 VAC: Typical 80.5mA/3.5W, Maximum 306mA/17W Nominal voltage 240VAC: Typical 60mA/3.75W, Maximum 191mA/17W	
Ambient Atmospheric (	Condition Ratings	
Operating Temperature	-4°F to 158°F (-20°C to 70°C)	
Storage Temperature	-4°F to 158°F (-20°C to 70°C)	
Humidity	20% to 80% relative humidity (non-condensing) across the operating temperature range	
Dimensions		
Height x Width x Depth	1.3 x 8.38 x 7.16 in (3.302 x 21.2852 x 18.1864 cm)	
Weight	3.8 pounds (1.72365 kg)	

Table A.2 Technical Specifications for the ACS800 Advanced Console System Hardware

# **Appendix B: Zero-touch Provisioning**

The zero-touch provisioning feature is an extension of the console system's BootP configuration retrieval and is a method for deploying many console systems into an environment. You will need a valid DHCP server and TFTP server to use zero-touch provisioning. You can configure your DHCP servers to instruct newly introduced console systems to download a template configuration and upgrade/downgrade firmware.

Setting up the DHCP/TFTP/configuration files should take only a few minutes and will potentially save hours of configuration time for console systems subsequently added to your network. After the provisioning step is completed, console systems can be accessed individually for any post-provision configuration desired (for example, assigning a static IP and a hostname).

With zero-touch provisioning, console systems can be automatically configured and upgraded after they are booted and initialized. This helps facilitate the introduction and installation of the console system into the existing network.

An administrator can view a log of zero-touch configurations by clicking *Monitoring-Zero-touch Log* from the sidebar of the Expert tab.

# B.1 Zero-touch provisioning configuration file

In order to utilize the zero-touch provisioning feature, an administrator must first save a console system's configuration file on a remote server. The configuration file will be referenced by the setup file that will be created for zero-touch provisioning. For information on creating and saving a configuration file, see Configuration files on page 18.

NOTE: Parameters in the configuration file will apply to all console systems receiving the file. If you do not want a parameter to apply to all console systems, for example a host name, make sure you comment it out by entering a pound sign (#) in front of the parameter.

# **B.2 Setup file**

Once the configuration file has been saved on a remote server and the DHCP server has been configured, an administrator needs to create a setup file. The setup file is used by the console system to identify configuration parameters and important provisioning information, such as the firmware image filename, configuration filename and the IP address for the remote server where the configuration file has been saved. The setup file needs to be stored on a server accessible via tftp or wget. The address of the server is sent in the DHCP offer message.

NOTE: It is recommended you store the setup file in the root folder if you're storing it on a TFTP server.

The following is an example of the setup file.

```
ONE_TIME_CONFIG=yes
FIRMWARE_VERSION=2.12.4
FIRMWARE_FILENAME=/tftpboot/firmware_acs8_2.12.4.fl
FIRMWARE_SERVER_IP=192.168.8.100
FIRMWARE_SERVER_PROTOCOL=tftp
```

CONFIG\_FILENAME=/tftpboot/acs8000.cfg CONFIG\_SERVER\_IP=192.168.8.100 CONFIG\_SERVER\_PROTOCOL=tftp

Parameter	Description	
ONE_TIME_ CONFIG	When the parameter is set to Yes, the configuration file is retrieved by the console system on the initial boot; it is not sent on subsequent boots. When set to No, the configuration file is retrieved by the console system each time it is booted.	
FIRMWARE_ VERSION	The version of the firmware to be sent to the appliance.	
FIRMWARE_ FILENAME	The path and file name of the firmware.	
FIRMWARE_ SERVER_IP	The IP address or hostname of the server hosting the firmware.	
FIRMWARE_ SERVER_ USERNAME	If the firmware is hosted on a secure server, the credentials to access the server.	
FIRMWARE_ SERVER_ PASSWORD		
FIRMWARE_ SERVER_ PROTOCOL	The protocol of the server used to host the firmware. Supported protocols include tftp, ftp, stfp, scp and wget.	
CONFIG_ FILENAME	The path and file name of the of the configuration file.	
CONFIG_ SERVER_IP	The IP address or hostname of the server hosting the configuration file.	
CONFIG_ SERVER_ USERNAME	If the configuration file is hosted on a secure server, the credentials to access the server. In most cases, the credentials will be	
CONFIG_ SERVER_ PASSWORD	required. The username is plain text, however the password must be encrypted.	
CONFIG_ SERVER_ PROTOCOL	The protocol of the server used to host the configuration file. Supported protocols include tftp, ftp, stfp, scp and wget.	

#### Table B.1 Setup File Descriptions

### **Password encryption**

An encrypted hash of a password should be created for the FIRMWARE\_SERVER\_PASSWORD or CONFIG\_SERVER\_ PASSWORD parameters. The hash needs to be generated from a Linux environment running openSSL. Enter the following commands at a Linux command prompt or on a console system's shell, as shown. Then enter the resulting hash password into the setup file for the defined server type.

```
echo ACS6000KEYAVOCENTEMERSON > mykey
echo <MyPassword> | openssl enc -base64 -salt -aes-256-cbc -pass file:./mykey
```

NOTE: In the preceding example, replace <MyPassword> with a valid password.

# B.3 Copying the setup file to a server

After creating the setup file, it must be copied to a TFTP server. The following example shows what to enter in your system to copy the files to your server and then verify that the console system can download the file.

Copying the Setup File to a TFTP server:

Example: tftpd-hpa Default TFTP root directory /var/lib/tftpboot ~\$ sudo cp zerotouch.setup /var/lib/tftpboot

# B.4 Obtaining the setup file

After obtaining the IP addresses for both the console system and the TFTP server where you uploaded the setup file, the zero-touch provisioning process will attempt to download the setup file. Once the console system downloads the setup file, it will use the information contained in the file to obtain the image and/or process the configuration of the console system.

# **B.5 DHCP server configuration**

During the boot process, the console system may issue a request, if needed, for an IP address assignment. During this process, the DHCP server will query the DNS server to get the location of the TFTP or HTTP server where the setup file resides. An administrator can, if desired, create an entry on the DHCP server that uniquely identifies a specific console system or range of console systems. This entry filters which console systems are provisioned.

An administrator needs to configure two options. Option 66 defines the hostname or IP address of the TFTP server where the setup file resides. Option 67 defines the name of the setup file (for example acszero.cfg).

#### To configure Options 66 and 67:

- 1. Using the Windows Server Manager or DHCP tools snap-in Microsoft Management Console (MMC), open your DHCP server console.
- 2. In the left panel of the DHCP server window, click IPv4.
- 3. Right-click on Server Options and click Configure Options to configure a global scope.

-or-

Right-click on Scope Options and click Configure Options to configure a single scope.

- 4. Click on Option 066 to enter the location of the server that will host the setup file.
- 5. Enter the host name for the TFTP server.
- 6. Click on Option 067 to enter the name of the setup file.

An administrator can use two additional DHCP options to filter zero-touch provisioning for select console systems. Option 60 defines the vendor class, Avocent\_ACS800/8000<serial number of the console system>. Option 61 defines the MAC address of the console system.

#### To create Options 60 and 61 (optional):

- 1. Using the Windows Server Manager or DHCP tools snap-in MMC, open your DHCP server console.
- 2. In the left panel of the DHCP window, click IPv4.
- 3. From the tab bar, click Action, then click Set Predefined Options from the pull-down menu.
- 4. Under the Options Class, select DHCP Standard Options, then click Add.

- 5. Enter a name for the option in the Name field, select *String* from the Data type drop-down menu, enter **060** in the Code field and enter a description for the option. Click *OK*.
- 6. Repeat step 5, entering 061 in the Code field.

#### **DNS** server

If the DNS scope option is not already defined on your DHCP server, and if the Option 66 entry is a hostname instead of an IP address, you can configure the DNS server.

#### To configure the DNS server:

- 1. Using the Windows Server Manager or DHCP tools snap-in MMC, open your DHCP server console.
- 2. In the left panel of the DHCP window, click IPv4.
- 3. Right-click on Server Options and click Configure Options.
- 4. Click Option 006 to define the DNS servers.
- 5. Enter the IP address in the appropriate field and click Add.

NOTE: If you enter the server name, the DNS server will resolve it.

#### Reservations

You can reserve IP addresses for each console system to be updated. A reservation is an IP address that will be always be issued to a specified console system when it renews its DHCP lease.

#### To reserve an IP address:

- 1. Using the Windows Server Manager or DHCP tools snap-in Microsoft Management Console (MMC), open your DHCP server console.
- 2. In the left panel of the DHCP window, click IPv4.
- 3. Right-click Reservations, then click New Reservation.
- 4. Enter a name for the reservation, the IP address to be assigned to the console system, the MAC address for the console system and a description in the appropriate fields.

#### NOTE: The console system's MAC address can be found on the bottom of console system.

- 5. Under Supported types, use the radio button to select either Both or DHCP only.
- 6. Click Add. The reserved IP address will be displayed in the Reserve table.

The following is an example of a Linux DHCP server configuration.

```
Example: ISC DHCP Server for Linux
Edit /etc/dhcp/dhcpd.conf ...
host acs8048 {
hardware ethernet 00:e0:86:12:34:56;
fixed-address 10.207.24.134;
filename "zerotouch.setup";
next-server 10.207.24.18;
```

# B.6 Enabling zero-touch provisioning

An administrator can enable zero-touch provisioning from either the web UI or the CLI. Once zero-touch provisioning is enabled, you must clear the zero-touch provisioning log.

#### To enable zero-touch provisioning from the web UI:

- 1. From the sidebar of the web UI, click System Security Security Profile.
- 2. Under the Bootp Configuration Retrieval heading, check the boxes to enable Bootp and enable Live Configuration Retrieval.
- 3. Use the drop-down to select *ethO* as the Bootp Interface.
- 4. Click Save.
- 5. From the sidebar of the web UI, click Monitoring Zero-touch Log then click Clear Log.

#### To enable zero-touch provisioning from the CLI:

- 1. Log in to the console system as **root**.
- 2. Type cd system/security/security\_profile/ to navigate to the security profile level.
- 3. Type set bootp\_enabled=yes and press Enter.
- 4. Type set bootp\_interface=eth0 and press Enter.
- 5. Type set enable\_live\_configuration\_retrieval\_(any\_time\_dhcp\_renews)=yes and press Enter.
- 6. Type **commit** to save the configuration.
- 7. Type cd /monitoring/zero-touch\_log/ to navigate to the zero-touch log level.
- 8. Type **clear\_log.** Type **Yes** when prompted if you want to clear the zero-touch provisioning log.

# **Appendix C: Bootp Configuration Retrieval**

You can set your console system to be reconfigured during boot or at IP renewal.

#### To generate configuration to be retrieved:

1. Click System Tools - Save Configuration and save the configuration to either an FTP site or locally.

-or-

Enter **list\_configuration** to get the CLI template scripts, edit the configuration of the console system and save it as a text file.

-or-

Edit a file with CLI commands and save it.

- 2. Transfer the saved file to a DHCP server.
- 3. Configure the DHCP server to transfer the configuration file to the console system.

#### To reconfigure a console system with bootp:

- 1. Click System Security Security Profile. Under the Bootp Configuration Retrieval heading, ensure the Enabled box is checked.
- 2. Uncheck the Enable Live Configuration box. The saved configuration is retrieved and applied on the next reboot.

-or-

Ensure the Enable Live Configuration box is checked. The saved configuration is retrieved and applied on the next IP renewal.

NOTE: You must configure your DHCP server in order to transfer the configuration file to your console system.

# Appendix D: SSH Setup Allowing RSA Keypair Authentication Instead of a Username/Password

To set up a client Linux system to access the ACS800/8000 advanced console system:

- 1. On the console system, create a new admin user. For example: acsadmin.
- 2 Add the new user to the admin and shell-login-profile groups.
- 3. On your Linux-client-system, generate a key pair to use for ssh access to your console system.

```
ssh-keygen -t rsa -b 4096 -C "acsadmin" -f ~/.ssh/acsadmin-id rsa
```

4. Press Enter twice to not install a pass phrase for this keypair on your server.

-or-

Enter a pass phrase.

NOTE: These two files are created by the ssh-keygen above.

\$HOME/.ssh/acsadmin-id\_rsa
\$HOME/.ssh/acsadmin-id rsa.pub

5. On your Linux-client-system, add lines similar to the ones below to your \$HOME/.ssh/config file:

```
Host acsadmin132
HostName <IP address of the console system> for example, 10.207.24.132
User acsadmin
IdentityFile ~/.ssh/acsadmin-id rsa
```

- 6. Log in to the console system via SSH as the user **acsadmin** (the new user).
- 7. Use the four following commands to install the public key for the acsadmin account on the console system.

```
mkdir -p ~/.ssh
touch .ssh/authorized_keys
chmod 600 .ssh/authorized_keys
ssh username@linuxclientsystem "cat .ssh/acsadmin-id_rsa.pub" >> .ssh/authorized_keys
```

For example, for the ssh command, enter the following:

```
ssh adminuser@10.207.24.28 "cat .ssh/acsadmin-id_rsa.pub" >> .ssh/authorized_keys
```

 From the System - Security - Security Profile tab of the web UI, uncheck the box to disable SSH allows authentication via username/password. The next SSH login from your Linux-client-system to the console system will succeed using the keypair and you will not be prompted for a password.

NOTE: Disabling this feature will prevent any user who does not have a keypair established on both the client and the console system from logging in to the console system via SSH. You also will not be able to launch serial sessions from the web UI, since those require username/password authentication.

An example ssh login command using the given.ssh/config host entry is: ssh acsadmin@acsadmin132.

# Appendix E: Port Information for Communication with the Vertiv<sup>™</sup> Avocent® DSView Software

The following ports on an Avocent ACS800/8000 advanced console system can accept connections from the Vertiv™ Avocent® DSView management software:

- TCP port 3502 (https)
- TCP port 3871 (adsap2)
- UDP port 3211 (aidp)
- TCP port 22 (sshd)

The following ports in the Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView software can accept connections from the console system:

- TCP port 4122 (default: SSH server)
- TCP port 4514 (default: data logging or Syslog server)

# Appendix F: Accessing a Console System with a Vertiv™ Avocent® DSView Software Installation via Dial-up

When a Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView software user establishes a serial session, the following events occur:

- The user selects a serial port to access.
- A viewer is downloaded from the Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView server to the user's workstation.
- The Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView software passes information to the viewer, such as an authorization key, the IP address and serial port of the console system.
- The viewer then accesses the serial port of the console system through an SSH session by passing the authorization key obtained from the Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView server.
- The serial session begins.

To ensure constant connectivity, a Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView server can be configured Out of Band (OOB) that will allow it to call a console system via modem in the event of a network or Internet failure.

# F.1 Installing Vertiv<sup>™</sup> Avocent® DSView software out of band

The Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView server must be running on hardware that has a connected modem, and the console system must have a built-in modem or access to a modem via USB or serial port.

For this installation, the Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView server must be the central point of reception of both the packets leaving the downloaded viewer and the console system. To ensure this, Proxy mode must be configured within the Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView software. The viewer will then point to the Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView server (not the console system) to establish the SSH connection. The Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView server would then route the packets by changing both the source and destination IP addresses and act as a middle point of communication.

Under normal operating conditions, packets received from the serial viewer would route through the Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView server via Ethernet. In an error state, the Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView server would detect that the normal path to the console system was interrupted and would dial out to the console system, pass authentication and establish a PPP connection. Packets that would normally pass via Ethernet would instead be routed via PPP.

Because of the speed differences between Ethernet and dial-up, performance would be notably slower. Multiuser connections would further degrade performance and are not recommended. For this reason, dial-up backup is recommended as an emergency backup feature only.

# F.2 Configuring dial-up for a console system

#### To configure dial-up to a console system within the Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView software:

- In a Units view window containing appliances, select the ACS800/8000 console system you want to configure. For dial-in with callback, you must first select DSView Server - Properties - DSView Modem Sessions under the System tab and enter the the phone number assigned to the Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView server in the Analog Phone Number field.
- 2. Select DSView Settings Dial-up and click Enable Dial-up.
- 3. Select Modem Type Analog.
- 4. Enter the phone number for the console system you want to use.
- 5. Enter the PPP User and select the PPP Auth Protocol in the appropriate fields.
- 6. For dial-in with callback, enable the dial-back checkbox.
- 7. Select *DSView Settings Dial-up PPP Password*, then enter and confirm the password needed to access the ACS800/8000 console system.
- 8. Select DSView Settings Dial-up IP Addresses.

- 9. Click *Generate Automatically* to set the IP address automatically or enter the PPP Local IP address and Appliance IP address manually.
- 10. Select DSView Settings Dial-up and click Save.
- 11. To configure a console system to receive the dial-up connection within the Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView software:
- 12. In a Units view window containing appliances, select the ACS800/8000 console system you want to configure.
- 13. For the internal modem, select Ports Internal Modem and select the modem.
- 14. Select DSView Settings Dial-up and click Push Configuration.

# NOTE: The following step is only required if *CHAP* was selected in the PPP Auth Protocol field in the Vertiv<sup>™</sup> Avocent<sup>®</sup> DSView software Settings Dial-up window.

15. Log in to the CLI of the console system and access the Linux shell. Edit the /etc/ppp/chap-secrets and add a line in the format, where the first column should have the PPP user and the third column should have the PPP password as is shown in the following example:

pppuser \* "ppppassword" \*

# Appendix G: Internal Analog Modem

Some models of the console system come equipped with an internal analog modem. This modem is used to originate and answer phone calls and establish communication with other modems to transmit data.

Controlling the modem's functions is done by using the "AT" commands. These commands are used to instruct the modem to perform functions, such as dialing or answering calls, and are normally automatically issued by communication software. However, for some applications, custom software may have to be written due to the absence of a normal operating system.

The modem will automatically accept and process AT commands at most standard DTE (Data Terminal Equipment) speeds and parity settings. For each command issued, the modem will respond with a result code to inform you of the modem's status. The format of a basic AT command and result code is as follows:

AT<Command><CR>

OK

AT = Attention.

<Command> = any valid command

<CR> = Carriage Return or Enter key

OK = Result Code

#### Table G.1 Sample Command String

Command	Description
ATDT7678900 <cr></cr>	Instructs the modem to dial the number 7678900 and attempt to connect to the remote device.
ATSO=2 <cr></cr>	Enables auto answer option. When the modem detects a ring, it will attempt to answer after two rings.

Command	Description	
ATA/	Repeat the previous command.	
ATA	Answer.	
ATB0	CCITT operation at 300 or 1200 bps.	
ATB1	Bell operation at 300 or 1200 bps (default).	
ATD	Dial.	
ATDO-9	Dial the DTMF digits 0 to 9.	
ATDA-D	Dial the DTMF digits A, B, C and D.	
ATDP	Select <i>pulse dialing</i> ; effects current and subsequent dialing.	
ATDT	Select tone dialing; effects current and subsequent dialing.	
ATD!	Flash: go on-hook by time defined by S29.	
ATDW	Wait for dial tone detection before dialing a number. If no dial tone is detected within the time specified by S7, the modem aborts the rest of the sequence, goes on-hook and generates an error message.	
ATD@	Wait for five seconds of silence before proceeding with next dialing string and then complete handshake sequence.	
ATD,	Pause. The modem pauses for a time specified by S8 before dialing the number. Most often used when dialing an outside line through a PBX.	
ATD;	Return to the command mode after processing the command.	
ATEO	Disables the command echo.	
ATE1	Enables the command echo (default).	
ATHO	Hang up.	
ATH1	Forces the modem off-hook.	
ATIO	Reports product code.	
ATI2	Reports OK (for software compatibility).	
ATI3	Reports the firmware version of the modem. Example: CX810801-V90.	
ATLO	Sets the speaker volume off.	
ATL1	Sets the speaker volume low (default).	
ATL2	Sets the speaker volume medium.	
ATL3	Sets the speaker volume high.	
ATM0	Speaker is always off.	
ATM1	Speaker is on during call establishment but goes off when carrier is detected (default).	
ATM2	Speaker is always on.	
ATM3	Speaker is off during dialing and when receiving carrier but on during answering.	
ATQ0	Enables result codes to the DTE (default).	
ATQ1	Disables result codes to the DTE.	
ATSr	Establishes S-register "r" as the default register.	
ATSr=n	Sets S-register "r" to the value "n."	
ATSr?	Reports the value of S-register "r."	
ATV0	Enables short-form result codes.	
ATV1	Enables long-form result codes.	

#### Table G.2 Basic AT Commands

Command	Description		
ATWO	Upon connection, the modem reports only the DTE speed (for example, CONNECT 9600). Subsequent responses are disabled (default).		
ATW1	Upon connection, the modem reports the modulation type, line speed, the error correction protocol and the DTE speed. Subsequent responses are disabled.		
ATW2	Upon connection, the modem reports DCE speed (for example, CONNECT 2400). Subsequent responses are disabled.		
ATXO	Ignores dial and busy tone. Sends CONNECT message when a connection is established by blind dialing.		
ATX1	Disables monitoring of busy tones. Sends only OK, CONNECT, RING, NO CARRIER and ERROR messages. If busy tone detection is enforced and busy tone is detected, NO CARRIER will be reported instead of BUSY. If dial tone detection is enforced or selected and dial tone is not detected, NO CARRIER will be reported instead of NO DIALTONE.		
ATX2	Disables monitoring of busy tones. Sends only OK, CONNECT, RING, NO CARRIER, ERROR, NO DIALTONE and CONNECT XXXX. If busy tone detection is enforced and busy tone is detected, NO CARRIER, will be reported instead of BUSY. If dial tone detection is enforced or selected and dial tone is not detected, NO CARRIER will be reported instead of NO DIALTONE.		
ATX3	Enables monitoring of busy tones. Sends only OK, CONNECT, RING, NO CARRIER, ERROR, NO DIALTONE and CONNECT or CARRIER XXXX. If dial tone detection is enforced and dial tone is not detected, NO CARRIER will be reported.		
ATX4	Enables monitoring of busy tones. Sends all messages (default).		
ATZ0	Soft reset.		
AT&CO	DCD remains on at all times.		
AT&C1	DCD follows the state of the carrier (default).		
AT&D0	Ignores DTR.		
AT&D1	Enters the escape mode when ON-to-OFF transition is detected on DTR.		
AT&D2	Hangs up, assumes command state and disables auto answer upon detecting ON-to-OFF transition of DTR (default).		
AT&D3	ON-to-OFF transition causes the modem to perform a soft reset. It is the same as if an ATZ command is issued.		
AT&F	Restores factory configuration.		
AT&G0	Disables guard tone (default).		
AT&G1	Enables 550-Hz guard tone.		
AT&G2	Enables 1800-Hz guard tone.		
AT&KO	Disables flow control.		
AT&K3	Enables RTS/CTS flow control (default for data modes).		
AT&K4	Enables XON/XOFF flow control.		
AT&K5	Supports transparent XON/XOFF flow control.		
AT&PO	39/61 make/break ratio at 10 pulses per second (default).		
AT&P1	33/67 make/break ratio at 10 pulses per second.		
AT&P2	39/61 make/break ratio at 20 pulses per second.		
AT&P3	33/67 make/break ratio at 20 pulses per second.		
AT&Q0	Selects direct asynchronous operation.		
AT&Q5	Modem will try an error-corrected link.		
AT&Q6	Selects asynchronous operation in normal mode (allows speed buffering and flow control but no error correction).		
AT&V	Displays modem's current configuration. When this command is entered, the modem will display its current command and register settings.		
AT%C0	Disables data compression.		
AT%C1	Enables MNP 5 data compression.		

#### Table G.3 Basic AT Commands (continued)

Command	Description
AT%C2	Enables V.42 bis data compression (sets S46 bit 1).
AT%C3	Enables V.42 bis and MNP 5 data compression (default).
AT%E0	Disables line quality monitor and auto-retrain.
AT%E1	Enables line quality monitor and auto-retrain.
AT%E2	Enables line quality monitor and fallback/fall-forward (default).
AT%L	Line signal level. Returns a value that indicates the received signal level. Example, 009 = -9dBM.
AT%Q	Line signal quality. Reports line signal quality (DAA-dependent). Returns higher order byte of the EQM value. Based on EQM value, retrain or fallback/fall-forward may be iniated if enabled with AT%E1 or AT%E2 commands.
AT+MS	Select/force modulation.

#### Table G.4 Basic AT Commands (continued)

# G.1 AT+MS modulation selection

This extended-format compound parameter controls the manner of operation of the modulation capabilities in the modem. It accepts six sub-parameters:

+MS=<carrier>, <automode>, <min\_tx\_rate>, <max\_tx\_rate>, <min\_rx\_rate), <max\_rx\_rate><CR>.

To read the current settings, enter AT+MS?<CR>.

Table G.5 + MS Command Supported Rates

Modulation	Carrier	Description	
Bell 103	B103	300	
Bell 212	B212	1200	
V.21	V21	300	
V.22	V22	1200	
V.22 bis	V22	2400 or 1200	
V.23	V23C	1200rx/75tx or 75rx/1200tx	
V.32	V32	9600 or 4800	
V.32 bis	V32B	14400, 12000, 9600, 7200 or 4800	
V.34	V34	33600, 31200, 28800, 26400, 19200, 16800, 14400, 12000, 9600, 7200, 4800 or 2400	
V.90	V90	56000, 54667, 53333, 52000, 50667, 49333, 48000, 46667, 45333, 42667, 41333, 40000, 38667, 37333, 36000, 34667, 33333, 32000, 30667, 29333, 28000	
K56flex	K56	56000, 54000, 52000, 50000, 48000, 46000, 44000, 42000, 40000, 38000, 36000, 34000, 32000	
V92 downstream	V92	000, 54667, 53333, 52000, 50667, 49333, 48000, 46667, 45333, 42667, 41333, 40000, 38667, 37333, 36000, 34667, 333, 32000, 30667, 29333, 28000	
V92 upstream	V92	48000, 46667, 45333, 42667, 41333, 40000, 38667, 37333, 36000, 34667, 33333, 32000, 30667, 29333, 28000, 26667, 25333, 24000	

# G.2 Set telephone extension option

This command enables/disables "line-in-use" and "extension pickup" options.

Table G.6 Set Telephone Extension Options

-STE=n Value	Extension Pickup	Line-In-Use
0 (default)	Disabled	Disabled
1	Disabled	Enabled
2	Enabled	Disabled
3	Enabled	Enabled

If the line is in use and the modem receives an ATDT command to dial out, the modem will not go off hook and will display the "LINE-IN-USE" result code. If the modem is off hook and the extension is picked up, the modem will drop the connection and display the "OFF-HOOK INTRUSION" result code.

# G.3 AT S registers

The S registers use the following format: ATSr=n<CR> where the "r" is the S register number and "n" is the parameter to set it to. To read the current contents of an S register, issue an ATSr?<CR> command where "r" is the register in question. The modem will then display the value of the S register.

Register	Range	Units	Default	Description	
SO	0-255	Rings	0	Ring to answer on. ATSO=1 <cr> means answer call on first ring detected.</cr>	
SI	0-255	Rings	0	Number of rings counted.	
S2	0-127	ASCII	43	Escape code character.	
S3	0-127	ASCII	13	Command terminator <cr>.</cr>	
S4	0-127	ASCII	10	Line feed character.	
S5	0-127	ASCII	8	Backspace character.	
S6	2-255	Seconds	2	Wait time for dial-tone detection.	
S7	1-255	Seconds	50	Wait time for carrier.	
S8	0-255	Seconds	2	Pause time for coma in dial string.	
S10	1-255	.1sec	14	Loss of carrier to hang up delay.	
S11	50-255	.01sec	85	DTMF tone duration.	
S12	0-127	1/50 sec	50	Escape code guard time.	
S24	0-255	1sec	0	Sleep mode inactivity timer.	
S29	0-255	10mS	70	Hook flash dial modifier time.	
S30	0-255	10Sec	0	Inactivity disconnect timer.	
S95			0	Result code control.	

Table G.7 AT S Registers

# G.4 Basic modem result codes

There are basic codes the modem will issue in response to processing an AT command. Result codes may be displayed either in word (V1) or numeric (V0) format by using the Vn command. The Qn command controls if result codes are issued (Q0) or not issued (Q1). The Xn, Wn commands and register S95 determines which result code format the modem will display to indicate the type of connection established. There are more than 300 codes. The most commonly used are listed in the table below.

Numeric	Verbose	Description
0	OK	The modem has received and acknowledged the command.
1	CONNECT	Connection made at 300bps or extended result codes are off (X0).
2	RING	An incoming ring signal has been detected.
3	NO CARRIER	This result code reflects either an intended disconnect or a failure to complete a connection.
4	ERROR	An invalid command was issued to the modem.
5	CONNECT 1200	Indicates a 1200bps line or DTE connection.
6	NO DIALTONE	
7	BUSY	The modem has detected a busy tone.
8	NO ANSWER	After S7 time has elapsed, the remote server never answered.
10	CONNECT 2400	Line speed or DTE connection at 2400bps.
12	CONNECT 9600	Line speed or DTE connection at 9600bps.
15	CONNECT 14400	Line speed or DTE connection at 14400bps.
16	CONNECT 19200	Line speed or DTE connection at 19200bps.
17	CONNECT 38400	Line speed or DTE connection at 38400bps.
18	CONNECT 57600	Line speed or DTE connection at 57600bps.

#### Table G.8 Basic Result Code Listing

# G.5 Digital line guard

The modem has an optional Digital Line Guard Circuit that automatically detects an over current situation on the Tip and Ring pins. When the modem goes off hook, it will immediately check the current on the Tip and Ring pins. If the current exceeds 150 mA, the modem will display the "DIGITAL LINE DETECTED" result code and then go back on hook. The modem will continue to display this result code until normal current is detected on the Tip and Ring pins during an off hook condition. The DLG feature will protect the modem in case it is accidentally connected to a Digital Telephone Line.

# G.6 Sleep mode operation

The modem can be set to enter the low power sleep mode by setting **ATS24=n**. In this case, "n" is time, in seconds, that the modem will operate in normal mode with no detected telephone line or DTE line activity before entering low power sleep mode. The timer is reset upon any DTE or telephone line activity. If S24 is set to zero, the modem will never enter the low power sleep mode.

# G.7 Disconnecting a call

There are several ways to disconnect a call. Below are the choices.

Resetting the modem's power or toggling the Reset Line (Pin #12) will disconnect and put the modem back into the OFF line state.

An ON to OFF transition of the DTR signal (Pin #4) will also disconnect the modem. If you use this method, check to make sure that the DTR command is set to &D2 or &D3 and not forced (&D0).

The remote device can also cause the modem to disconnect. If the remote modem disconnects, your modem will automatically sense the loss of the carrier signal and return to the OFF line state.

The ATH or ATZ commands can also be used to disconnect a call. In order to issue a command to the modem when it is On Line, the modem must be placed into the On Line Command State. This is accomplished by issuing a special escape sequence. The default value of this three digit escape sequence is the "+" character (see S2 to change). The "+++" is protected by a one-second delay before and after it is sent (see S12 to change the time) When the modem detects the escape sequence, the OK result Result code will be displayed and the modem is in the On Line Command State. The ATH or ATZ command can now be issued to disconnect the call.

## G.8 Selecting country codes

Setting the modem's country code is done by with the +GCI command. To change to one of the 30 available countries, issue the AT+GCI=n command where "n" is one of the two digit country codes. This command must be issued each the modem is turned on. It will not automatically store or save this setting. It should be part of the Initialization string.

Example: AT+GCI=00<CR> Meaning: Change country code to Japan.

**OK** Meaning: The modem has accepted the command and is

now configured to operate in Japan

AT+GCI?<CR> Meaning: Display current country code

+GCI:00 Meaning: (Japan is the current country selected).

ΟK

To view which countries are available in the modems firmware, enter AT+GCI=?<CR>.

The modem will display all of the possible two-digit country codes available.

Country	Code	Country	Code	Country	Code
Australia	09	Hong Kong	50	Poland	8A
Austria	Austria 0A		53	Portugal	8B
Belgium	OF	Ireland	57	South Africa	9F
Brazil	16	Italy	59	Singapore	9C
China	26	Japan	00	Spain	AO
Denmark	31	Korea	61	Sweden	A5
Finland	3C	Mexico	73	Switzerland	A6
France	3D	Netherlands	7B	Taiwan	Fe
Germany 42 Norway		Norway	82	TBR21	FD
United States	B5	United Kingdom	B4		

Table G.9 Country Codes List

# G.9 Using caller ID

The modem can be used to display certain information about incoming telephone calls. The modem can inform you of the date, time, telephone number and name associated with incoming calls. When the CID option is enabled, information will be displayed between the first and second incoming "RING." In order for this feature to work properly, the telephone line connected to the modem must subscribe to caller ID service offered by the local telephone company. A sample of the displayed information is shown below:

RING

DATE = 0513

TIME = 1346

NMBR = 408 767 8900

NAME = RADICOM RESEARCH

RING

The CID information can either be presented formatted as shown previously or unformatted. The +VCID and +VRID commands control the modem CID option.

#### Table G.10 Caller ID Information

Command	Parameter	Description	
+VCID?	N/A	Display current +VCID setting (0-2)	
+VCID=	0	Disable caller ID reporting (default).	
+VCID=	1	Enable caller ID with formatted presentation to the DTE.	
+VCID+	2	Enable caller ID with unformatted presentation to the DTE.	
+VRID=	0	Displays the formatted caller ID of the last received call.	
+VRID+	1	Displays the unformatted caller ID of the last received call.	

# Appendix H: Regulatory Information Concerning the Analog Modem Installed in this Product

# H.1 Analog telecom safety warnings

Before servicing, disconnect this product from its power source and telephone network. Also:

- Never install telephone wiring during a lightning storm.
- Never install a telephone jack in wet locations unless the jack is specifically designed for wet locations.
- Never touch uninsulated telephone wires or terminals unless the telephone line has been disconnected at the network interface.
- Use caution when installing or modifying telephone lines.

# H.2 Avertissements de sécurité télécom analogique

Avant de l'entretien, débrancher ce produit de son réseau d'alimentation et de téléphone. également:

- Ne jamais installer du câblage téléphonique pendant un orage électrique.
- Ne jamais installer de prises téléphoniques à des endroits mouillés à moins que la prise ne soit conçue pour de tels emplacements.
- Ne jamais toucher fils ou des bornes téléphoniques non isolés à moins que la ligne téléphonique n'ait été déconnectée au niveau de l'interface réseau.
- Faire preuve de prudence au moment d'installer ou de modifier des lignes téléphoniques.

# H.3 International modem restrictions

Some dialing and answering defaults and restrictions may vary for international modems. Changing settings may cause a modem to become non-compliant with national regulatory requirements in specific countries. Also note some software packages may have features or lack restrictions that may cause the modem to become noncompliant.

#### U.S.A., 47 CFR Part 68 Telecom

 This equipment complies with Part 68 of the 47 CFR rules and the requirements adopted by the ACTA (Administrative Council for Terminal Attachments). Located on this equipment is a label that contains, among other information, the registration number and Ringer Equivalence Number (REN) for this equipment or a product identifier in the format:

For current products: US:AAAEQ##Txxxx.

For legacy products: AU7USA-xxxxx-xx-x.

If requested, this number must be provided to the telephone company.

- 2. A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable 47 CFR Part 68 rules and requirements adopted by the ACTA. It's designed to be connected to a compatible modular jack that is also compliant.
- 3. The Ringer Equivalence Number (REN) is used to determine the number of devices that may be connected to a telephone line. Excessive RENs on a telephone line may result in the devices not ringing in response to an incoming call. In most but not all areas, the sum of RENs should not exceed five (5.0). To be certain of the number of devices that may be connected to a line, as determined by the total RENs, contact the local telephone company. For products approved after July 23, 2001, the REN for this product is part of the product identifier that has the format US:AAAEQ##Txxxx. The digits represented by ## are the REN without a decimal point (e.g., 03 is a REN of 0.3). For earlier products, the REN is separately shown on the label.

- 4. If this equipment causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. But if advance notice isn't practical, the telephone company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary.
- 5. The telephone company may make changes in its facilities, equipment, operations or procedures that could affect the operation of the equipment. If this happens, the telephone company will provide advance notice in order for you to make necessary modifications to maintain uninterrupted service.
- 6. If trouble is experienced with this equipment, please contact Vertiv at the address shown below for details of how to have the repairs made. If the equipment is causing harm to the telephone network, the telephone company may request that you disconnect the equipment until the problem is resolved.
- 7. Manufacturing Information on telecommunications device (modem):

Manufacturer: Multi-Tech Systems, Inc.
Trade Name: Socket Modem SocketModem SocketModem
Model Number: MT5692SMI
Registration No: US:AU7MM01BMT5692SMI
Ringer Equivalence: 0.1B
Modular Jack (USOC): RJ11C or RJ11W or RJ45 (single line)
Vertiv
4991 Corporate Drive
Huntsville, AL 35805 USA
1-888-793-8763

# H.4 Thailand approval for MT5692SMI

This telecom device conforms to NTC1 requirements.

1NTC is the National Telecommunications Commission, Thailand's telecommunications regulator.

"เครื ่ องโทรคมนาคมและอ≬ ปกรณ่ นี่ ้ มี ความสอดคล้ องตามข้ อก าหนดของ กทช."

# H.5 New Zealand telecom warning notice

1. The grant of a Telepermit for any item of terminal equipment indicates only that Telecom has accepted that the item complies with minimum conditions for connection to its network. It indicates no endorsement of the product by Telecom, nor does it provide any sort of warranty. Above all, it provides no assurance that any item will work correctly in all respects with another item of Telepermitted equipment of a different make or model, nor does it imply that any product is compatible with all of Telecom's network services.

This equipment is not capable under all operating conditions of correct operating conditions of correct operation at the higher speed which it is designated. 33.6 kbps and 56 kbps connections are likely to be restricted to lower bit rates when connected to some PSTN implementations. Telecom will accept no responsibility should difficulties arise in such circumstances.

- 2. Immediately disconnect this equipment should it become physically damaged and arrange for its disposal or repair.
- 3. This modem shall not be used in any manner which could constitute a nuisance to other Telecom customers.

4. This device is equipped with pulse dialing, while the Telecom standard is DTMF tone dialing. There is no guarantee that Telecom lines will always continue to support pulse dialing.

Use of pulse dialing, when this equipment is connected to the same line as other equipment, may give rise to 'bell tinkle' or noise and may also cause a false answer condition. Should such problems occur, the user should NOT contact the Telecom Faults Service.

The preferred method of dialing is to use DTMF tones, as this is faster than pulse (decadic) dialing and is readily available on almost all New Zealand telephone exchanges.

- 5. Warning Notice: No '111' or other calls can be made from this device during a mains power failure.
- 6. This equipment may not provide for the effective hand-over of a call to another device connected to the same line.
- 7. Some parameters required for compliance with Telecom's Telepermit requirements are dependent on the equipment (PC) associated with this device. The associated equipment shall be set to operate within the following limits for compliance with Telecom's Specifications:

For repeat calls to the same number:

- There shall be no more than 10 call attempts to the same number within any 30 minute period for any single manual call initiation, and
- The equipment shall go on-hook for a period of not less than 30 seconds between the end of one attempt and the beginning of the next attempt.

For automatic calls to different numbers:

- The equipment shall be set to ensure that automatic calls to different numbers are spaced such that there is no less than 5 seconds between the end of one call attempt and the beginning of another.
- 8. For correct operation, total of the RNs of all devices connected to a single line at any time should not exceed 5.

### H.6 Japan requirements

The modem conforms to (JATE) Japan Approval Institute for Telecommunications Equipment:

MT5692SMI - JATE Approval A09-0123001

This page intentionally left blank

### **Connect with Vertiv on Social Media**



https://www.facebook.com/vertiv/



https://www.instagram.com/vertiv/



https://www.linkedin.com/company/vertiv/

https://www.twitter.com/Vertiv/



Vertiv.com | Vertiv Headquarters, 505 N Cleveland Ave, Westerville, OH 43082 USA

© 2024 Vertiv Group Corp. All rights reserved. Vertiv™ and the Vertiv logo are trademarks or registered trademarks of Vertiv Group Corp. All other names and logos referred to are trade names, trademarks or registered trademarks of their respective owners. While every precaution has been taken to ensure accuracy and completeness here, Vertiv Group Corp. assumes no responsibility, and disclaims all liability, for damages resulting from use of this information or for any errors or omissions.