ON
OFF
MAINTENANCE
BYPASS
BREAKER COVER
WARNING:
QUALIFIED SERVICE PERSONNEL ONLY.
THE COVER MUST BE SECURED
WITH CAPTIVE SCREW FOR
NORMAL UPS OPERATION.
UP FOR TOWER INSTALLATION
USE COPPER CONDUCTOR ONLY
ON
OFF
OUTPUT BREAKER 30A
ON
OFF
OUTPUT BREAKER 20A
ON
OFF
OUTPUT BREAKER
50A
ON
OFF
MAINTENANCE
BYPASS BREAKER
20A
MAINTENANCE
BYPASS BREAKER
50A
ON
OFF
INPUT BREAKER
50A