ON
OFF
MAINTENANCE
BYPASS
BREAKER COVER
WARNING:
QUALIFIED SERVICE PERSONNEL ONLY.
USE COPPER CONDUCTOR ONLY
UP FOR TOWER INSTALLATION
THE COVER MUST BE SECURED
WITH CAPTIVE SCREW FOR
NORMAL UPS OPERATION.
OUTPUT BREAKER 30A
OUTPUT BREAKER 20A
OUTPUT
BREAKER
63A
MAINTENANCE
BYPASS BREAKER
20A
MAINTENANCE
BYPASS BREAKER
63A
OUTPUT
INPUT
INPUT
BREAKER
63A